

## **MPSHF2 Clip Point Blade Black Handle - MPSHF2CP Clip Point Blade Black Handle Clam Pack**

- 8Cr13MoV Ti-Nitride Coated High Carbon S.S. Blade Glass Filled Nylon Handle
- Full Tang
- Thumb Jimping
- Thin Profile
- Lanyard Hole, Belt Loop and Nylon Fiber Sheath

NO IMAGE  
AVAILABLE

### **Attributes**

- Name: MPSHF2CP Clip Point Blade Black Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001466
- Mfr. No.: 1085879
- Color: Black
- Delivery weight: 0.2kg
- Shipping height: 260mm
- Shipping width: 42mm
- Shipping length: 83mm
- UPC: 661120413783

# Table of Contents

- [Startpage](#)
- [English: M&P MPSHF2 Clip Point Blade Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P MPSHF2 Clip Point Blade](#)

# M&P MPSHF2 Clip Point Blade Safety Instructions

## Introduction

Thank you for purchasing the M&P MPSHF2 Clip Point Blade. This product is designed to provide reliable performance while ensuring your safety during use. Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

## General Safety Guidelines

- Always handle the knife with care to avoid cuts or injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in good condition.
- Use the knife only for its intended purpose; do not use it for tasks it is not designed for.
- Store the knife in a safe place when not in use, preferably in its sheath.
- Report any unsafe conditions or incidents to the appropriate authorities.

## Specific Safety Precautions for Use

- Ensure that the blade is sharp before use to prevent excessive force that could lead to accidents.
- Always cut away from your body and keep your fingers clear of the cutting path.
- Use a stable surface when cutting to maintain control of the knife.
- Avoid using the knife in wet or slippery conditions to prevent loss of grip.
- Do not engage in horseplay or distractions while using the knife.
- If the knife becomes damaged or shows signs of wear, discontinue use immediately and contact customer support.

## Instructions for Installation and Usage

### 1. Unpacking the Knife

- Carefully remove the knife from the clam pack.
- Inspect the knife for any visible damage or defects.

### 2. Using the Knife

- Hold the knife by the handle securely, ensuring your grip is firm.
- Use the thumb jimping for better control during cutting tasks.
- For tasks requiring precision, use a slow and steady motion.

### 3. Storing the Knife

- After use, clean the blade with a damp cloth and dry it thoroughly.
- Place the knife back into the nylon fiber sheath to protect the blade and ensure safety.
- Store the knife in a designated area, away from children and pets.

## Disposal Instructions

- Dispose of the knife responsibly in accordance with local regulations.
- If the knife is damaged beyond use, wrap it in protective material to prevent injury and dispose of it in a secure manner.

## **Contact Information for Further Support**

For any safety inquiries or concerns regarding the M&P MPSHF2 Clip Point Blade, please contact the designated EUbased support team. Ensure you have the product details ready for assistance.

## **Conclusion**

By following these safety instructions, you can ensure a safe and enjoyable experience with your M&P MPSHF2 Clip Point Blade. Always prioritize safety and be mindful of your surroundings while using this product. Thank you for choosing M&P.

# Säkerhetsinstruktioner för M&P MPSHF2 Clip Point Blade

## Introduktion

Tack för att du har valt M&P MPSHF2 Clip Point Blade. Denna säkerhetsinstruktionsguide är utformad för att ge dig viktig information om säker användning, installation och avfallshantering av produkten. Vänligen läs igenom denna guide noggrant för att säkerställa en säker och effektiv användning.

## Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera eventuella osäkra produkter eller olyckor till myndigheterna.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

## Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar när du hanterar kniven för att förhindra skador.
- Se till att bladet är i gott skick innan användning; byt ut det om det är skadat.
- Använd kniven för dess avsedda syfte och undvik att använda den på hårda ytor som kan skada bladet.
- Förvara kniven på en säker plats när den inte används, helst i ett fodral eller en säkerhetslåda.
- Var försiktig med tummjimping för att undvika att tappa kontrollen över kniven.

## Instruktioner för installation och användning

1. **Öppna förpackningen:** Ta bort kniven från förpackningen med försiktighet.
2. **Inspektera kniven:** Kontrollera att kniven är hel och utan skador.
3. **Användning av kniven:**
  - Håll kniven i ett fast grepp.
  - Använd tummjimping för att få bättre kontroll över bladet.
  - Skär alltid bort från kroppen och andra personer.
4. **Rengöring:** Rengör kniven efter varje användning med en fuktig trasa och torka den ordentligt.
5. **Förvaring:** Förvara kniven på en torr plats, borta från direkt solljus och fukt. Använd en nylonfiberficka eller ett fodral för att skydda bladet.

## Avfallshanteringsinstruktioner

- Kassera förpackningen och eventuella oanvändbara delar enligt lokala avfallsregler.
- Återvinn materialet där det är möjligt.
- Tillsammans med kniven, se till att alla delar är säkert förpackade för att förhindra skador på andra under transport till avfallsstationen.

## Kontaktinformation för ytterligare support

För frågor eller mer information om produkten, vänligen kontakta tillverkaren eller den lokala distributören. Se till att ha produktens modellnummer och inköpsinformation tillgänglig.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet!