

MPBG30 Bodyguard Clip Point Blade Black Handle

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Glass Filled Textured Nylon Handle
- Finger Actuator
- Liner Lock
- Dual Thumbstuds
- Pocket Clip and Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: MPBG30 Bodyguard Clip Point Blade Black Handle
- Manufacturer: M&P
- Product no.: EU1001473
- Mfr. No.: 1085890
- Color: Black
- Delivery weight: 0.077kg
- Shipping height: 25mm
- Shipping width: 34mm
- Shipping length: 70mm
- UPC: 661120413899

Table of Contents

- [Startpage](#)
- [English: M&P MPBG30 Bodyguard Clip Point Blade Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P MPBG30 Bodyguard Clip Point Blade Black Handle](#)

M&P MPBG30 Bodyguard Clip Point Blade Safety Instruction Guide

Introduction

Thank you for choosing the M&P MPBG30 Bodyguard Clip Point Blade. This guide provides essential safety instructions to ensure the safe use and handling of your knife. Please read and follow these instructions carefully to minimize risks and enhance your experience with the product.

General Safety Guidelines

- Always keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in good working condition.
- Use the knife only for its intended purpose; do not use it for tasks it was not designed for.
- Store the knife in a safe place when not in use, preferably in a secure sheath or holder.
- Do not attempt to modify or alter the knife in any way.
- If the knife becomes damaged or shows signs of wear, discontinue use immediately and seek a replacement.
- Report any accidents or unsafe conditions to the appropriate authorities.

Specific Safety Precautions for Use

- Always handle the knife with care and respect.
- Keep your fingers and other body parts clear of the blade while opening and closing.
- Use the finger actuator to safely open the blade.
- Always engage the liner lock when the blade is open to prevent accidental closure.
- Use the dual thumbstuds to open the knife; do not force the blade open.
- When using the knife, cut away from your body and avoid pointing the blade at yourself or others.
- Always ensure the area around you is clear of obstacles and people when using the knife.
- If carrying the knife in your pocket, use the pocket clip securely to prevent accidental drops.

Instructions for Installation and Usage

- To open the knife:
 - Locate the dual thumbstuds on either side of the blade.
 - Use your thumb to push the thumbstud outward until the blade is fully extended.
 - Ensure the liner lock engages to secure the blade in the open position.
- To close the knife:
 - Press the liner lock down to release the blade.
 - Carefully fold the blade back into the handle while keeping fingers clear of the blade path.
- To attach the pocket clip:
 - Align the clip with the designated hole on the handle.
 - Secure the clip in place using the provided screws (if applicable).
- To use the lanyard hole:
 - Thread a lanyard or cord through the hole for added security when carrying.

Disposal Instructions

- When the knife reaches the end of its useful life, dispose of it responsibly.
- Do not throw the knife in regular household waste.
- Check local regulations for proper disposal methods, which may include recycling or hazardous waste disposal.
- Ensure the blade is covered or secured to prevent injury during disposal.

Contact Information for Further Support

For any questions or concerns regarding the M&P MPBG30 Bodyguard Clip Point Blade, please refer to the manufacturer's website or contact your local retailer for assistance.

Thank you for following these safety instructions. Enjoy your M&P MPBG30 Bodyguard Clip Point Blade responsibly!

Säkerhetsinstruktioner för M&P MPBG30 Bodyguard Clip Point Blade Black Handle

Introduktion

Tack för att du valt M&P MPBG30 Bodyguard Clip Point Blade Black Handle. Denna kniv är designad för att ge användaren en säker och effektiv upplevelse. För att säkerställa säker användning och för att följa EU:s allmänna produkt säkerhetsförordning (GPSR) har vi sammanställt följande säkerhetsinstruktioner.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera alltid att kniven är i gott skick innan användning.
- Rapportera eventuella skador eller defekter till tillverkaren.
- Vid onlineköp, se till att du köper från en betrodd återförsäljare.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med ett fast grepp och rikta bladet bort från dig själv.
- Undvik att använda kniven på hårda ytor som kan skada bladet.
- Använd kniven endast för dess avsedda syfte.
- Håll kniven ren och torr för att förhindra rost och andra skador.
- Förvara kniven på en säker plats när den inte används.

Instruktioner för installation och användning

- För att aktivera kniven, tryck på fingeraktiveraren för att öppna bladet.
- Kontrollera att liner lock är korrekt låst innan användning.
- Använd den dubbla tumknappen för att enkelt öppna och stänga kniven.
- För att fästa kniven i fickan, använd fickklämman. Se till att klämman är ordentligt fastsatt.
- Om du vill fästa en snodd, använd snoddhålet på handtaget.

Avfallshanteringsinstruktioner

- Kasta inte kniven i hushållsavfallet.
- Följ lokala riktlinjer för avfallshantering av vassa föremål.
- Om kniven är skadad eller oanvändbar, se till att den hanteras på ett säkert sätt för att undvika skador på andra.

Kontaktinformation för ytterligare support

För frågor eller säkerhetsinformationsförfrågningar, vänligen kontakta tillverkaren direkt via deras officiella kontaktkanaler.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din M&P MPBG30 Bodyguard Clip Point Blade Black Handle. Tack för att du är en ansvarsfull användare!