

MPBG30 Bodyguard Clip Point Blade Black Handle - MPBG30CP Bodyguard Clip Point Blade Black Handle Clam Pack

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Glass Filled Textured Nylon Handle
- Finger Actuator
- Liner Lock
- Dual Thumbstuds
- Pocket Clip and Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: MPBG30CP Bodyguard Clip Point Blade Black Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001474
- Mfr. No.: 1085891
- Color: Black
- Delivery weight: 0.1kg
- Shipping height: 20mm
- Shipping width: 80mm
- Shipping length: 70mm
- UPC: 661120413905

Table of Contents

- [Startpage](#)
- [English: M&P MPBG30 Bodyguard Clip Point Blade Safety Instructions](#)
- [Svenska: Säkerhetsanvisningar för M&P MPBG30 Bodyguard Clip Point Blade](#)

M&P MPBG30 Bodyguard Clip Point Blade Safety Instructions

Introduction

Thank you for choosing the M&P MPBG30 Bodyguard Clip Point Blade with a Black Handle. This guide provides essential safety instructions to ensure the safe use and handling of your knife. Please read this manual carefully before use to understand the product's features and safety precautions.

General Safety Guidelines

- Always keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use for any signs of damage or wear.
- Use the knife only for its intended purpose; do not use it for tasks it was not designed for.
- Always cut away from your body and keep fingers clear of the blade.
- Store the knife in a safe place when not in use, preferably in a secured location or sheath.
- Report any unsafe products or accidents to the appropriate authorities and check for recall updates.

Specific Safety Precautions for Use

- Ensure that the blade is fully deployed and locked in place before use.
- Use the finger actuator to open the blade safely.
- Be cautious when using the dual thumb studs; ensure your fingers are clear of the blade path.
- Avoid using excessive force when cutting; let the blade do the work.
- If the knife becomes stuck, do not force it; assess the situation before attempting to free it.
- Be aware of your surroundings when using the knife to avoid accidental injury to yourself or others.

Instructions for Installation and Usage

1. Opening the Knife:

- Use the finger actuator to deploy the blade.
- Ensure the blade clicks into place and is securely locked before using.

2. Using the Knife:

- Hold the knife firmly by the handle.
- Position the blade at the desired angle for cutting.
- Cut in a controlled manner, being mindful of your fingers and surroundings.

3. Closing the Knife:

- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle until it clicks into place.

4. Attaching the Pocket Clip:

- Use the provided pocket clip to attach the knife to your belt or pocket for easy access.
- Ensure the clip is securely fastened.

5. Using the Lanyard Hole:

- If desired, attach a lanyard to the lanyard hole for additional security.

Disposal Instructions

- Dispose of the knife responsibly and in accordance with local regulations.
- If the knife is damaged beyond repair, ensure the blade is safely wrapped to prevent injury during disposal.
- Do not dispose of the knife in regular household waste; consider recycling options where applicable.

Contact Information for Further Support

For any questions or concerns regarding the M&P MPBG30 Bodyguard Clip Point Blade, please refer to the product packaging or visit the manufacturer's website for additional support and resources related to safety and product information.

Thank you for your attention to these safety instructions. Enjoy using your M&P MPBG30 Bodyguard Clip Point Blade safely and responsibly!

Säkerhetsanvisningar för M&P MPBG30 Bodyguard Clip Point Blade

Introduktion

Tack för att du valt M&P MPBG30 Bodyguard Clip Point Blade. Denna produkt är designad för att vara säker och effektiv vid användning. För att säkerställa en trygg och korrekt användning av din kniv, vänligen läs igenom följande säkerhetsanvisningar noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert sätt och i enlighet med dessa riktlinjer.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage.
- Rapportera eventuella skador eller faror till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för avsett ändamål.
- Undvik att använda kniven i fuktiga eller hala miljöer för att minska risken för olyckor.
- Använd alltid kniven med ett fast grepp och undvik att använda den med en hand om det är möjligt.
- Se till att kniven är helt stängd när den inte används.
- Använd skyddshandskar om det behövs för att skydda händerna.

Instruktioner för installation och användning

1. **Öppna kniven:** Använd tumknappen för att öppna kniven försiktigt. Se till att fingrarna är borta från bladet.
2. **Stäng kniven:** För att stänga kniven, tryck på liner lock och vik bladet tillbaka in i handtaget.
3. **Användning av fickklämma:** Fäst fickklämman på bältet eller väskan för enkel åtkomst.
4. **Fingeraktiverare:** Använd fingeraktiveraren för att enkelt öppna kniven med en hand.

Avfallshantering

- Kasta inte kniven i hushållsavfall. Kontakta din lokala avfallshantering för riktlinjer om hur du korrekt ska kassera kniven.
- Om kniven är skadad eller inte längre användbar, se till att den förvaras på ett säkert sätt tills den kan kasseras.

Kontaktinformation för ytterligare support

För mer information eller frågor angående säkerheten kring M&P MPBG30 Bodyguard Clip Point Blade, vänligen kontakta din lokala återförsäljare eller besök tillverkarens officiella webbplats för mer information.

Vi tackar för att du valt vår produkt och vi hoppas att du får en säker och nöjd användning av din M&P MPBG30 Bodyguard Clip Point Blade.