

MP301 M&P Dagger Clip Point Blade Black/Grey Handle - MP301CP M&P Dagger Clip Point Blade Black/Grey Handle Clam Pack

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Aluminum & Nylon Handle
- Liner Lock
- Thumbstud
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: MP301CP M&P Dagger Clip Point Blade Black/Grey Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001482
- Mfr. No.: 1085899
- Color: Black/Silver
- Delivery weight: 0.163kg
- Shipping height: 290mm
- Shipping width: 15mm
- Shipping length: 98mm
- UPC: 661120413981

Table of Contents

- [Startpage](#)
- [English: M&P MP301 Dagger Clip Point Blade Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P MP301 Dagger Clip Point Blade](#)

M&P MP301 Dagger Clip Point Blade Safety Instructions

Introduction

Thank you for choosing the M&P MP301 Dagger Clip Point Blade with a Black/Grey Handle. This guide provides essential safety instructions and guidelines for the proper use and care of your knife. Please read this document carefully to ensure safe handling and usage.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Ensure that the knife is stored in a safe place when not in use.
- Regularly inspect the knife for any damage or wear.
- Do not use the knife for purposes other than its intended use.
- Familiarize yourself with the knife's features before use.

Specific Safety Precautions for Use

- **Blade Safety:** The 8Cr13MoV blade is sharp. Always cut away from your body and keep fingers clear of the blade.
- **Lock Mechanism:** Ensure the liner lock is fully engaged before using the knife to prevent accidental closure.
- **Thumbstud Use:** Use the thumbstud to open the knife safely. Do not force the blade open.
- **Pocket Clip:** Use the pocket clip to securely carry the knife. Ensure the clip is properly attached to avoid loss.
- **Environmental Awareness:** Be aware of your surroundings when using the knife to prevent accidents.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly by the handle.
- Use your thumb to push the thumbstud until the blade opens fully.
- Ensure the liner lock clicks into place, securing the blade.

2. Using the Knife:

- Position the knife at the desired angle for cutting.
- Apply gentle pressure while cutting, allowing the blade to do the work.
- Always cut on a stable surface.

3. Closing the Knife:

- Ensure your fingers are clear of the blade.
- Press the liner lock to release the blade.
- Gently fold the blade back into the handle until it clicks into place.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged or no longer usable, wrap it securely to prevent injury and dispose of it in accordance with local regulations.

- Do not throw the knife in regular household waste.

Contact Information for Further Support

For any safety inquiries or concerns regarding your M&P MP301 Dagger Clip Point Blade, please contact the manufacturer directly. It is important to have all relevant information available when seeking support.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your M&P MP301 Dagger Clip Point Blade. Always prioritize safety and proper handling to make the most of your knife. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för M&P MP301 Dagger Clip Point Blade

Introduktion

Tack för att du valt M&P MP301 Dagger Clip Point Blade med svart/grå handtag. Denna produkt är utformad för att vara säker och effektiv. För att säkerställa en trygg användning, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt dess avsedda syfte.
- Förvara kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage. Använd inte en skadad kniv.
- Vid onlineköp, se till att du köper från auktoriserade återförsäljare för att säkerställa att produkten uppfyller säkerhetsstandarder.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med försiktighet och var medveten om din omgivning.
- Håll knivbladet rent och skarpt för att undvika olyckor.
- Använd liner lockfunktionen korrekt för att säkerställa att bladet är säkert i öppet läge.
- Använd tummknappen för att öppna kniven på ett säkert sätt.
- Använd fickklämman för att fästa kniven på bältet eller i fickan för att förhindra att den tappas.
- Använd aldrig kniven för att skära eller öppna föremål som inte är avsedda för knivar.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd tummknappen för att öppna kniven. Se till att bladet klickar på plats.

2. Stäng kniven:

- Tryck på liner lock för att frigöra bladet och stäng det försiktigt tillbaka i handtaget.

3. Förvaring:

- Förvara kniven på en säker plats, utom räckhåll för barn.
- Använd fickklämman för att fästa kniven på bältet eller i fickan när den inte används.

Avfallsinstruktioner

- Kasta inte kniven i hushållsavfallet. Kontakta lokala myndigheter för information om korrekt avfallshantering av vassa föremål.
- Återvinn materialet i enlighet med lokala riktlinjer för avfallshantering.

Kontaktinformation för ytterligare stöd

För frågor om säkerhet eller produktinformation, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens modellnummer till hands för snabbare hjälp.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.