

MPBG52 Bodyguard Tanto Point Serrated Blade Grey/Wood Handle

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Aluminum w/Wood Insert Handle
- Finger Actuator
- Liner Lock
- Dual Thumbstuds
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: M&P MPBG52 Bodyguard Tanto Point Serrated Blade Grey/Wood Handle
- Manufacturer: M&P
- Product no.: EU1001483
- Mfr. No.: 1085900
- Delivery weight: 0.154kg
- Shipping height: 24mm
- Shipping width: 38mm
- Shipping length: 93mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: M&P MPBG52 Bodyguard Tanto Point Serrated Blade Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P MPBG52 Bodyguard Tanto Point Serrated Blade Grey/Wood Handle](#)

M&P MPBG52 Bodyguard Tanto Point Serrated Blade Safety Instruction Guide

Introduction

Thank you for choosing the M&P MPBG52 Bodyguard Tanto Point Serrated Blade. This guide provides essential safety instructions to ensure the safe and effective use of your knife. Please read this document carefully before using the product.

General Safety Guidelines

- Always use the knife for its intended purpose.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife for any damage before each use. Do not use if damaged.
- Store the knife in a safe location when not in use.
- Be aware of your surroundings while using the knife to avoid accidents.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use caution when handling the knife to prevent cuts or injuries.
- Always cut away from your body and keep fingers clear of the blade.
- Ensure the blade is fully deployed and locked before use.
- Do not attempt to modify or disassemble the knife.
- Avoid using the knife in wet or slippery conditions to maintain grip.
- If the knife is dropped, inspect it for damage before reuse.

Instructions for Installation and Usage

1. Deployment of the Blade:

- Locate the finger actuator on the handle.
- Apply pressure to the actuator to deploy the blade.
- Ensure the liner lock engages to secure the blade in an open position.

2. Using the Knife:

- Hold the knife firmly by the handle, ensuring your fingers are away from the blade.
- Use the dual thumbstuds for easy onehanded opening.
- Make controlled cuts, applying appropriate pressure based on the material being cut.

3. Pocket Clip Usage:

- Use the pocket clip to secure the knife to your pocket or belt for easy access.
- Ensure the clip is firmly attached and not loose.

4. PostUse Care:

- Clean the blade after each use to remove any debris or residue.
- Store the knife in a dry place to prevent rust and corrosion.

Disposal Instructions

- Dispose of the knife responsibly, following local regulations for hazardous materials.
- If the knife is damaged beyond repair, ensure the blade is safely contained to prevent injury during disposal.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please contact the manufacturer or your retailer. It is essential to have a point of contact for any safety concerns.

By following these guidelines, you can ensure the safe use of your M&P MPBG52 Bodyguard Tanto Point Serrated Blade. Thank you for prioritizing safety!

Säkerhetsinstruktioner för M&P MPBG52 Bodyguard Tanto Point Serrated Blade Grey/Wood Handle

Introduktion

Tack för att du valt M&P MPBG52 Bodyguard Tanto Point Serrated Blade. Denna kniv är designad för att ge hög kvalitet och funktionalitet. För att säkerställa en säker och effektiv användning, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven med försiktighet och respekt.
- Förvara kniven på en säker plats, utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven innan användning för att säkerställa att den är i gott skick och att inga skador finns.
- Rapportera eventuella skador eller defekter till tillverkaren.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven för dess avsedda syfte.
- Håll kniven borta från ansiktet och kroppen när du använder den.
- Använd kniven på en stabil yta för att förhindra olyckor.
- Undvik att använda kniven i fuktiga eller hala miljöer.
- Var försiktig med bladets skärpa; hantera alltid kniven med båda händerna när det är möjligt.
- Använd skyddshandskar om du är osäker på din förmåga att hantera kniven säkert.

Instruktioner för installation och användning

1. **Öppna kniven:** Använd fingeraktiveraren för att fälla ut bladet. Se till att fingret är borta från bladets väg.
2. **Lås fast bladet:** Kontrollera att liner lock är korrekt aktiverad innan du börjar använda kniven.
3. **Användning:** Använd kniven med ett fast grepp och skär med en jämn rörelse.
4. **Stäng kniven:** Tryck på liner lock för att frigöra bladet och fäll tillbaka det försiktigt.

Avfallshanteringsinstruktioner

- Kasta inte kniven i hushållsavfallet. Kontakta din lokala avfallshantering för riktlinjer om hur man korrekt avyttrar knivar och vassa föremål.
- Återvinn material om möjligt, enligt lokala riktlinjer för återvinning.

Kontaktinformation för vidare support

För frågor eller rapportering av osäkra produkter, vänligen kontakta tillverkaren eller din lokala myndighet. Kontrollera även EU:s Safety Gateplattform för uppdateringar om eventuella återkallelser.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.