

MPM2.0UG Drop Point Blade - MPM2.0UG3B M2.0 Drop Point Blade Black/Grey Handle

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Aluminum & Nylon Handle
- Dual Thumbstuds
- Finger Actuator
- Liner Lock
- Pocket Clip and Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: MPM2.0UG3B M2.0 Drop Point Blade Black/Grey Handle
- Manufacturer: M&P
- Product no.: EU1001491
- Mfr. No.: 1085910
- Color: Black/Silver
- Delivery weight: 0.136kg
- Shipping height: 27mm
- Shipping width: 42mm
- Shipping length: 89mm
- UPC: 661120414094

Table of Contents

- [Startpage](#)
- [English: M&P MPM2.0UG Drop Point Blade Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P MPM2.0UG Drop Point Blade](#)

M&P MPM2.0UG Drop Point Blade Safety Instructions

Introduction

Thank you for purchasing the M&P MPM2.0UG Drop Point Blade. This safety instruction guide is designed to ensure the safe use and handling of your knife. Please read this document carefully to understand the safety precautions and proper usage guidelines.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear.
- Use the knife only for its intended purpose.
- Follow all local laws and regulations regarding knife ownership and carry.
- In case of an emergency or injury, seek medical help immediately.

Specific Safety Precautions for Use

- **Blade Safety:**
 - The blade is sharp; always cut away from your body.
 - Do not attempt to catch a falling knife.
- **Handle Safety:**
 - Ensure the handle is dry and clean before use to prevent slipping.
 - Do not use the knife if the handle is damaged or loose.
- **Lock Mechanism:**
 - Always ensure the liner lock is fully engaged before using the knife.
 - Check the lock mechanism for functionality before each use.
- **Thumbstuds:**
 - Use both dual thumbstuds for safe opening.
 - Avoid forcing the blade open if it feels stuck.
- **Storage:**
 - Store the knife in a safe, dry place when not in use.
 - Use the pocket clip or lanyard hole for secure attachment when carrying.

Instructions for Installation and Usage

- **Opening the Knife:**
 1. Hold the knife firmly by the handle.
 2. Use your thumb to press the dual thumbstuds simultaneously to open the blade.
 3. Ensure the blade is fully extended and the liner lock is engaged before use.

- **Using the Knife:**

1. Always cut on a stable surface.
2. Use the knife for cutting tasks only (e.g., opening packages, slicing).
3. Avoid using the knife for prying or as a screwdriver.

- **Closing the Knife:**

1. Ensure the blade is free from any obstructions.
2. Press the liner lock to release the blade.
3. Carefully fold the blade back into the handle until it clicks into place.

Disposal Instructions

- Dispose of the knife in accordance with local regulations.
- If the knife is damaged beyond repair, wrap it securely to prevent injury and discard it in a waste container.
- Do not dispose of the knife in recycling bins.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P MPM2.0UG Drop Point Blade, please refer to the manufacturer's contact information provided with your product packaging.

Thank you for your attention to these safety instructions. Enjoy your M&P MPM2.0UG Drop Point Blade responsibly!

Säkerhetsinstruktioner för M&P MPM2.0UG Drop Point Blade

Introduktion

Tack för att du valt M&P MPM2.0UG Drop Point Blade. Denna blad är designad för att ge en säker och effektiv användning. För att säkerställa din säkerhet och korrekt användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt sätt och håll den utom räckhåll för barn.
- Kontrollera alltid knivens skick innan användning. Använd inte kniven om den är skadad.
- Förvara kniven på en säker plats när den inte används.
- Följ alltid lokala lagar och förordningar gällande knivbruk och bärande.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för dess avsedda syfte.
- Håll kniven skarp och i gott skick för att undvika olyckor.
- Använd alltid kniven med båda händerna för bättre kontroll.
- Undvik att använda kniven på instabila ytor.
- Använd skyddshandskar om du arbetar med material som kan skada kniven eller dig själv.
- Håll kniven borta från ansikte och kropp när du använder den.
- Var särskilt försiktig när du öppnar och stänger kniven, och använd liner lockfunktionen korrekt.

Instruktioner för installation och användning

- För att öppna kniven, tryck på den dubbla tumknappen med tummen för att frigöra bladet.
- När bladet är helt utsträckt, se till att liner lockfunktionen är aktiverad för att hålla bladet på plats.
- För att stänga kniven, tryck på liner lockfunktionen och tryck försiktigt ner bladet tillbaka i handtaget.
- Använd fickklämman för att fästa kniven på bältet eller i fickan för säker förvaring.

Avfallshanteringsinstruktioner

- Släng kniven på ett ansvarsfullt sätt när den inte längre är användbar.
- Om kniven är skadad eller sliten, se till att den inte kan orsaka skada för andra innan den kasseras.
- Följ lokala riktlinjer för avfallshantering och återvinning av metallprodukter.

Kontaktinformation för ytterligare stöd

För frågor, support eller rapportering av osäkra produkter, vänligen kontakta den angivna kontaktpunkten inom EU. Det är viktigt att du rapporterar eventuella olyckor eller säkerhetsproblem så att åtgärder kan vidtas för att skydda andra användare.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet!