

MPSHSA10 Shield Drop Point Blade Black/Grey Handle - MPSHSA10CP Shield Drop Point Blade Black/Grey Handle Clam Pack

- 8Cr13MoV Black Oxide Coated High Carbon S.S. Blade Aluminum w/Rubber Overmolded Handle
- Ball Bearing Pocket Clip
- Dual Thumbstuds
- Liner Lock
- Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: MPSHSA10CP Shield Drop Point Blade Black/Grey Handle Clam Pack
- Manufacturer: M&P
- Product no.: EU1001500
- Mfr. No.: 1085919
- Color: Black/Silver
- Delivery weight: 0.109kg
- Shipping height: 250mm
- Shipping width: 15mm
- Shipping length: 70mm
- UPC: 661120414230

Table of Contents

- [Startpage](#)
- [English: M&P MPSHSA10 Shield Drop Point Blade Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P MPSHSA10 Shield Drop Point Blade](#)

M&P MPSHSA10 Shield Drop Point Blade

Safety Instructions

Introduction

Thank you for choosing the M&P MPSHSA10 Shield Drop Point Blade. This guide provides essential safety instructions to ensure the safe use and handling of your knife. Please read this manual thoroughly before using the product.

General Safety Guidelines

- Always keep the blade closed when not in use to prevent accidental injuries.
- Store the knife in a safe place, out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear before each use.
- Avoid using the knife for tasks it is not designed for, such as prying or cutting hard materials.
- Ensure proper lighting and a stable work surface when using the knife.

Specific Safety Precautions for Use

- Handle the knife with care, keeping fingers and hands away from the blade edge.
- Use the dual thumbstuds to open the knife safely, ensuring your fingers are clear of the blade path.
- When using the knife, maintain a firm grip on the handle to avoid slipping.
- Do not attempt to modify the knife or its components.
- If the knife becomes dull, sharpen it properly before use; do not use excessive force on a dull blade.
- Always cut away from your body and never towards yourself.
- If the knife is dropped, inspect it for damage before using it again.

Instructions for Installation and Usage

1. Opening the Knife:

- Locate the dual thumbstuds on either side of the blade.
- Use your thumb to press down on one of the studs to open the blade smoothly.

2. Using the Knife:

- Ensure the blade is fully extended and locked in place using the liner lock mechanism.
- Hold the handle securely with one hand and use the other hand to guide the material being cut.

3. Closing the Knife:

- To close the knife, press the liner lock to release the blade.
- Carefully fold the blade back into the handle, ensuring your fingers are clear of the blade path.

4. Attaching the Pocket Clip:

- The ball bearing pocket clip allows for convenient carrying. Attach it to your belt or pocket for easy access.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged or no longer usable, wrap it securely in protective material to prevent injury during disposal.

- Check local regulations for proper disposal methods of sharp objects.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P MPSHSA10 Shield Drop Point Blade, please contact the manufacturer directly. Ensure you provide the model number and any relevant details about your inquiry.

Conclusion

By following these safety instructions, you can enjoy the full benefits of your M&P MPSHSA10 Shield Drop Point Blade while minimizing risks. Always prioritize safety and responsible usage. Thank you for your attention.

Säkerhetsinstruktioner för M&P MPSHSA10 Shield Drop Point Blade

Introduktion

Tack för att du valt M&P MPSHSA10 Shield Drop Point Blade. Denna produkt är designad för att ge hög kvalitet och säker användning. Läs noggrant igenom dessa säkerhetsinstruktioner för att säkerställa en trygg och effektiv användning av din kniv.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven i enlighet med dess avsedda syfte.
- Se till att bladet är rent och fritt från skräp innan användning.
- Undvik att använda kniven för att skära hårda material som kan skada bladet.
- Använd skyddshandskar om nödvändigt för att undvika skador.
- Stäng alltid kniven när den inte används.

Instruktioner för installation och användning

- För att öppna kniven, tryck på den dubbla tumknappen och dra bladet utåt.
- För att stänga kniven, tryck på linerlåset och tryck bladet tillbaka i handtaget.
- Använd kullager fickklämma för att fästa kniven på bältet eller i fickan.
- Kontrollera att kniven är ordentligt låst innan du använder den.

Avfallsinstruktioner

- Kassera kniven på ett ansvarsfullt sätt enligt lokala avfallsföreskrifter.
- Om kniven är skadad eller sliten, överväg att återvinna materialet om möjligt.

Kontaktinformation för vidare support

För frågor eller mer information, vänligen kontakta din återförsäljare eller besök tillverkarens webbplats. Se till att ha produktens modellnummer tillgängligt för snabbare hjälp.