

S.A. OD Liner Lock - S&W S.A. OD Green Box

- Spring assisted opening
- 8Cr13MoV steel with 3.25" blade length and weighs 4.4 oz
- Rubberized aluminum handle with black oxide blade coating
- Liner lock and thumbstud
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: S&W S.A. OD Green Box
- Manufacturer: M&P
- Product no.: EU1001501
- Mfr. No.: 1100036
- Color: Olive Drab Green
- Delivery weight: 0.136kg
- Shipping height: 22mm
- Shipping width: 37mm
- Shipping length: 82mm
- UPC: 661120075967

Table of Contents

- [Startpage](#)
- [English: M&P S.A. OD Liner Lock S&W S.A. OD Green Box Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P S.A. OD Liner Lock](#)

M&P S.A. OD Liner Lock S&W S.A. OD Green Box Safety Instruction Guide

Introduction

Thank you for choosing the M&P S.A. OD Liner Lock knife. This guide provides important safety instructions to ensure safe and effective use of your knife. Please read this manual carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to prevent injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Use the knife only for its intended purpose.
- Regularly inspect the knife for any signs of damage or wear.
- If the knife is damaged or malfunctioning, discontinue use immediately.
- Follow all local laws and regulations regarding knife ownership and carry.

Specific Safety Precautions for Use

- Ensure the blade is fully opened and locked before use.
- Avoid placing your fingers near the blade edge while opening or closing.
- Do not use excessive force when opening or closing the knife.
- Always cut away from your body and keep your other hand clear of the cutting path.
- Store the knife in a safe place when not in use, preferably in a sheath or protective case.
- Do not attempt to modify the knife in any way, as this may compromise its safety.

Instructions for Installation and Usage

- **Opening the Knife:**
 - Use the thumb stud located on the blade to assist in opening.
 - The knife features a springassisted opening mechanism for ease of use.
- **Closing the Knife:**
 - To close the knife, press the liner lock to release the blade.
 - Carefully fold the blade back into the handle, ensuring fingers are clear of the blade path.
- **Using the Pocket Clip:**
 - The pocket clip allows for convenient carry. Ensure it is securely attached to your clothing or bag.
- **Maintenance:**
 - Regularly clean the blade and handle with a dry cloth to remove dirt and moisture.
 - Apply a small amount of lubricant to the pivot point of the blade to ensure smooth operation.

Disposal Instructions

- Dispose of the knife responsibly and in accordance with local regulations.
- If the knife is no longer usable, consider recycling the materials where possible.
- Do not discard the knife in regular household waste.

Contact Information for Further Support

For any safety inquiries or assistance, please refer to the manufacturer's website or contact customer support through the provided channels.

Thank you for your attention to these safety instructions. By following these guidelines, you can ensure a safe and enjoyable experience with your M&P S.A. OD Liner Lock knife.

Säkerhetsinstruktioner för M&P S.A. OD Liner Lock

Introduktion

Tack för att du valt M&P S.A. OD Liner Lock. Denna produkt är designad för att ge säker och effektiv användning. För att säkerställa din säkerhet och förlänga produktens livslängd, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten på ett säkert sätt och håll den utom räckhåll för barn.
- Kontrollera produkten regelbundet för skador eller slitage. Använd inte produkten om den är skadad.
- Förvara produkten på en säker plats när den inte används.
- Rapportera alltid osäkra produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med försiktighet och se till att bladet är helt utfällt innan användning.
- Undvik att använda kniven för uppgifter den inte är avsedd för, såsom att skära genom hårda material.
- Använd skyddshandskar om du är osäker på din förmåga att hantera kniven säkert.
- Håll kniven borta från ansiktet och kroppen under användning.
- Använd kniven på en stabil yta för att förhindra olyckor.

Instruktioner för installation och användning

- För att öppna kniven, tryck på tumstudsens och dra försiktigt i handtaget för att fälla ut bladet.
- Kontrollera att liner locken är korrekt på plats innan du använder kniven.
- Stäng kniven genom att trycka ner liner locken och fäll bladet tillbaka i handtaget.
- Rengör kniven efter varje användning för att förhindra rost och slitage. Använd en mjuk trasa och mild tvål.
- Förvara kniven i det medföljande fodralet eller på en säker plats när den inte används.

Avfallshanteringsinstruktioner

- Avfallshantering av produkten bör ske enligt lokala föreskrifter.
- Om produkten är skadad eller inte längre behövs, se till att den inte kan användas av barn eller andra som kan skada sig.
- Återvinn materialet om möjligt, i enlighet med lokala återvinningsprogram.

Kontaktinformation för vidare support

För frågor eller mer information om säkerhetsåtgärder, vänligen kontakta din återförsäljare eller besök tillverkarens webbplats för support.