

S&W Clip Lock w/Keychain - S&W Clip Fold w/Keychain Clam Pack

- Folding Knife
- 8Cr13MoV steel with 3.25" blade length and weighs 3.7 oz
- Plastic handle with black oxide blade coating
- Liner lock, thumbstud, lanyard hole and Keychain bottle opener/screwdriver
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: S&W Clip Fold w/Keychain Clam Pack
- Manufacturer: M&P
- Product no.: EU1001508
- Mfr. No.: 1100061
- Color: Black/Blue
- Delivery weight: 0.163kg
- Shipping height: 270mm
- Shipping width: 25mm
- Shipping length: 81mm
- UPC: 661120076032

Table of Contents

- [Startpage](#)
- [English: M&P S&W Clip Lock with Keychain Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P S&W Clip Lock w/Keychain](#)

M&P S&W Clip Lock with Keychain Safety Instructions

Introduction

Thank you for purchasing the M&P S&W Clip Lock with Keychain. This folding knife is designed for everyday use and offers a variety of features including a liner lock, thumbstud, lanyard hole, and a keychain bottle opener/screwdriver. Please read this safety instruction guide carefully to ensure safe and proper use of the product.

General Safety Guidelines

- Ensure that the knife is stored in a secure location away from children and pets.
- Always inspect the knife before use to ensure that it is in good working condition.
- Use the knife only for its intended purpose. Do not use it for tasks that could cause damage to the blade or injury to yourself.
- Keep the knife clean and dry to prevent rust and maintain its effectiveness.
- If you notice any damage or malfunction, discontinue use and seek assistance.

Specific Safety Precautions for Use

- Always cut away from your body while using the knife to minimize the risk of injury.
- Do not attempt to catch a falling knife. Let it fall to the ground to avoid potential injury.
- Use the thumbstud to open the knife safely, ensuring your fingers are clear of the blade's path.
- When using the bottle opener/screwdriver, ensure that you have a firm grip and are applying the tool on a stable surface.
- Avoid using the knife while distracted or under the influence of substances that may impair your judgment.

Instructions for Installation and Usage

1. Opening the Knife:

- Locate the thumbstud on the blade.
- With a firm grip on the handle, push the thumbstud to open the blade.
- Ensure the liner lock engages securely before use.

2. Using the Knife:

- Hold the knife firmly by the handle.
- Position the blade at the desired angle for cutting.
- Perform cutting motions away from your body and keep fingers clear of the blade.

3. Using the Keychain Bottle Opener/Screwdriver:

- To use the bottle opener, position the opener under the bottle cap and apply upward pressure.
- For screwdriving, align the screwdriver tip with the screw head and turn clockwise to tighten or counterclockwise to loosen.

4. Closing the Knife:

- To close the knife, press the liner lock downwards and gently fold the blade back into the handle.
- Ensure the blade is fully secured within the handle before storing.

Disposal Instructions

- Dispose of the knife responsibly and in accordance with local regulations.
- If the knife is damaged beyond repair, ensure it is wrapped securely to prevent injury during disposal.
- Do not dispose of the knife in regular household waste. Check for local recycling programs or hazardous waste disposal options.

Contact Information for Further Support

For further inquiries or safety concerns, please refer to the manufacturer's website or contact your local retailer for assistance.

By following these safety instructions, you can enjoy the M&P S&W Clip Lock with Keychain safely and effectively. Thank you for your attention to safety.

Säkerhetsinstruktioner för M&P S&W Clip Lock w/Keychain

Introduktion

Tack för att du har valt M&P S&W Clip Lock med nyckelring. Denna produkt är designad för att vara säker och lättanvänd. För att säkerställa en säker användning av produkten, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd produkten endast för avsett ändamål.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage.
- Vid eventuella skador, sluta använda produkten och kontakta tillverkaren.
- Rapportera osäkra produkter och olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid produkten med försiktighet och uppmärksamhet.
- Se till att bladet är helt utfällt innan du använder det.
- Undvik att rikta bladet mot dig själv eller andra.
- Använd inte produkten för att öppna föremål som kan orsaka skador.
- Förvara produkten på en säker plats när den inte används.
- Använd inte produkten om den är skadad eller defekt.

Instruktioner för installation och användning

1. **Öppna förpackningen:** Ta försiktigt bort produkten från förpackningen.
2. **Kontrollera produkten:** Inspektera fällkniven för eventuella skador.
3. **Fäll ut bladet:** Använd tumstudsens för att fälla ut bladet helt.
4. **Användning:** Använd fällkniven för avsett ändamål, och följ de specifika säkerhetsåtgärderna ovan.
5. **Stäng bladet:** När du är klar, stäng bladet genom att trycka på liner lock och fäll tillbaka bladet i handtaget.
6. **Förvaring:** Förvara produkten på en säker plats, helst i en skyddande förpackning.

Avfallsinstruktioner

- Avlägsna produkten på ett miljövänligt sätt när den är uttjänt.
- Följ lokala riktlinjer för avfallshantering för metall och plast.
- Undvik att slänga produkten i hushållsavfall.

Kontaktinformation för vidare support

För frågor eller säkerhetsinquiry, vänligen kontakta tillverkaren direkt. Se förpackningen eller produktens webbplats för mer information.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en säker och effektiv användning av M&P S&W Clip Lock med nyckelring. Tack för att du prioriterar säkerheten!