

Clip Fold w/G10 Ti Box - S&W Clip Fold w/G10 Ti Box

- Folding Knife
- 8Cr13MoV steel with 3.25" blade length and weighs 4.7 oz
- G10 and steel handle with ti-nitride blade coating
- Finger flipper, liner lock, thumbstud and lanyard hole
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: S&W Clip Fold w/G10 Ti Box
- Manufacturer: M&P
- Product no.: EU1001509
- Mfr. No.: 1100062
- Color: Black/Silver
- Delivery weight: 0.141kg
- Shipping height: 20mm
- Shipping width: 40mm
- Shipping length: 85mm
- UPC: 661120076049

Table of Contents

- [Startpage](#)
- [English: M&P Clip Fold w/G10 Ti Box Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P Clip Fold w/G10 Ti Box](#)

M&P Clip Fold w/G10 Ti Box Safety Instruction Guide

Introduction

Thank you for choosing the M&P Clip Fold w/G10 Ti Box. This folding knife is designed for various cutting tasks while ensuring user safety and comfort. It is essential to follow the safety guidelines outlined in this document to maximize your experience and minimize risks.

General Safety Guidelines

- Always handle the knife with care and keep it out of reach of children.
- Use the knife only for its intended purpose. Do not use it for prying or as a lever.
- Inspect the knife before each use for any signs of damage or wear.
- Always cut away from your body and keep your fingers clear of the cutting path.
- Store the knife in a safe place when not in use, preferably in a secure sheath or container.
- Do not attempt to modify or disassemble the knife.
- In case of any accidents or injuries, seek medical attention immediately.

Specific Safety Precautions for Use

- Ensure the knife is locked in place when in use. The liner lock mechanism should be fully engaged.
- Use the finger flipper and thumb stud to open the knife safely; do not force it open.
- Be cautious of the blade edge when folding the knife back into the handle.
- Avoid using the knife in wet or slippery conditions to prevent accidents.
- If the knife becomes dull, sharpen it carefully or seek professional sharpening services.

Instructions for Installation and Usage

1. Opening the Knife:

- Grip the handle firmly.
- Use the finger flipper or thumb stud to open the blade.
- Ensure the blade is fully extended and locked in place before use.

2. Using the Knife:

- Hold the handle securely with one hand.
- With the other hand, guide the material you are cutting.
- Always cut away from your body and keep your fingers clear of the blade.

3. Folding the Knife:

- After use, ensure the blade is free of any debris.
- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle until it clicks into place.

4. Using the Pocket Clip:

- Attach the pocket clip to your belt or pocket for easy access.
- Ensure the clip is secured to avoid accidental drops.

Disposal Instructions

- When the knife reaches the end of its life cycle or is no longer needed, dispose of it responsibly.
- Follow local regulations for disposing of sharp objects to prevent injury to waste handlers.
- Consider recycling options if available, especially for the steel and G10 materials.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P Clip Fold w/G10 Ti Box, please refer to the appropriate contact point provided by the manufacturer. Always ensure you have access to updated safety information and recall notices.

Thank you for your attention to these safety guidelines. Your safety is our priority, and following these instructions will help ensure a safe and enjoyable experience with your M&P Clip Fold w/G10 Ti Box.

Säkerhetsinstruktioner för M&P Clip Fold w/G10 Ti Box

Introduktion

Tack för att du har valt M&P Clip Fold w/G10 Ti Box. Denna fällkniv är designad för att vara både funktionell och säker. För att säkerställa en trygg användning, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera kniven regelbundet för tecken på skador eller slitage.
- Använd kniven endast för dess avsedda syfte.
- Förvara kniven på en säker plats när den inte används.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven i en säker miljö, borta från människor och djur.
- Håll fingrarna borta från bladet när du fäller ut det.
- Använd fingerflippern för att fälla ut bladet på ett kontrollerat sätt.
- Stäng kniven ordentligt efter användning för att förhindra oavsiktlig öppning.
- Använd skyddshandskar om du hanterar kniven under svåra förhållanden.

Instruktioner för installation och användning

- För att fälla ut bladet, använd fingerflippern på kniven.
- Kontrollera att liner locken är korrekt låst innan du använder kniven.
- Om kniven är utrustad med en tumknapp, använd den för att öppna bladet om det är nödvändigt.
- Använd fickklämman för att fästa kniven på bältet eller i fickan för säker förvaring.
- Rengör kniven regelbundet för att upprätthålla dess prestanda och livslängd.

Avfallsinstruktioner

- Kasta inte kniven i vanlig hushållssopor.
- Om kniven är skadad eller oanvändbar, kontakta en lokal återvinningsstation för korrekt avfallshantering.
- Se till att kniven är ordentligt stängd innan du slänger den för att undvika skador.

Kontaktinformation för ytterligare support

För frågor eller mer information om säkerhetsåtgärder, vänligen kontakta den lokala distributören eller tillverkaren. Kontrollera alltid EU:s säkerhetsportal för uppdateringar om återkallelser och säkerhetsinformation.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet!