

Clip Fold w/G10 Ti Box - S&W Clip Fold w/G10 Ti Clam Pack

- Folding Knife
- 8Cr13MoV steel with 3.25" blade length and weighs 4.7 oz
- G10 and steel handle with ti-nitride blade coating
- Finger flipper, liner lock, thumbstud and lanyard hole
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: S&W Clip Fold w/G10 Ti Clam Pack
- Manufacturer: M&P
- Product no.: EU1001510
- Mfr. No.: 1100063
- Color: Black/Silver
- Delivery weight: 0.168kg
- Shipping height: 270mm
- Shipping width: 25mm
- Shipping length: 85mm
- UPC: 661120076056

Table of Contents

- [Startpage](#)
- [English: M&P Clip Fold w/G10 Ti Box Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P Clip Fold w/G10 Ti Box S&W Clip Fold w/G10 Ti Clam Pack](#)

M&P Clip Fold w/G10 Ti Box Safety Instructions

Introduction

Thank you for choosing the M&P Clip Fold w/G10 Ti Box. This folding knife is designed for safe and effective use. Please read this safety instruction guide carefully to ensure proper handling and maintenance of your knife.

General Safety Guidelines

- Always handle the knife with care and keep it out of reach of children.
- Inspect the knife before each use to ensure it is in good condition.
- Use the knife only for its intended purpose.
- Do not use the knife if it appears damaged or defective.
- Store the knife in a safe place when not in use.
- Follow local laws and regulations regarding the possession and use of knives.

Specific Safety Precautions for Use

- **Cutting Surface:** Always use a stable and appropriate cutting surface to prevent accidents.
- **Grip:** Maintain a firm grip on the handle while using the knife to avoid slipping.
- **Blade Direction:** Always cut away from your body and keep your fingers clear of the cutting path.
- **Closing the Knife:** Ensure your fingers are clear of the blade when closing the knife.
- **Finger Flipper and Lock:** Use the finger flipper and liner lock properly to avoid accidental blade deployment.

Instructions for Installation and Usage

1. Opening the Knife:

- Use the finger flipper to open the knife.
- Ensure the blade locks securely in place before use.

2. Using the Knife:

- Hold the handle firmly with one hand.
- Use your other hand to guide the material being cut, keeping it away from the blade.
- Apply even pressure while cutting to maintain control.

3. Closing the Knife:

- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle, ensuring your fingers are clear of the blade path.

4. Pocket Clip Adjustment:

- If necessary, adjust the pocket clip to suit your carrying preference. Ensure it is securely fastened.

Disposal Instructions

- Dispose of the knife in accordance with local regulations.
- If the knife is damaged beyond repair, consider recycling the materials where possible.
- Ensure the blade is safely covered or wrapped before disposal to prevent injury.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the M&P Clip Fold w/G10 Ti Box, please contact your local distributor or the manufacturer directly.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your M&P Clip Fold w/G10 Ti Box. Always prioritize safety and proper usage to make the most of your product. Thank you for your attention to safety!

Säkerhetsinstruktioner för M&P Clip Fold w/G10 Ti Box S&W Clip Fold w/G10 Ti Clam Pack

Introduktion

Tack för att du har valt M&P Clip Fold w/G10 Ti Box S&W Clip Fold w/G10 Ti Clam Pack. Denna fällkniv är designad för att ge dig en säker och effektiv användning. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant innan du använder produkten för att säkerställa en trygg och korrekt användning.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner.
- Håll produkten utom räckhåll för barn och sårbara personer.
- Inspektera produkten regelbundet för skador eller slitage.
- Rapportera eventuella skador eller defekter till försäljaren.
- Följ lokala lagar och förordningar angående bärande och användning av knivar.

Specifika säkerhetsåtgärder vid användning

- Använd alltid kniven på en stabil yta för att undvika olyckor.
- Håll knivbladet borta från kroppen och andra personer under användning.
- Stäng alltid kniven efter användning för att förhindra oavsiktlig skada.
- Använd fingerflippern för att öppna kniven med ett fast grepp.
- Se till att liner locken är i låst läge innan du använder kniven.
- Använd tumstudsens för att enkelt öppna kniven med en hand.
- Använd fickklämmen för att fästa kniven på en säker plats när den inte används.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd fingerflippern eller tumstudsens för att öppna kniven.
- Kontrollera att liner locken är i låst läge.

2. Användning av kniven:

- Håll kniven med ett fast grepp i handtaget.
- Använd kniven för avsedda syften, såsom skärning av material.

3. Stänga kniven:

- Tryck på liner locken för att frigöra bladet.
- Vik bladet försiktigt tillbaka in i handtaget tills det låses på plats.

4. Fickklämma:

- Fäst fickklämmen på bältet eller i fickan för säker förvaring när kniven inte används.

Avfallshantering

- Kasta inte produkten i hushållsavfall. Följ lokala riktlinjer för avfallshantering.

- Om produkten är skadad eller inte längre behövs, se till att den hanteras på ett säkert sätt för att undvika skador.

Kontaktinformation för ytterligare support

För frågor eller säkerhetsinquiries, vänligen kontakta tillverkaren eller återförsäljaren där du köpte produkten. Se till att ha produktens modellnummer och inköpsinformation till hands.

Rapportera osäkra produkter

- Om du upptäcker en osäker produkt eller en olycka, rapportera det omedelbart till de lokala myndigheterna.
- Kontrollera regelbundet EU:s Safety Gateplattform för uppdateringar om återkallelser och säkerhetsinformation.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din M&P Clip Fold w/G10 Ti Box S&W Clip Fold w/G10 Ti Clam Pack. Tack för att du prioriterar säkerheten!