

Search & Rescue w/Sharp - M&P S&W Search & Rescue w/Sharp Box

- Fixed Blade
- 8Cr13MoV steel with 6" blade length and weighs 5.9 oz
- Textured rubber handle with black oxide blade coating
- Partial serration with blood groove, tungsten window punch and sharpener
- Sheath

NO IMAGE
AVAILABLE

Attributes

- Name: M&P S&W Search & Rescue w/Sharp Box
- Manufacturer: M&P
- Product no.: EU1001515
- Mfr. No.: 1100070
- Color: Black
- Delivery weight: 0.522kg
- Shipping height: 41mm
- Shipping width: 95mm
- Shipping length: 150mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: M&P Search & Rescue w/Sharp Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P Search & Rescue w/Sharp](#)

M&P Search & Rescue w/Sharp Safety Instructions

Introduction

Thank you for choosing the M&P Search & Rescue w/Sharp. This fixed blade knife is designed for safety and efficiency in various rescue situations. Please read this safety instruction guide carefully to ensure proper usage and to minimize risks associated with the product.

General Safety Guidelines

- Always use the knife in a safe and controlled manner.
- Keep the knife out of reach of children and unauthorized users.
- Inspect the knife before each use to ensure it is in good condition.
- Do not use the knife for purposes other than intended.
- Store the knife in its sheath when not in use to prevent accidents.
- Be aware of your surroundings to avoid accidental injury to yourself or others.

Specific Safety Precautions for Use

- Handle the knife with care, ensuring a firm grip on the textured rubber handle.
- Be cautious of the sharp blade and partial serration; always cut away from your body.
- Use the tungsten window punch and sharpener only as intended.
- If the knife becomes damaged or shows signs of wear, discontinue use immediately.
- Do not attempt to modify the knife in any way.

Instructions for Installation and Usage

1. Unpacking the Knife

- Carefully remove the knife from its packaging.
- Inspect the knife for any visible damage or defects.

2. Using the Knife

- Hold the knife firmly by the handle, ensuring your fingers are clear of the blade.
- Use the knife for cutting tasks only. Avoid using it as a pry tool or for striking.
- If using the tungsten window punch, ensure the target surface is safe and appropriate.

3. Sheath Usage

- Always return the knife to its sheath after use.
- Ensure the knife is securely fastened in the sheath to prevent accidental exposure.

4. Maintenance

- Clean the blade with a soft cloth after each use to prevent rust and corrosion.
- Sharpen the blade as necessary using the provided sharpener.

Disposal Instructions

- Dispose of the knife responsibly. If it is no longer usable, wrap it securely in a protective material to prevent injury.

- Follow local regulations for disposal of knives and sharp objects.

Contact Information for Further Support

For any questions or concerns regarding the safety and usage of this product, please refer to the manufacturer's contact details available on the packaging or product documentation.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with your M&P Search & Rescue w/Sharp knife. Always prioritize safety and stay informed about proper usage to maximize the benefits of this tool.

Säkerhetsinstruktioner för M&P Search & Rescue w/Sharp

Introduktion

Tack för att du valt M&P Search & Rescue w/Sharp. Denna kniv är designad för att ge säker och effektiv användning. För att säkerställa din säkerhet och optimal prestanda, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med instruktionerna.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till myndigheterna.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med båda händerna för bättre kontroll.
- Var försiktig när du hanterar den delvis tandade eggen för att undvika skador.
- Använd skyddshandskar om du arbetar med hårda material.
- Undvik att använda kniven för ändamål som den inte är avsedd för, såsom att öppna burkar eller som verktyg.
- Förvara alltid kniven i det medföljande fodralet när den inte används.

Instruktioner för installation och användning

1. **Öppna kniven:** Håll handtaget stadigt och tryck på låsmekanismen för att öppna bladet.
2. **Användning:** Använd kniven för skärande uppgifter som är lämpliga för en kniv av denna typ.
3. **Stäng kniven:** Tryck på låsmekanismen och vik bladet tillbaka till handtaget.
4. **Rengöring:** Torka av bladet med en ren, torr trasa efter användning för att förhindra rost.
5. **Underhåll:** Smörj knivens gångjärn med ett lämpligt smörjmedel för att säkerställa smidig funktion.

Avfallshantering

- Kasta inte kniven i hushållsavfall. Kontakta lokala myndigheter för korrekt avfallshantering.
- Återvinn materialet om möjligt, i enlighet med lokala återvinningsriktlinjer.

Kontaktinformation för vidare stöd

För frågor angående säkerhet eller produkter, vänligen kontakta den angivna EUbaserade kontaktpunkten för säkerhetsförfrågningar.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår högsta prioritet.