

M2.0 U.G. TI Rub Alum - M&P M&P M2.0 U.G. Grey Rub Alum Clam Pack

- Folding Knife
- 8Cr13MoV steel with 2.75" blade length and weighs 3 oz
- Rubberized aluminum handle with black oxide blade coating
- Finger flipper, liner lock, thumbstud and lanyard hole
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: M&P M&P M2.0 U.G. Grey Rub Alum Clam Pack
- Manufacturer: M&P
- Product no.: EU1001524
- Mfr. No.: 1100041
- Color: Black/Silver
- Delivery weight: 0.113kg
- Shipping height: 260mm
- Shipping width: 15mm
- Shipping length: 70mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: M&P M2.0 U.G. TI Rub Alum Folding Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P M2.0 U.G. TI Rub Alum](#)

M&P M2.0 U.G. TI Rub Alum Folding Knife

Safety Instructions

Introduction

Thank you for choosing the M&P M2.0 U.G. TI Rub Alum Folding Knife. This guide provides important safety instructions and guidelines to ensure safe and effective use of your product. Please read this manual carefully before using the knife.

General Safety Guidelines

- Always handle the knife with care to avoid injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in good working condition.
- Do not use the knife for purposes other than its intended use.
- If the knife becomes damaged or malfunctions, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- When opening or closing the knife, ensure your fingers are clear of the blade.
- Use the finger flipper and thumbstud to safely deploy the blade.
- Always cut away from your body and keep your other hand out of the cutting path.
- Do not force the blade open if it does not move freely; this may indicate a blockage or damage.
- Avoid using the knife in wet or slippery conditions to maintain a secure grip.
- Store the knife in a secure location when not in use to prevent accidental injury.

Instructions for Installation and Usage

1. Opening the Knife:

- Use the finger flipper or thumbstud to open the blade.
- Ensure that the blade locks into place before use.

2. Using the Knife:

- Hold the handle firmly with one hand.
- Use the other hand to guide the material being cut.
- Always maintain control of the knife while cutting.

3. Closing the Knife:

- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle, ensuring your fingers are clear of the blade path.

Disposal Instructions

- Dispose of the knife responsibly. Do not throw it in regular trash.
- If the knife is damaged beyond repair, consider recycling the metal parts where possible.
- Always ensure that the blade is securely closed before disposal to prevent injury.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P M2.0 U.G. TI Rub Alum Folding Knife, please refer to the contact information included with your product packaging or visit the manufacturer's website for assistance.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your M&P M2.0 U.G. TI Rub Alum Folding Knife. Remember to always prioritize safety and report any unsafe conditions or incidents to the appropriate authorities. Thank you for your attention to these important guidelines.

Säkerhetsinstruktioner för M&P M2.0 U.G. TI Rub Alum

Introduktion

Tack för att du har valt M&P M2.0 U.G. TI Rub Alum. Denna fällkniv är designad för att ge användarna en säker och effektiv upplevelse. Det är viktigt att följa dessa säkerhetsinstruktioner noggrant för att säkerställa säker användning och för att undvika potentiella risker.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt instruktionerna för att undvika skador.
- Kontrollera kniven regelbundet för tecken på slitage eller skador.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Rapportera alla osäkra produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder vid användning

- Använd alltid kniven på en säker och stabil yta.
- Håll fingrarna borta från bladet när du öppnar eller stänger kniven.
- Använd kniven endast för avsedd användning; undvik att använda den för andra ändamål.
- Var försiktig när du använder fingerflippern och liner lockfunktionen för att undvika oavsiktlig skada.
- Använd alltid fickklämman för att fästa kniven på ett säkert sätt när den inte används.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd fingerflippern för att öppna bladet. Se till att fingrarna är borta från bladets väg.

2. Stäng kniven:

- Tryck på liner lock för att frigöra bladet och stäng det försiktigt. Håll fingrarna borta från bladets kant.

3. Användning av fickklämman:

- Fäst fickklämman på bältet eller i fickan för att förhindra att kniven tappas bort.

4. Underhåll:

- Rengör kniven regelbundet med en mjuk trasa.
- Smörj gångjärnet med lämpligt smörjmedel för att säkerställa smidig öppning och stängning.

Avfallshanteringsinstruktioner

- Kasta inte kniven i vanliga hushållssopor. Kontakta lokala myndigheter för korrekt avfallshantering.
- Återvinn materialet där det är möjligt. För aluminium och stål, följ lokala riktlinjer för återvinning.

Kontaktinformation för vidare support

För frågor eller säkerhetsinquiries, vänligen kontakta den angivna EUbaserade kontaktpunkten för produkten.

Det är viktigt att ha den informationen tillgänglig för att säkerställa en trygg användning av produkten.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet!