

U.G. Blk/Blk Rub Alum Box

- Folding Knife
- 8Cr13MoV steel with 3" blade length and weighs 3 oz
- Rubberized aluminum handle with black oxide blade coating
- Finger flipper and liner lock
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: M&P U.G. Blk/Blk Rub Alum Box
- Manufacturer: M&P
- Product no.: EU1001527
- Mfr. No.: 1100074
- Color: Black
- Delivery weight: 0.091kg
- Shipping height: 20mm
- Shipping width: 35mm
- Shipping length: 73mm
- UPC: 661120076223

Table of Contents

- [Startpage](#)
- [English: M&P U.G. Blk/Blk Rub Alum Folding Knife Safety Instructions](#)
- [Svenska: Säkerhetsanvisningar för M&P U.G. Blk/Blk Rub Alum Fällkniv](#)

M&P U.G. Blk/Blk Rub Alum Folding Knife

Safety Instructions

Introduction

Thank you for choosing the M&P U.G. Blk/Blk Rub Alum Folding Knife. This guide provides important safety information and instructions to ensure safe and effective use of your knife. Please read this manual carefully before using the product.

General Safety Guidelines

- Always handle the knife with care and respect.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in good working condition.
- Do not use the knife for any purpose other than intended.
- Store the knife in a secure location when not in use.

Specific Safety Precautions for Use

- Always use the knife with both hands for better control.
- Ensure the blade is fully opened and locked before use.
- Avoid placing your fingers near the blade edge while using the knife.
- Do not attempt to disassemble the knife.
- If the knife becomes damaged or malfunctions, cease use immediately and contact the manufacturer for support.

Instructions for Installation and Usage

1. Opening the Knife:

- Use the finger flipper to open the blade.
- Ensure that the blade locks into place securely.

2. Using the Knife:

- Hold the knife firmly by the handle.
- Cut away from your body and keep your other hand clear of the cutting path.
- If cutting through tough materials, apply steady pressure without forcing the blade.

3. Closing the Knife:

- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle.
- Ensure the blade is fully enclosed before storing.

Disposal Instructions

- Dispose of the knife responsibly and in accordance with local regulations.
- If the knife is damaged beyond repair, ensure it is securely wrapped to prevent injury during disposal.

Contact Information for Further Support

For any safety inquiries, concerns, or to report an unsafe product, please reach out to the appropriate EUbased contact point for assistance.

Thank you for taking the time to read this safety instruction guide. Your safety is our priority.

Säkerhetsanvisningar för M&P U.G. Blk/Blk Rub Alum Fällkniv

Introduktion

Tack för att du valt M&P U.G. Blk/Blk Rub Alum Fällkniv. Denna handbok innehåller viktiga säkerhetsanvisningar och riktlinjer för användning av produkten. Vänligen läs noggrant igenom dessa instruktioner för att säkerställa en säker och effektiv användning av din fällkniv.

Allmänna säkerhetsriktlinjer

- Använd alltid fällkniven på ett ansvarsfullt sätt och håll den utom räckhåll för barn.
- Kontrollera kniven regelbundet för skador eller slitage. Använd inte kniven om den är skadad.
- Följ alltid lokala lagar och förordningar angående användning av knivar.
- Förvara kniven på en säker plats när den inte används för att förhindra olyckor.
- Rapportera eventuella farliga produkter eller olyckor till myndigheterna.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för dess avsedda syfte. Undvik att använda den som ett verktyg för att bryta eller slå något.
- Håll alltid fingrarna borta från bladet när du öppnar eller stänger kniven.
- Använd ett fast grepp och var medveten om din omgivning när du använder kniven.
- Använd kniven på en stabil yta för att minimera risken för olyckor.
- Om kniven har en liner lock, se till att låset är ordentligt på plats innan du använder kniven.

Instruktioner för installation och användning

- För att öppna kniven, tryck på fingertippare och vrid handtaget försiktigt.
- Kontrollera att bladet är helt utsträckt och att liner locken är aktiverad innan användning.
- För att stänga kniven, tryck på liner locken och vik bladet tillbaka in i handtaget.
- Förvara kniven i det medföljande fodralet eller på en säker plats när den inte används.
- Rengör kniven efter användning för att förhindra rost och förlänga livslängden.

Avfallshantering

- Kasta inte kniven i vanliga sopor. Kontrollera lokala riktlinjer för avfallshantering av vassa föremål.
- Om kniven är skadad och inte längre kan användas, se till att den avyttras på ett säkert sätt för att undvika olyckor.

Kontaktinformation för vidare support

För frågor eller ytterligare information, vänligen kontakta tillverkaren eller återförsäljaren där du köpte produkten. Se till att ha produktens modellnummer och inköpsinformation tillgänglig.

Vi tackar för att du valt M&P U.G. Blk/Blk Rub Alum Fällkniv och hoppas att du får stor nytta av den!