

2-Tone Clip Folder Tanto Box

- Folding Knife
- 8Cr13MoV steel with 3.5" blade length and weighs 3.6 oz
- Rubber overmold handle with black oxide blade coating
- Finger flipper, liner lock, thumbstud and lanyard hole
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: M&P 2-Tone Clip Folder Tanto Box
- Manufacturer: M&P
- Product no.: EU1001535
- Mfr. No.: 1100080
- Color: Silver
- Delivery weight: 0.109kg
- Shipping height: 22mm
- Shipping width: 35mm
- Shipping length: 87mm
- UPC: 661120076308

Table of Contents

- [Startpage](#)
- [English: M&P 2Tone Clip Folder Tanto Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P 2Tone Clip Folder Tanto](#)

M&P 2Tone Clip Folder Tanto Safety Instruction Guide

Introduction

Thank you for choosing the M&P 2Tone Clip Folder Tanto. This folding knife is designed for safe and effective use. Please read this safety instruction guide carefully to ensure proper handling and maintenance, in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always handle the knife with care to avoid accidental injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Use the knife only for its intended purpose; do not use it as a tool for prying or other inappropriate applications.
- Inspect the knife before use to ensure it is in good condition. Do not use if damaged.
- Store the knife in a safe place when not in use, preferably in a sheath or protective case.
- Dispose of the knife responsibly when it is no longer usable.

Specific Safety Precautions for Use

- Ensure your hands are dry and free from oils or substances that may affect grip.
- Use the finger flipper and thumb stud safely to open the blade; avoid using excessive force.
- Be aware of your surroundings when using the knife to prevent accidental injuries to yourself or others.
- Always cut away from your body and keep your fingers clear of the blade's path.
- Avoid distractions while using the knife to maintain focus and control.
- If the knife becomes stuck or difficult to operate, do not force it; assess the situation calmly.

Instructions for Installation and Usage

• Opening the Knife:

- Use the finger flipper or thumb stud to open the blade.
- Ensure the blade is fully extended and locks into place before use.

• Using the Knife:

- Hold the knife firmly by the handle, ensuring a secure grip.
- Use the knife on a stable surface to prevent slipping.
- Employ gentle pressure when cutting to maintain control.

• Closing the Knife:

- To close the knife, press the liner lock to unlock the blade.
- Carefully fold the blade back into the handle, ensuring fingers are clear of the blade's path.

• Maintenance:

- Regularly clean the blade with a soft cloth to remove dirt and moisture.
- Occasionally apply a light oil to the pivot area to maintain smooth operation.
- Store the knife in a dry place to prevent rust and deterioration.

Disposal Instructions

- When the knife is no longer usable, dispose of it in accordance with local regulations.
- Consider recycling the metal components where possible.
- Ensure that the blade is covered or wrapped to prevent injury during disposal.

Contact Information for Further Support

For any inquiries regarding the safety of this product, please contact the manufacturer or your local distributor. It is important to report any unsafe products or incidents to the relevant authorities. Check for recall updates on the EU's Safety Gate platform to stay informed about product safety.

Remember, your safety is our priority. Thank you for following these guidelines and using the M&P 2Tone Clip Folder Tanto responsibly.

Säkerhetsinstruktioner för M&P 2Tone Clip Folder Tanto

Introduktion

Tack för att du har valt M&P 2Tone Clip Folder Tanto. Denna fällkniv är designad för att ge användaren en säker och effektiv upplevelse. För att säkerställa korrekt och säker användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage.
- Använd inte kniven för syften den inte är avsedd för.
- Vid onlineköp, se till att du köper från betrodda återförsäljare som uppfyller EU:s säkerhetskrav.

Specifika säkerhetsåtgärder vid användning

- Använd alltid kniven med båda händerna för bättre kontroll.
- Håll bladet borta från kroppen och andra personer när du öppnar eller stänger kniven.
- Använd fingerflippern för att öppna kniven på ett säkert sätt.
- Stäng kniven helt när den inte används.
- Använd tumstudsens för att stänga kniven, och se till att fingrarna är borta från bladets väg.
- Om kniven faller, kontrollera den noggrant innan du använder den igen.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd fingerflippern för att öppna bladet.
- Se till att kniven är stabilt placerad i handen.

2. Stäng kniven:

- Tryck på liner lock för att frigöra bladet.
- Fäll försiktigt tillbaka bladet i handtaget.
- Kontrollera att bladet är helt stängt innan du förvarar kniven.

3. Fickklämma:

- Använd fickklämman för att fästa kniven i fickan eller bältet.
- Se till att klämman är ordentligt fastsatt för att förhindra att kniven faller ut.

Avfallshanteringsinstruktioner

- Kasta inte kniven i hushållsavfallet om den är skadad eller trasig.
- Kontakta en lokal avfallshanteringsanläggning för att få information om korrekt avfallshantering av knivar.
- Återvinn materialet där det är möjligt, i enlighet med lokala föreskrifter.

Kontaktinformation för ytterligare stöd

För frågor eller säkerhetsinquiry, vänligen kontakta tillverkaren eller din återförsäljare. Se till att ha produktens serienummer till hands för snabbare hjälp.

Genom att följa dessa säkerhetsinstruktioner kan du njuta av din M&P 2Tone Clip Folder Tanto på ett säkert sätt. Tack för att du bidrar till en säker användning av produkter!