

2-Tone Clip Folder Tanto Clam Pack

- Folding Knife
- 8Cr13MoV steel with 3.5" blade length and weighs 3.6 oz
- Rubber overmold handle with black oxide blade coating
- Finger flipper, liner lock, thumbstud and lanyard hole
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: M&P 2-Tone Clip Folder Tanto Clam Pack
- Manufacturer: M&P
- Product no.: EU1001536
- Mfr. No.: 1100081
- Color: Silver
- Delivery weight: 0.127kg
- Shipping height: 280mm
- Shipping width: 20mm
- Shipping length: 87mm
- UPC: 661120076315

Table of Contents

- [Startpage](#)
- [English: M&P 2Tone Clip Folder Tanto Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P 2Tone Clip Folder Tanto](#)

M&P 2Tone Clip Folder Tanto Safety Instruction Guide

Introduction

Thank you for choosing the M&P 2Tone Clip Folder Tanto. This folding knife is designed for safe and effective use. Please read this safety instruction guide carefully to ensure safe handling and operation.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear.
- Do not use the knife for purposes other than intended.
- If the knife shows signs of damage, discontinue use immediately.
- Ensure that the knife is stored in a safe location when not in use.
- Be aware of your surroundings when using the knife to prevent accidents.

Specific Safety Precautions for Use

- Always use the finger flipper or thumb stud to open the knife.
- Ensure the liner lock is fully engaged before using the blade.
- Avoid placing your fingers near the blade when opening or closing the knife.
- Do not attempt to modify the knife in any way.
- Always cut away from your body to minimize the risk of injury.
- Use the knife in a welllit area to ensure visibility.
- If using the knife outdoors, be cautious of uneven surfaces and potential hazards.

Instructions for Installation and Usage

• Opening the Knife:

- Use the finger flipper or thumb stud to open the blade.
- Ensure the blade is fully extended before use.

• Using the Knife:

- Hold the handle firmly, ensuring your grip is secure.
- Cut with controlled motions, applying only the necessary force.
- After use, carefully close the blade by pushing the liner lock and folding the blade back into the handle.

• Attaching the Pocket Clip:

- If desired, attach the pocket clip to the designated slot on the handle for easy carrying.
- Ensure the clip is securely fastened to prevent accidental loss.

Disposal Instructions

- Dispose of the knife in accordance with local regulations.
- If the knife is damaged beyond repair, wrap it securely in a material that prevents injury and dispose of it in a designated waste facility.
- Do not throw the knife in regular household waste.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P 2Tone Clip Folder Tanto, please refer to the EU-based contact point provided with your purchase.

Conclusion

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your M&P 2Tone Clip Folder Tanto. Always prioritize safety and responsible usage. Thank you for your attention to these important instructions.

Säkerhetsinstruktioner för M&P 2Tone Clip Folder Tanto

Introduktion

Tack för att du valt M&P 2Tone Clip Folder Tanto. Denna fällkniv är designad för att ge både funktionalitet och säkerhet. Följ dessa säkerhetsinstruktioner noggrant för att säkerställa en trygg användning av produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven borta från barn och andra som inte är utbildade i säker användning.
- Kontrollera kniven regelbundet för skador eller slitage. Använd inte en skadad kniv.
- Förvara kniven på en säker plats när den inte används, helst i ett skyddande fodral.
- Rapportera alla skador eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för avsedd användning.
- Håll fingrarna borta från bladet när du öppnar och stänger kniven.
- Använd ett fast grepp på handtaget för att förhindra att kniven glider ur handen.
- Var medveten om omgivningen när du använder kniven för att undvika skador på dig själv eller andra.
- Använd kniven på en stabil yta för att undvika olyckor.

Instruktioner för installation och användning

- För att öppna kniven, använd fingerflippern eller tumstudsens. Se till att bladet är helt utfällt innan du börjar använda det.
- För att stänga kniven, tryck ned liner lock och vik bladet försiktigt tillbaka in i handtaget.
- Kontrollera att kniven är ordentligt stängd innan du förvarar den.
- Använd fickklämman för att fästa kniven på bältet eller i fickan för säker transport.

Avfallsinstruktioner

- Kasta inte kniven i hushållsavfall. Kontakta lokala myndigheter för korrekt avfallshantering av knivar.
- Om kniven är skadad och inte längre säker att använda, se till att den förvaras på ett säkert sätt tills den kan kasseras korrekt.

Kontaktinformation för vidare support

För frågor eller säkerhetsrelaterade ärenden, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att du har produktens information tillgänglig för snabbare hjälp.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din M&P 2Tone Clip Folder Tanto. Tack för att du prioriterar säkerheten!