

Tactical Pen Black w/Glass Breaker Clam Pack

- 6" overall length and weighs 1.9 oz
- 6061 aircraft aluminum
- Uses Schmidt P900M Parker Style Black Ball Point Pen Refill
- Patent pending, spring loaded window punch and twist cap
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: M&P Tactical Pen Black w/Glass Breaker Clam Pack
- Manufacturer: M&P
- Product no.: EU1001542
- Mfr. No.: 1100099
- Color: Black
- UPC: 661120076377

Table of Contents

- [Startpage](#)
- [English: M&P Tactical Pen Black w/Glass Breaker Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P Tactical Pen Black w/Glass Breaker](#)

M&P Tactical Pen Black w/Glass Breaker

Safety Instruction Guide

Introduction

Thank you for purchasing the M&P Tactical Pen Black w/Glass Breaker. This guide provides essential safety instructions to ensure the safe use and handling of your tactical pen. Please read this document carefully to understand the safety guidelines, proper usage, and disposal methods.

General Safety Guidelines

- Always use the tactical pen according to the manufacturer's specifications.
- Keep the pen out of reach of children and vulnerable individuals to prevent accidents.
- Do not use the pen for any unintended purposes, such as selfdefense or as a weapon.
- Regularly inspect the pen for any signs of damage or wear. If damaged, discontinue use immediately.
- Report any unsafe conditions or incidents related to the product to the appropriate authorities.

Specific Safety Precautions for Use

- **Glass Breaker:**
 - Use the glass breaker feature only in emergencies or when necessary.
 - Ensure the area around the glass is clear of individuals before using the glass breaker.
- **Writing Use:**
 - The pen is designed for writing and should be used as such.
 - Avoid applying excessive pressure while writing to prevent damage to the pen tip.
- **Pocket Clip:**
 - Ensure the pocket clip is securely attached before carrying the pen.
 - Do not overload the pocket clip with additional items to prevent bending or breaking.

Instructions for Installation and Usage

1. Using the Tactical Pen:

- To write, twist the cap to expose the pen tip.
- Ensure the Schmidt P900M Parker Style Black Ball Point Pen Refill is properly installed.
- When finished writing, twist the cap back to cover the pen tip.

2. Using the Glass Breaker:

- Identify the glass surface you wish to break.
- Hold the pen firmly and position the glass breaker point against the glass.
- Apply a quick, firm pressure to break the glass. Avoid excessive force.

3. Carrying the Tactical Pen:

- Use the pocket clip to secure the pen to your pocket or bag for easy access.
- Ensure the pen is stored in a safe location when not in use.

Disposal Instructions

- Dispose of the tactical pen responsibly according to local regulations.
- If the pen is damaged or no longer functional, consider recycling the aluminum components where facilities are available.
- Do not dispose of the pen in regular household waste if it contains any hazardous materials.

Contact Information for Further Support

For any questions regarding safety or product inquiries, please contact the manufacturer or the designated EU contact point. Ensure to keep your purchase receipt and any relevant documentation for reference.

Thank you for following these safety instructions. Your safety and satisfaction are our top priorities.

Säkerhetsinstruktioner för M&P Tactical Pen Black w/Glass Breaker

Introduktion

Tack för att du valt M&P Tactical Pen Black w/Glass Breaker. Denna penna är designad för både skrivande och som ett verktyg för nödsituationer. För att säkerställa en säker och effektiv användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt instruktionerna för att undvika skador.
- Håll produkten utom räckhåll för barn och känsliga grupper.
- Kontrollera produkten regelbundet för tecken på slitage eller skador.
- Vid användning av produkten, se till att den inte riktas mot människor eller djur.
- Rapportera alla osäkra produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- **Användning av glaskrossare:**
 - Använd glaskrossaren endast i nödsituationer.
 - Se till att det glas som ska krossas är avsett för detta ändamål.
 - Undvik att använda glaskrossaren på ytor som kan orsaka skador eller splittra.
- **Skrivspets:**
 - Tryck inte för hårt när du skriver för att undvika att spetsen bryts.
 - Byt ut bläckpatronen (Schmidt P900M) enligt tillverkarens anvisningar.
- **Fickklämma:**
 - Använd fickklämman för att fästa pennan på kläder eller väskor.
 - Kontrollera att klämman är säker innan användning.

Instruktioner för installation och användning

- **Installation av bläckpatron:**
 1. Skruva av pennans övre del.
 2. Ta bort den använda bläckpatronen.
 3. Sätt i en ny Schmidt P900M bläckpatron.
 4. Skruva tillbaka den övre delen av pennan.
- **Användning av glaskrossare:**
 1. Håll pennan i ett fast grepp.
 2. Rikta glaskrossaren mot det glas som ska krossas.
 3. Slå försiktigt men bestämt för att krossa glaset.
- **Skrivning:**
 1. Ta bort pennans hättan.
 2. Tryck ner spetsen för att börja skriva.
 3. Sätt tillbaka hättan när du är klar för att skydda spetsen.

Avfallsinstruktioner

- Kassera produkten i enlighet med lokala avfallsbestämmelser.
- Ta bort bläckpatroner och kassera dem separat enligt lokala riktlinjer för kemiskt avfall.
- Återvinn material som kan återvinnas, som aluminium.

Kontaktinformation för vidare support

För frågor eller mer information, vänligen kontakta tillverkaren eller återförsäljaren där produkten köptes. Kontrollera även EU:s Safety Gateplattform för eventuella återkallelser eller säkerhetsuppdateringar.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att använda M&P Tactical Pen Black w/Glass Breaker på rätt sätt kan du säkerställa en säker och effektiv upplevelse.