

Drop Point Blade Carbon Fiber Handle - Drop Point Blade Carbon Fiber Handle Clam Pack

- 9Cr18MoV Titanium Coated High Carbon S.S. Blade Ti-Nitride Steel Handle
- Carbon Fiber Slab on One Side
- Finger Flipper
- Frame Lock
- Pocket Clip with Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: Drop Point Blade Carbon Fiber Handle Clam Pack
- Manufacturer: Shrade
- Product no.: EU1001548
- Mfr. No.: 1084282
- Delivery weight: 0.082kg
- Shipping height: 229mm
- Shipping width: 18mm
- Shipping length: 70mm
- UPC: 661120413431

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Shrade Drop Point Blade with Carbon Fiber Handle](#)
- [Svenska: Säkerhetsinstruktioner för Shrade Drop Point Blade](#)

Safety Instruction Guide for Shrade Drop Point Blade with Carbon Fiber Handle

Introduction

Thank you for choosing the Shrade Drop Point Blade with Carbon Fiber Handle. This guide provides important safety instructions and guidelines to ensure the safe use of your knife. Please read this document carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the blade sharp and clean for optimal performance.
- Store the knife in a safe place, out of reach of children and pets.
- Do not use the knife for purposes other than its intended use.
- Be aware of your surroundings when using the knife to prevent accidents.
- Always cut away from your body and keep fingers clear of the blade.
- If the knife becomes damaged or shows signs of wear, discontinue use immediately.

Specific Safety Precautions for Use

- **Age Restrictions:** This knife is not intended for use by individuals under the age of 18. Ensure that it is used only by responsible adults.
- **Cutting Surface:** Always use a stable and appropriate cutting surface when using the knife.
- **Flipping Mechanism:** Use the finger flipper with caution. Ensure your fingers are clear of the blade path when deploying the blade.
- **Frame Lock:** Always verify that the frame lock is engaged before using the knife to prevent accidental closure.
- **Pocket Clip:** When using the pocket clip, ensure that it is securely attached to your clothing or bag to prevent loss.

Instructions for Installation and Usage

1. **Unboxing:** Carefully remove the knife from the clam pack. Dispose of packaging materials responsibly.
2. **Opening the Knife:**
 - Use the finger flipper to deploy the blade. Ensure that your fingers are clear from the blade's path.
3. **Using the Knife:**
 - Hold the knife firmly by the handle.
 - Cut away from your body and keep your other hand clear of the cutting path.
4. **Closing the Knife:**
 - To close the knife, ensure your fingers are clear of the blade.
 - Press the frame lock to release the blade and gently fold it back into the handle.
5. **Storing the Knife:** After use, store the knife in a safe location, preferably in its original packaging or a designated knife case.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged beyond use, consider recycling the metal components where possible.
- Always ensure that the blade is safely retracted or covered before disposal to prevent injury.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product recalls, please refer to the contact information provided on the packaging or visit the manufacturer's website.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your Shrade Drop Point Blade. Always prioritize safety and responsible use. Thank you for choosing our product.

Säkerhetsinstruktioner för Shrade Drop Point Blade

Introduktion

Tack för att du valt Shrade Drop Point Blade med kolfiberhandtag. Denna produkt är designad för att ge en säker och effektiv användning. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant för att säkerställa en trygg användning av produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven enligt tillverkarens instruktioner.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera kniven regelbundet för tecken på slitage eller skador.
- Använd kniven endast för avsett ändamål.
- Rapportera omedelbart eventuella skador eller defekter till återförsäljaren.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven i ett väl upplyst område.
- Håll kniven borta från ansiktet och kroppen när du använder den.
- Använd skyddshandskar om du är osäker på knivens säkerhet.
- Förvara kniven i ett säkert läge när den inte används.
- Stäng alltid kniven när den inte är i bruk.

Instruktioner för installation och användning

1. **Öppna kniven:** Använd fingerflippare för att öppna kniven. Se till att fingrarna är borta från bladet.
2. **Användning:** Använd kniven för skärande uppgifter som är lämpliga för en drop point blade. Undvik att använda kniven för att skära genom hårda material som metall eller glas.
3. **Stäng kniven:** För att stänga kniven, tryck på ramlåset och vik bladet tillbaka i handtaget. Se till att fingrarna är borta från bladet under denna process.
4. **Förvaring:** Förvara kniven i en säker och torr plats, helst i det medföljande clampacket.

Avfallsinstruktioner

- Kasta inte kniven i hushållsavfall. Kontakta lokala myndigheter för korrekt avfallshantering.
- Om kniven är skadad och inte längre kan användas, se till att den inte kan orsaka skada för andra innan den kasseras.

Kontaktinformation för vidare support

För frågor eller säkerhetsärenden, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens modellnummer och inköpsinformation tillgänglig för snabb hjälp.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet!