

SCH702 Cage Clip Point Blade Cage Handle

- 9Cr18MoV Titanium Coated High Carbon S.S. Blade Ti-Nitride Steel Machined w/G10 Inlay Handle
- Thumb Hole
- Finger Flipper
- Frame Lock
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade SCH702 Cage Clip Point Blade Cage Handle
- Manufacturer: Shrade
- Product no.: EU1001549
- Mfr. No.: 1084283
- Color: Grey
- Delivery weight: 0.086kg
- Shipping height: 22mm
- Shipping width: 32mm
- Shipping length: 68mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Shrade SCH702 Cage Clip Point Blade Cage Handle Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH702 Cage Clip Point Blade Cage Handle](#)

Shrade SCH702 Cage Clip Point Blade Cage Handle Safety Instructions

Introduction

Thank you for choosing the Shrade SCH702 Cage Clip Point Blade Cage Handle. This product is designed for safe and effective use, providing you with a reliable tool for various applications. Please read this safety instruction guide carefully to ensure safe handling, usage, and disposal of the product.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear.
- Do not use the knife for purposes other than its intended use.
- Always ensure the blade is securely locked in place before use.
- If the knife is damaged or malfunctions, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- **Cutting Surface:** Always use a stable cutting surface to prevent slips and accidents.
- **Cutting Direction:** Cut away from your body and keep fingers clear of the blade's path.
- **Blade Care:** Keep the blade clean and dry to prevent rust and ensure optimal performance.
- **Storage:** Store the knife in a safe place, preferably in a sheath or protective case, to prevent accidental cuts.
- **DistractionFree Environment:** Avoid using the knife when distracted or under the influence of drugs or alcohol.

Instructions for Installation and Usage

1. **Unboxing:** Carefully remove the knife from its packaging. Dispose of packaging materials responsibly.
2. **Blade Inspection:** Examine the blade for any defects or damage before first use.
3. **Opening the Knife:**
 - Use the thumb hole or finger flipper to open the blade.
 - Ensure the blade is fully extended and locked in place before using.
4. **Using the Knife:**
 - Hold the knife firmly by the handle.
 - Use the knife for cutting tasks only, avoiding excessive force.
5. **Closing the Knife:**
 - To close, press the frame lock and carefully fold the blade back into the handle.
 - Ensure the blade is securely locked before storing.
6. **Regular Maintenance:**
 - Clean the blade after each use with a damp cloth.
 - Lubricate the pivot point periodically to maintain smooth operation.

Disposal Instructions

- Dispose of the knife responsibly, following local regulations for sharp objects.
- If the knife is no longer usable, consider recycling the metal components where facilities are available.
- Ensure the blade is safely covered or wrapped to prevent injury during disposal.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Shrade SCH702 Cage Clip Point Blade Cage Handle, please refer to the manufacturer's website or customer service.

Conclusion

By following these safety instructions, you can ensure safe and effective use of your Shrade SCH702 Cage Clip Point Blade Cage Handle. Thank you for prioritizing safety and responsible usage.

Säkerhetsinstruktioner för Shrade SCH702 Cage Clip Point Blade Cage Handle

Introduktion

Tack för att du valt Shrade SCH702 Cage Clip Point Blade Cage Handle. Denna handbok innehåller viktiga säkerhetsanvisningar och riktlinjer för korrekt användning av produkten. Vänligen läs igenom hela dokumentet noggrant innan du använder produkten för att säkerställa en säker och effektiv användning.

Allmänna säkerhetsriktlinjer

- Produkten är avsedd för säker användning. Följ alltid instruktionerna för att undvika olyckor och skador.
- Kontrollera produkten regelbundet för skador. Använd inte produkten om den är skadad.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid produkten enligt avsedd funktion.
- Undvik att använda produkten i fuktiga eller instabila miljöer.
- Använd skyddshandskar om det är nödvändigt för att skydda händerna under användning.
- Håll fingrarna borta från bladet när du öppnar eller stänger produkten.
- Använd produkten med försiktighet om du är ovan vid knivar eller skärverktyg.

Instruktioner för installation och användning

- För att öppna kniven, använd tummhålet eller fingerflippern. Se till att fingrarna är borta från bladet.
- För att stänga kniven, tryck på ramlåsen för att frigöra bladet och stäng det försiktigt.
- För att fästa kniven i en ficka eller bälte, använd fickklämman. Kontrollera att klämman är ordentligt på plats innan du bär kniven.
- För att rengöra kniven, torka av bladet med en ren, torr trasa. Undvik att använda starka kemikalier.

Avfallsanvisningar

- Kasta inte produkten i hushållsavfall. Följ lokala riktlinjer för avfallshantering och återvinning.
- Om produkten är skadad eller inte längre användbar, se till att den hanteras på ett säkert sätt för att undvika skador på andra.

Kontaktinformation för vidare support

För frågor eller mer information om produkten, vänligen kontakta tillverkaren eller återförsäljaren där produkten köptes. Se till att ha produktens modellnummer och inköpsinformation tillgänglig vid kontakt.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.