

Clip Point Blade Grey/Black Handle

- 9Cr18MoV Bead Blast Satin High Carbon S.S. Blade Anodized Aluminum w/Rubber Inlay Handle
- Dual Thumbstuds
- Liner Lock
- Pocket Clip
- Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: Clip Point Blade Grey/Black Handle
- Manufacturer: Shrade
- Product no.: EU1001553
- Mfr. No.: 1084289
- Color: Black/Silver
- Delivery weight: 0.132kg
- Shipping height: 20mm
- Shipping width: 38mm
- Shipping length: 79mm
- UPC: 661120413509

Table of Contents

- [Startpage](#)
- [English: Shrade Clip Point Blade Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Shrade Clip Point Blade](#)

Shrade Clip Point Blade Safety Instruction Guide

Introduction

Thank you for choosing the Shrade Clip Point Blade with a Grey/Black Handle. This safety instruction guide is designed to help you use the knife safely and effectively while complying with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and pets.
- Use the knife only for its intended purpose.
- Regularly inspect the knife for any damage or wear before use.
- If the knife becomes damaged, discontinue use immediately and seek professional repair or disposal.
- Report any unsafe conditions or accidents related to the knife to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform to stay informed about product safety.

Specific Safety Precautions for Use

- Always use the knife with both hands, ensuring a firm grip on the handle.
- When opening or closing the knife, keep your fingers clear of the blade path to prevent cuts.
- Do not attempt to modify the knife in any way, as this may compromise its safety features.
- Store the knife in a safe place, preferably in a sheath or protective case, when not in use.
- Be aware of your surroundings when using the knife to avoid accidental injury to yourself or others.
- Avoid using the knife in wet or slippery conditions to maintain a secure grip.

Instructions for Installation and Usage

1. Opening the Knife:

- Locate the dual thumbstuds on both sides of the blade.
- Use your thumb to press down on one of the thumbstuds and gently pull the blade out until it locks into place.

2. Using the Knife:

- Hold the knife firmly by the anodized aluminum handle with rubber inlay.
- Use the blade for cutting tasks only and avoid using it for prying or twisting.
- Maintain control of the knife at all times during use.

3. Closing the Knife:

- To close the knife, press down on the liner lock located on the handle.
- While pressing the liner lock, carefully push the blade back into the handle until it is fully closed.

4. Cleaning and Maintenance:

- Clean the blade and handle after each use with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive materials that may damage the knife.
- Lubricate the pivot area occasionally to ensure smooth operation.

Disposal Instructions

- When the knife reaches the end of its useful life, dispose of it responsibly.
- Check local regulations for proper disposal methods, as knives may be considered hazardous waste.
- If possible, recycle the materials according to local recycling guidelines.

Contact Information for Further Support

For any questions or concerns regarding the Shrade Clip Point Blade, please refer to the manufacturer's website or contact the authorized retailer where the knife was purchased. It is important to have an EUbased contact for safety inquiries.

Thank you for your attention to these safety guidelines. Enjoy using your Shrade Clip Point Blade responsibly!

Säkerhetsinstruktioner för Shrade Clip Point Blade

Introduktion

Tack för att du valt Shrade Clip Point Blade. Denna guide innehåller viktig information om säker användning, installation och avfallshantering av din kniv. Vänligen läs noggrant igenom alla instruktioner och säkerhetsåtgärder innan du använder produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage. Använd inte en skadad kniv.
- Följ alltid lokala lagar och förordningar gällande bärande och användning av knivar.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med båda händerna för att säkerställa bättre kontroll.
- Håll knivbladet borta från kroppen och andra personer under användning.
- Använd kniven endast för avsett ändamål; undvik att använda den för att skära genom hårda material som metall eller sten.
- Stäng alltid kniven när den inte används och förvara den på en säker plats.
- Använd kniven med försiktighet när du skär i närheten av andra människor.

Instruktioner för installation och användning

- För att öppna kniven, använd den dubbla tumknappen för att fälla ut bladet.
- Kontrollera att liner lock är korrekt på plats för att säkerställa att bladet inte kan fällas tillbaka under användning.
- Använd fickklämman för att fästa kniven i din ficka eller bälte för säker förvaring.
- Om kniven har ett snoddhål, använd en snodd eller rem för extra säkerhet vid förvaring.
- Rengör kniven efter varje användning för att förhindra rost och slitage. Använd en mjuk trasa och mild tvål vid behov.

Avfallsinstruktioner

- När kniven inte längre är i bruk, se till att den är ordentligt stängd och förvarad på en säker plats.
- Om kniven är skadad eller inte längre säker att använda, kassera den på ett ansvarsfullt sätt. Kontakta lokala avfallsmyndigheter för instruktioner om korrekt avfallshantering.
- Återvinn om möjligt delar av produkten enligt lokala återvinningsregler.

Kontaktinformation för ytterligare support

För frågor, säkerhetsinquiry eller rapportering av osäkra produkter, vänligen kontakta din lokala återförsäljare eller tillverkare. Se till att alltid ha produktens serienummer och inköpsinformation tillgänglig för snabbare hjälp.

Vi tackar för att du valt Shrade Clip Point Blade och önskar dig en säker och trevlig användning!