

Clip Point Blade Grey/Black Handle Clam Pack

- 9Cr18MoV Bead Blast Satin High Carbon S.S. Blade Anodized Aluminum w/Rubber Inlay Handle
- Dual Thumbstuds
- Liner Lock
- Pocket Clip
- Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade Clip Point Blade Grey/Black Handle Clam Pack
- Manufacturer: Shrade
- Product no.: EU1001554
- Mfr. No.: 1084290
- Color: Black/Silver
- Delivery weight: 0.145kg
- Shipping height: 250mm
- Shipping width: 18mm
- Shipping length: 79mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Shrade Clip Point Blade Grey/Black Handle](#)
- [Svenska: Säkerhetsinstruktioner för Shrade Clip Point Blade](#)

Safety Instruction Guide for Shrade Clip Point Blade Grey/Black Handle

Introduction

Thank you for purchasing the Shrade Clip Point Blade with a Grey/Black Handle. This guide provides essential safety instructions to ensure the safe use and maintenance of your knife. Please read through the entire guide carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Use the knife only for its intended purpose.
- Regularly inspect the knife for any signs of damage or wear.
- If the knife is damaged, do not use it and seek appropriate repairs or replacements.
- Always store the knife in a safe and secure place when not in use.
- Be aware of your surroundings while using the knife to prevent accidents.

Specific Safety Precautions for Use

- **Cutting Surface:** Always use a stable and appropriate cutting surface to prevent slipping.
- **Grip:** Ensure your grip on the handle is firm and secure while using the knife.
- **Blade Direction:** Cut away from your body and keep your fingers clear of the blade's path.
- **Dual Thumbstuds:** Use the dual thumbstuds for safe and easy blade deployment.
- **Liner Lock:** Ensure the liner lock is fully engaged before using the knife to prevent accidental closure.
- **Pocket Clip:** Use the pocket clip to secure the knife in your pocket when not in use, preventing accidental drops or injuries.
- **Lanyard Hole:** If using a lanyard, ensure it is securely attached to prevent dropping the knife.

Instructions for Installation and Usage

1. Opening the Knife:

- Use the dual thumbstuds on both sides of the blade to open the knife.
- Ensure your fingers are clear of the blade's path during deployment.

2. Using the Knife:

- Hold the knife firmly by the handle.
- Position the blade at the desired angle for cutting.
- Cut in a controlled manner, taking care not to apply excessive force.

3. Closing the Knife:

- When finished, carefully close the knife by pressing the liner lock to release the blade.
- Fold the blade back into the handle while keeping fingers away from the blade's path.

4. Cleaning and Maintenance:

- Clean the blade and handle after each use with a damp cloth.
- Dry the knife thoroughly to prevent rusting.
- Regularly lubricate the pivot point to ensure smooth operation.

Disposal Instructions

- When disposing of the knife, ensure that it is no longer usable to prevent accidental injury to others.
- Consider recycling the materials if possible, following local regulations for disposal of metal products.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Shrade Clip Point Blade, please reach out to the designated EU contact point for assistance.

Conclusion

By following these safety instructions, you can ensure the safe use and maintenance of your Shrade Clip Point Blade. Always prioritize safety and report any unsafe conditions or incidents to the appropriate authorities. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för Shrade Clip Point Blade

Introduktion

Tack för att du valt Shrade Clip Point Blade med grå/svart handtag. Denna produkt är designad för att ge en säker och effektiv användarupplevelse. För att säkerställa din säkerhet och korrekt användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt instruktionerna för att undvika skador.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för eventuella skador eller slitage innan användning.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven på en säker och stabil yta.
- Undvik att använda kniven för uppgifter den inte är avsedd för, såsom att öppna burkar eller som skruvmejsel.
- Håll knivbladet rent och skarpt för att säkerställa effektiv användning.
- Använd alltid ett skydd när kniven inte är i bruk.
- Använd kniven med försiktighet för att undvika skador på dig själv eller andra.

Instruktioner för installation och användning

- För att öppna kniven, tryck på tumsstudsens med tummen och dra handtaget bort från bladet.
- Se till att liner locken är korrekt låst innan du använder kniven.
- Använd fickklämmen för att fästa kniven på bältet eller i fickan för enkel åtkomst.
- För att stänga kniven, tryck på liner locken och stäng bladet försiktigt.
- Förvara kniven på en torr plats när den inte används.

Avfallsinstruktioner

- Släng inte kniven i hushållsavfallet.
- Följ lokala riktlinjer för avfallshantering för metallprodukter.
- Om produkten är skadad eller inte längre i bruk, se till att den hanteras på ett säkert sätt för att undvika skador.

Kontaktinformation för ytterligare stöd

För frågor eller säkerhetsinformationsförfrågningar, vänligen kontakta en auktoriserad återförsäljare eller besök den officiella webbplatsen för mer information.

Vi tackar för att du valt Shrade Clip Point Blade och hoppas att du får en säker och tillfredsställande användning av produkten!