

SCH706 Drop Point Blade Carbon Fiber Handle

- 9Cr18MoV Titanium Coated High Carbon S.S. Blade Ti-Nitride Steel w/Carbon Fiber Inlay Handle
- Thumbstud
- Liner Lock
- Pocket Clip
- Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade SCH706 Drop Point Blade Carbon Fiber Handle
- Manufacturer: Shrade
- Product no.: EU1001555
- Mfr. No.: 1084291
- Delivery weight: 0.086kg
- Shipping height: 22mm
- Shipping width: 32mm
- Shipping length: 69mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Shrade SCH706 Drop Point Blade Carbon Fiber Handle](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH706 Drop Point Blade Carbon Fiber Handle](#)

Safety Instruction Guide for Shrade SCH706 Drop Point Blade Carbon Fiber Handle

Introduction

Thank you for choosing the Shrade SCH706 Drop Point Blade with a Carbon Fiber Handle. This guide provides essential safety instructions to ensure the safe use of your knife. Please read this manual carefully before using the product.

General Safety Guidelines

- Always keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in good condition.
- Use the knife only for its intended purpose.
- Store the knife in a safe place when not in use.
- Be aware of your surroundings when using the knife to avoid accidents.
- Do not use the knife if it is damaged or malfunctioning.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- **Cutting Surface:** Always use a stable and appropriate cutting surface to prevent slips and accidents.
- **Grip:** Ensure a firm grip on the handle while using the knife.
- **Cutting Direction:** Cut away from your body and keep your hands clear of the blade path.
- **Thumbstud:** Use the thumbstud to open the blade safely; do not force it.
- **Liner Lock:** Ensure the liner lock is fully engaged before using the knife to prevent accidental closure.
- **Pocket Clip:** Use the pocket clip to secure the knife when carrying it; do not carry it loose in your pocket.
- **Lanyard Hole:** Use the lanyard hole for additional safety when carrying the knife.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly by the handle.
- Use your thumb to press the thumbstud and open the blade until it locks into place.
- Ensure the liner lock is engaged.

2. Using the Knife:

- Place the knife on a stable surface.
- Hold the handle firmly and use the blade for cutting as intended.
- Always cut away from your body and keep your hands away from the blade.

3. Closing the Knife:

- Press the liner lock to release the blade.
- Carefully fold the blade back into the handle until it is securely closed.

4. Cleaning and Maintenance:

- Clean the blade with a soft cloth after each use to prevent rust.
- Store the knife in a dry place to maintain the integrity of the materials.

Disposal Instructions

- Dispose of the knife responsibly. If it is damaged or no longer usable, please ensure it is discarded in a manner that prevents injury to others.
- Follow local regulations regarding the disposal of knives and sharp objects.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Shrade SCH706 Drop Point Blade, please refer to the official Shrade website or contact your local retailer for assistance.

Thank you for your attention to these safety instructions. Enjoy your Shrade SCH706 Drop Point Blade responsibly!

Säkerhetsinstruktioner för Shrade SCH706 Drop Point Blade Carbon Fiber Handle

Introduktion

Tack för att du valt Shrade SCH706 Drop Point Blade med kolfiberhandtag. Denna guide innehåller viktiga säkerhetsinstruktioner och riktlinjer för att säkerställa en säker användning av produkten. Vänligen läs igenom alla avsnitt noggrant innan du använder kniven.

Allmänna säkerhetsriktlinjer

- Se till att produkten är i gott skick innan användning. Kontrollera att bladet är fritt från skador eller defekter.
- Använd endast kniven för avsett ändamål.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Följ alltid lokala lagar och förordningar angående knivanvändning.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd alltid ett fast grepp om handtaget när du hanterar kniven.
- Undvik att använda kniven i våta eller hala miljöer för att minska risken för olyckor.
- Använd inte kniven för att skära genom hårda material som metall eller sten.
- Var försiktig när du öppnar och stänger kniven; se till att fingrarna är utanför bladets väg.
- Förvara kniven på en säker plats när den inte används, helst i ett skyddande fodral.

Instruktioner för installation och användning

- För att öppna kniven, tryck på tummknappen med tummen och lyft bladet med den andra handen.
- Kontrollera att liner locken klickar på plats för att säkerställa att bladet är säkert.
- För att stänga kniven, tryck på liner locken och sänk försiktigt ner bladet.
- Använd fickklämman för att fästa kniven på bältet eller i fickan för säker transport.
- Om kniven har ett snoddhål, kan du använda en snodd för att öka säkerheten vid transport.

Avfallsinstruktioner

- Avfallshantering av produkten ska ske i enlighet med lokala föreskrifter.
- Om kniven är skadad eller inte längre användbar, se till att den kasseras på ett säkert sätt för att undvika olyckor.
- Återvinn materialet i enlighet med lokala återvinningsprogram om möjligt.

Kontaktinformation för vidare support

För frågor eller säkerhetsinquiry, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Kontrollera alltid den officiella webbplatsen för uppdateringar och säkerhetsinformation.

Tack för att du valde Shrade. Vi önskar dig en säker och tillfredsställande upplevelse med din nya kniv.