

SCH707 Tanto Point Blade Rubberized Handle - SCH707CP Tanto Point Blade Rubberized Handle Clam Pack

- 9Cr18MoV Bead Blast Satin High Carbon S.S. Blade ABS & Kraton w/Anodized Aluminum Insert Handle
- Dual Thumbstuds
- Liner Lock
- Pocket Clip
- Lanyard Hole

NO IMAGE
AVAILABLE

Attributes

- Name: SCH707CP Tanto Point Blade Rubberized Handle Clam Pack
- Manufacturer: Shrade
- Product no.: EU1001558
- Mfr. No.: 1084294
- Color: Green/Black
- Delivery weight: 0.104kg
- Shipping height: 250mm
- Shipping width: 18mm
- Shipping length: 78mm
- UPC: 661120413554

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Shrade SCH707 Tanto Point Blade Rubberized Handle](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH707 Tanto Point Blade](#)

Safety Instruction Guide for Shrade SCH707 Tanto Point Blade Rubberized Handle

Introduction

Thank you for choosing the Shrade SCH707 Tanto Point Blade Rubberized Handle. This guide provides important safety information to ensure the safe use of your knife. Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that the knife is kept out of reach of children and vulnerable individuals.
- Always inspect the knife for any signs of damage before use. Do not use if damaged.
- Use the knife only for its intended purpose. Misuse can lead to injury.
- Store the knife in a safe place when not in use, preferably in a sheath or protective case.
- Be aware of your surroundings when using the knife to avoid accidents.

Specific Safety Precautions for Use

- Always cut away from your body and keep your fingers clear of the cutting path.
- Use a stable surface when cutting to prevent slipping.
- Avoid using excessive force when cutting; let the knife do the work.
- Do not attempt to catch a falling knife.
- Wear appropriate personal protective equipment, such as cutresistant gloves, if necessary.

Instructions for Installation and Usage

1. **Unboxing:** Carefully remove the knife from the clam pack. Dispose of packaging materials responsibly.
2. **Handling:**
 - Grasp the rubberized handle firmly.
 - Ensure that your fingers are not in the path of the blade when opening or closing.
3. **Opening the Knife:**
 - Use the dual thumbstuds to open the knife.
 - Ensure the blade is locked in place before using.
4. **Using the Knife:**
 - Hold the knife securely by the handle.
 - Make smooth, controlled cuts.
5. **Closing the Knife:**
 - Press the liner lock to release the blade.
 - Close the blade carefully, ensuring fingers are clear of the cutting edge.
6. **Cleaning and Maintenance:**
 - Clean the blade after each use with a damp cloth.
 - Dry thoroughly to prevent rust.
 - Regularly check the knife for sharpness and damage.

Disposal Instructions

- Dispose of the knife responsibly in accordance with local regulations.
- If the knife is damaged beyond repair, consider recycling the metal parts where facilities exist.
- Do not throw the knife in regular household waste.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Shrade SCH707 Tanto Point Blade Rubberized Handle, please refer to the EU contact point or relevant local authority for assistance.

By following these guidelines, you can help ensure a safe and enjoyable experience with your Shrade SCH707 Tanto Point Blade Rubberized Handle. Thank you for your attention to safety!

Säkerhetsinstruktioner för Shrade SCH707 Tanto Point Blade

Introduktion

Tack för att du valt Shrade SCH707 Tanto Point Blade. Denna kniv är designad för att ge säker och effektiv användning. För att säkerställa din säkerhet och för att maximera livslängden på produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och sårbara personer.
- Kontrollera alltid kniven för skador innan användning.
- Följ tillverkarens instruktioner för användning och underhåll.
- Rapportera eventuella skador eller säkerhetsproblem till myndigheterna.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för avsett syfte.
- Håll kniven skarp och i gott skick för att förhindra olyckor.
- Använd alltid kniven med en stabil och säker hand.
- Undvik att använda kniven i trånga utrymmen där du kan skada dig själv eller andra.
- Använd skyddshandskar om nödvändigt för att skydda händerna.
- Var försiktig vid stängning av kniven för att undvika klämning av fingrarna.

Instruktioner för installation och användning

1. **Öppna kniven:** Använd tumstudsens för att enkelt öppna kniven. Se till att kniven är i ett stabilt läge innan du använder den.
2. **Användning:** Håll kniven med ett fast grepp. Använd en säker teknik för det arbete du utför.
3. **Stäng kniven:** Använd liner lockfunktionen för att stänga kniven försiktigt. Kontrollera att bladet är helt stängt innan du förvarar kniven.
4. **Förvaring:** Förvara kniven på en säker plats, borta från barn och husdjur. Använd fickklämman för att fästa kniven på ett bälte eller en väska om så önskas.

Avfallshanteringsinstruktioner

- Kasta inte kniven i vanliga hushållsavfall.
- Om kniven är trasig eller inte längre säker att använda, ta den till en lokal återvinningsstation eller avfallshanteringsanläggning som är specialiserad på metallavfall.
- Följ lokala riktlinjer för avfallshantering för att säkerställa korrekt och säker bortskaffande.

Kontaktinformation för vidare support

För frågor eller rapportering av säkerhetsproblem, vänligen kontakta den lokala myndigheten eller besök EU:s Safety Gateplattform för senaste information om produktåterkallelser och säkerhetsmeddelanden.

Tack för att du valt Shrade SCH707 Tanto Point Blade. Din säkerhet är vår prioritet.