

U.G. G10 Ti Tanto Box - SCH U.G. G10 Ti Tanto Box

- Folding Knife
- 9Cr18MoV steel with 3.25" blade length and weighs 3.8 oz
- G10 handle with ti-nitride blade coating
- Finger flipper, liner lock and lanyard hole
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: SCH U.G. G10 Ti Tanto Box
- Manufacturer: Shrade
- Product no.: EU1001560
- Mfr. No.: 1100044
- Color: Black
- Delivery weight: 0.118kg
- Shipping height: 20mm
- Shipping width: 37mm
- Shipping length: 81mm
- UPC: 661120076407

Table of Contents

- [Startpage](#)
- [English: Shrade U.G. G10 Ti Tanto Box Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Shrade U.G. G10 Ti Tanto Box](#)

Shrade U.G. G10 Ti Tanto Box Safety Instruction Guide

Introduction

Thank you for choosing the Shrade U.G. G10 Ti Tanto Box Folding Knife. This guide provides important safety instructions and guidelines to ensure the safe use of your knife. Please read and understand these instructions before using the product.

General Safety Guidelines

- Always keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in proper working condition.
- Use the knife only for its intended purpose; do not use it as a tool for prying or other inappropriate tasks.
- Always cut away from your body and keep your fingers clear of the blade.
- Store the knife in a secure place when not in use to prevent accidental injury.
- If the knife is damaged, do not attempt to repair it yourself; contact the manufacturer for assistance.

Specific Safety Precautions for Use

- The blade is made of 9Cr18MoV steel and is sharp. Handle with care to avoid cuts.
- The G10 handle provides a secure grip; however, ensure your hands are dry to prevent slipping.
- The knife features a finger flipper and liner lock for safe operation. Always ensure the lock is engaged when the knife is not in use.
- Be cautious when using the pocket clip; ensure it is securely attached to your clothing or bag to prevent loss or injury.

Instructions for Installation and Usage

- **Opening the Knife:**
 - Use the finger flipper to open the knife with a smooth motion.
 - Ensure that the blade locks into place before use.
- **Using the Knife:**
 - Hold the knife firmly by the handle.
 - Position the blade at the desired cutting angle and apply gentle pressure to cut.
 - Always maintain control of the knife during use.
- **Closing the Knife:**
 - To close the knife, press the liner lock down and carefully fold the blade back into the handle.
 - Ensure the blade is fully closed and locked before storing.

Disposal Instructions

- Dispose of the knife responsibly at a designated waste facility.
- Do not dispose of the knife in regular household waste.
- If the knife is damaged beyond repair, ensure the blade is wrapped securely to prevent injury during disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Shrade U.G. G10 Ti Tanto Box Folding Knife, please refer to the manufacturer's contact details provided with your product packaging or visit the official website.

By following these guidelines, you can ensure a safe and enjoyable experience with your Shrade U.G. G10 Ti Tanto Box Folding Knife. Thank you for your attention to safety.

Säkerhetsinstruktioner för Shrade U.G. G10 Ti Tanto Box

Introduktion

Tack för att du valt Shrade U.G. G10 Ti Tanto Box. Denna fällkniv är designad för att ge hög prestanda och säkerhet. För att säkerställa en trygg och effektiv användning, vänligen läs igenom följande säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera alla osäkra produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om återkallelser genom EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för avsett ändamål, dvs. skärning och relaterade aktiviteter.
- Se till att knivbladet är i gott skick innan användning. Byt ut det om det är skadat.
- Undvik att använda kniven i blöta eller hala miljöer för att förhindra olyckor.
- Använd alltid kniven med försiktighet och kontrollera att handen är borta från bladet vid användning.
- Förvara kniven på en säker plats när den inte används, helst i ett skyddande fodral.

Instruktioner för installation och användning

1. **Öppna kniven:** Använd fingerflippern för att öppna kniven. Se till att kniven är riktad bort från dig och andra.
2. **Lås kniven:** Kontrollera att liner lock är i låst läge innan du börjar använda kniven.
3. **Användning av kniven:**
 - Håll kniven i ett fast grepp.
 - Använd bladet för skärning, men undvik att använda det för att bryta eller hacka hårda material.
4. **Stäng kniven:** Efter användning, tryck på liner lock för att låsa upp bladet och stäng det försiktigt.
5. **Förvaring:** Förvara kniven i ett torrt och säkert utrymme. Använd fickklämmen för att fästa kniven vid bältet eller i fickan när den inte används.

Avfallshantering

- Kasta inte kniven i vanligt avfall. Kontakta lokala avfallsmyndigheter för instruktioner om hur du korrekt kan kassera kniven.
- Om kniven är skadad eller sliten, se till att den inte kan orsaka skada på andra innan du kasserar den.

Kontaktinformation för vidare support

För frågor eller ytterligare information om säkerhet och användning av Shrade U.G. G10 Ti Tanto Box, vänligen kontakta tillverkaren eller återförsäljaren där produkten köptes. Det är viktigt att ha tillgång till en kontaktpunkt inom EU för säkerhetsfrågor.

Vi tackar för ditt köp och hoppas att du får en säker och njutbar upplevelse med din Shrade U.G. G10 Ti Tanto Box.