

U.G. G10 Ti Tanto Box - SCH U.G. G10 Ti Tanto Clam Pack

- Folding Knife
- 9Cr18MoV steel with 3.25" blade length and weighs 3.8 oz
- G10 handle with ti-nitride blade coating
- Finger flipper, liner lock and lanyard hole
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: SCH U.G. G10 Ti Tanto Clam Pack
- Manufacturer: Shrade
- Product no.: EU1001561
- Mfr. No.: 1100045
- Color: Black
- Delivery weight: 0.132kg
- Shipping height: 260mm
- Shipping width: 15mm
- Shipping length: 81mm
- UPC: 661120076414

Table of Contents

- [Startpage](#)
- [English: Shrade U.G. G10 Ti Tanto Box Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade U.G. G10 Ti Tanto Box](#)

Shrade U.G. G10 Ti Tanto Box Safety Instructions

Introduction

Thank you for choosing the Shrade U.G. G10 Ti Tanto Knife. This guide provides essential safety instructions to ensure the safe and effective use of your knife. Please read this manual carefully before use to understand how to operate and maintain your knife safely.

General Safety Guidelines

- Always handle the knife with care to avoid accidental cuts or injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Do not use the knife for tasks it is not designed for, such as prying or twisting.
- Regularly inspect the knife for any damage or wear before use.
- Store the knife in a safe place when not in use, preferably in a sheath or protective case.
- Ensure that the blade is always clean and dry to prevent corrosion and maintain performance.

Specific Safety Precautions for Use

- When opening the knife, ensure that your fingers are clear of the blade path.
- Use the finger flipper mechanism to deploy the blade safely.
- Always engage the liner lock to secure the blade in the open position during use.
- Be mindful of your surroundings when using the knife to avoid accidental injury to yourself or others.
- If the knife becomes dull, sharpen it carefully using appropriate tools and techniques.
- Do not attempt to modify or disassemble the knife, as this may compromise its safety and functionality.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly by the handle.
- Use your index finger to push the finger flipper downwards to open the blade.
- Ensure that the blade locks into place with the liner lock engaged.

2. Using the Knife:

- Always cut away from your body and keep your fingers clear of the blade.
- Use the knife for its intended purpose, such as cutting, slicing, or piercing materials.
- If you need to pause during use, ensure the blade is locked in the open position.

3. Closing the Knife:

- To close the knife, press the liner lock to release the blade.
- Carefully fold the blade back into the handle while keeping your fingers clear of the blade path.
- Ensure the knife is fully closed before storing it.

4. Cleaning and Maintenance:

- Clean the blade with a soft cloth after each use to remove dirt and moisture.
- If necessary, apply a light oil to the blade to prevent rust and maintain smooth operation.
- Store the knife in a dry environment to prevent corrosion.

Disposal Instructions

- When disposing of the knife, ensure that it is no longer usable to prevent accidental injury.
- Wrap the knife securely in a material that will prevent the blade from cutting through, such as cardboard or thick paper.
- Dispose of the wrapped knife in accordance with local waste management regulations.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Shrade U.G. G10 Ti Tanto Knife, please refer to the official Shrade website or contact your local retailer for assistance.

Thank you for your attention to these safety instructions. Enjoy your Shrade U.G. G10 Ti Tanto Knife responsibly!

Säkerhetsinstruktioner för Shrade U.G. G10 Ti Tanto Box

Introduktion

Tack för att du valt Shrade U.G. G10 Ti Tanto. Denna fällkniv är designad för att ge en säker och effektiv användning. För att säkerställa din säkerhet och för att maximera knivens livslängd, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven med försiktighet och respekt.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera alltid kniven för skador innan användning.
- Använd kniven endast för avsedd användning och undvik att använda den för andra syften.
- Förvara kniven på en säker plats när den inte används.

Specifika säkerhetsåtgärder för användning

- Använd alltid ett fast grepp om handtaget när du använder kniven.
- Använd kniven på en stabil yta för att undvika olyckor.
- Håll fingrarna borta från knivens blad när du använder fingerflippern.
- Stäng alltid kniven när den inte används och se till att liner lock är korrekt låst.
- Använd inte kniven om du är trött eller distraherad.

Instruktioner för installation och användning

- För att öppna kniven, använd fingerflippern för att fälla ut bladet.
- Kontrollera att liner lock är i låst läge innan du börjar använda kniven.
- För att stänga kniven, tryck på liner lock och fäll bladet tillbaka i handtaget.
- Rengör kniven efter användning med en mjuk trasa för att ta bort smuts och fukt.
- Smörj knivens gångjärn regelbundet för att säkerställa smidig öppning och stängning.

Avfallsinstruktioner

- Kasta inte kniven i hushållssoporna.
- Om kniven är skadad eller trasig, följ lokala riktlinjer för farligt avfall.
- Återvinn materialet i enlighet med lokala miljöbestämmelser.

Kontaktinformation för vidare support

För frågor eller rapportering av farliga produkter, vänligen kontakta den lokala myndigheten eller besök EU:s Safety Gateplattform för uppdateringar om återkallelser och säkerhetsinformation.

Genom att följa dessa riktlinjer kan du säkerställa en säker och effektiv användning av din Shrade U.G. G10 Ti Tanto. Tack för att du bidrar till en säker användning av våra produkter.