

SCH U.G. Green/Black Box

- Folding Knife
- 9Cr18MoV steel with 3.25" blade length and weighs 4.3 oz
- Rubberized aluminum handle with black oxide blade coating
- Finger flipper, liner lock, thumbstud and lanyard hole
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: SCH U.G. Green/Black Box
- Manufacturer: Shrade
- Product no.: EU1001564
- Mfr. No.: 1100048
- Color: Green/Black
- Delivery weight: 0.122kg
- Shipping height: 20mm
- Shipping width: 40mm
- Shipping length: 78mm
- UPC: 661120076445

Table of Contents

- [Startpage](#)
- [English: Shrade SCH U.G. Green/Black Box Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH U.G. Grön/Svart Fällkniv](#)

Shrade SCH U.G. Green/Black Box Safety Instructions

Introduction

Thank you for choosing the Shrade SCH U.G. Green/Black Box Folding Knife. This guide provides essential safety information and instructions to ensure the safe use of your knife. Please read this manual carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to prevent injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Regularly inspect the knife for any signs of damage or wear.
- Use the knife only for its intended purpose.
- Be cautious when opening and closing the knife to avoid accidental cuts.
- Do not use the knife if it is damaged or malfunctioning.
- Follow local laws and regulations regarding knife ownership and use.

Specific Safety Precautions for Use

- Ensure the blade is fully deployed and locked before use.
- Use the finger flipper and thumb stud with care.
- Avoid using excessive force when cutting to prevent blade breakage.
- Do not use the knife for prying or as a lever.
- Always cut away from your body and keep fingers clear of the blade.
- Store the knife in a safe place when not in use, preferably in a sheath or protective case.

Instructions for Installation and Usage

1. Opening the Knife

- Use the finger flipper or thumb stud to open the knife.
- Ensure that the blade locks into place securely.

2. Using the Knife

- Hold the knife firmly by the rubberized aluminum handle.
- Position the blade at the desired angle for cutting.
- Apply steady pressure while cutting through materials.

3. Closing the Knife

- To close the knife, press the liner lock to release the blade.
- Carefully fold the blade back into the handle.
- Ensure the blade is fully closed before storing.

Disposal Instructions

- Dispose of the knife responsibly.
- If the knife is damaged beyond repair, consider recycling metal components where applicable.
- Follow local regulations for the disposal of sharp objects to prevent injury to waste handlers.

Contact Information for Further Support

For safety inquiries or to report any issues with your knife, please contact the manufacturer directly. Ensure you have your product details ready for reference.

By following these safety instructions, you can ensure a safe and enjoyable experience with your Shrade SCH U.G. Green/Black Box Folding Knife. Thank you for your attention to safety!

Säkerhetsinstruktioner för Shrade SCH U.G. Grön/Svart Fällkniv

Introduktion

Tack för att du valt Shrade SCH U.G. Grön/Svart Fällkniv. Denna guide innehåller viktiga säkerhetsinstruktioner och riktlinjer för att säkerställa en säker och effektiv användning av produkten. Vänligen läs igenom hela dokumentet noggrant innan du använder kniven.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och personer som inte är utbildade i säker användning av knivar.
- Kontrollera kniven regelbundet för skador eller slitage innan användning.
- Använd kniven endast för avsedda ändamål och undvik att använda den för uppgifter den inte är avsedd för.
- Om kniven skadas eller fungerar onormalt, sluta använda den omedelbart och kontakta en specialist.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven på en stabil och säker yta.
- Använd skyddshandskar om möjligt för att skydda händerna under användning.
- Håll fingrarna borta från bladets väg när du fäller ut eller stänger kniven.
- Använd fingerflippern för att fälla ut bladet men var försiktig så att du inte skadar dig själv.
- Förvara kniven i ett säkert läge, helst i ett fodral eller en fickklämma när den inte används.

Instruktioner för installation och användning

1. Fäll ut bladet:

- Använd fingerflippern för att fälla ut bladet.
- Se till att bladet är helt utfällt och låst på plats innan du använder kniven.

2. Användning:

- Håll handtaget med ett fast grepp.
- Använd kniven för skärning, skrapning eller andra avsedda uppgifter.
- Undvik att använda kniven för att skära genom hårda material som metall eller glas.

3. Stängning av kniven:

- Tryck på liner lock för att låsa upp bladet.
- Fäll försiktigt tillbaka bladet i handtaget.
- Kontrollera att bladet är helt stängt innan du förvarar kniven.

Avfallshanteringsinstruktioner

- När kniven inte längre är användbar, hantera den på ett ansvarsfullt sätt.
- Kontrollera lokala riktlinjer för avfallshantering, speciellt för vassa föremål.
- Om kniven är skadad eller defekt, se till att den förvaras på ett säkert sätt tills den kan kasseras.

Kontaktinformation för vidare support

För frågor eller säkerhetsrelaterade ärenden, vänligen kontakta den lokala återförsäljaren eller besök vår webbplats för mer information. Vi rekommenderar att du alltid kontrollerar för eventuella återkallelser eller säkerhetsuppdateringar via EU:s Safety Gateplattform.

Dessa säkerhetsinstruktioner är utformade för att följa EU:s allmänna produkt säkerhetsförordning (GPSR) och säkerställa en trygg användning av din Shrade SCH U.G. Grön/Svart Fällkniv. Tack för att du valde våra produkter!