

SCH U.G. Green/Black Box - SCH U.G. Green/Black Clam Pack

- Folding Knife
- 9Cr18MoV steel with 3.25" blade length and weighs 4.3 oz
- Rubberized aluminum handle with black oxide blade coating
- Finger flipper, liner lock, thumbstud and lanyard hole
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: SCH U.G. Green/Black Clam Pack
- Manufacturer: Shrade
- Product no.: EU1001565
- Mfr. No.: 1100049
- Color: Green/Black
- Delivery weight: 0.154kg
- Shipping height: 260mm
- Shipping width: 13mm
- Shipping length: 78mm
- UPC: 661120076452

Table of Contents

- [Startpage](#)
- [English: Shrade SCH U.G. Green/Black Folding Knife Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH U.G. Grön/Svart Fällkniv](#)

Shrade SCH U.G. Green/Black Folding Knife Safety Instruction Guide

Introduction

Thank you for choosing the Shrade SCH U.G. Green/Black Folding Knife. This guide provides essential safety instructions to ensure safe and effective use of your knife. Please read this guide carefully before using the product.

General Safety Guidelines

- Always handle the knife with care and keep it out of reach of children.
- Ensure that the knife is fully opened and locked before use.
- Keep the blade clean and dry to prevent rust and maintain sharpness.
- Do not use the knife for purposes other than intended (e.g., do not use it as a screwdriver or pry bar).
- Regularly inspect the knife for any signs of damage or wear.
- In case of any accidents or injuries, seek medical attention immediately.

Specific Safety Precautions for Use

- **Blade Handling:** Always cut away from your body and keep your fingers clear of the blade.
- **Lock Mechanism:** Familiarize yourself with the liner lock mechanism to ensure it is properly engaged during use.
- **Finger Flipper:** Use the finger flipper feature to open the knife safely, ensuring your fingers are positioned away from the blade.
- **Thumbstud:** Utilize the thumbstud for quick access, but ensure the blade is directed away from yourself and others.
- **Lanyard Hole:** Consider using a lanyard for added security when using the knife in outdoor settings.
- **Pocket Clip:** Securely attach the knife to your pocket or belt with the pocket clip to prevent accidental drops.

Instructions for Installation and Usage

1. Opening the Knife:

- Grip the handle firmly.
- Use the finger flipper or thumbstud to open the blade.
- Ensure the blade locks into place securely.

2. Using the Knife:

- Hold the knife by the handle, ensuring a firm grip.
- Position the blade at the desired angle for cutting.
- Cut away from your body and avoid excessive force.

3. Closing the Knife:

- Press the liner lock to disengage the blade.
- Carefully fold the blade back into the handle.
- Ensure the blade is fully closed and locked before storing.

Disposal Instructions

- Dispose of the knife in accordance with local regulations.
- If the knife is damaged or no longer usable, consider recycling the metal components where possible.
- Ensure that the blade is secured or covered to prevent injury during disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Shrade SCH U.G. Green/Black Folding Knife, please refer to the manufacturer's contact information provided on the packaging or visit the official website.

By following these safety instructions, you can ensure a safe and enjoyable experience with your Shrade SCH U.G. Green/Black Folding Knife. Always prioritize safety and proper handling to prevent accidents and injuries.

Säkerhetsinstruktioner för Shrade SCH U.G. Grön/Svart Fällkniv

Introduktion

Tack för att du valt Shrade SCH U.G. Grön/Svart Fällkniv. Denna fällkniv är designad för säker och effektiv användning. Vänligen läs och följ dessa säkerhetsinstruktioner noggrant för att säkerställa en säker användning av produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Förvara kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador. Använd inte en skadad kniv.
- Håll kniven ren och torr för att förhindra rost och skador.
- Rapportera eventuella farliga produkter eller olyckor till myndigheterna.
- Kontrollera EU:s Safety Gateplattform för uppdateringar om återkallelser.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med spetsen borta från kroppen och andra personer.
- Undvik att använda kniven för uppgifter den inte är avsedd för, såsom att öppna burkar eller som verktyg för att slå.
- Använd fingerflippern och tumstudsens för att öppna kniven på ett säkert sätt.
- Stäng alltid kniven när den inte används och förvara den i ett säkert läge.
- Var försiktig när du hanterar kniven, särskilt vid rengöring och underhåll.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd fingerflippern för att öppna kniven försiktigt.
- Se till att kniven låses på plats med liner lock.

2. Använd kniven:

- Håll kniven med ett fast grepp om det gummibelagda aluminiumhandtaget.
- Utför ditt arbete med kniven i en stabil och säker position.

3. Stäng kniven:

- Tryck på liner lock för att frigöra bladet.
- Vik bladet försiktigt tillbaka in i handtaget tills det klickar på plats.

4. Rengöring och underhåll:

- Torka av kniven med en ren, torr trasa efter användning.
- Förvara kniven i en torr miljö för att förhindra rost.

Avfallsinstruktioner

- Kassera kniven på ett ansvarsfullt sätt. Om kniven är skadad eller inte längre används, se till att den inte kan användas av barn eller andra oskyddade personer.

- Följ lokala riktlinjer för avfallshantering för metallprodukter.

Kontaktinformation för vidare support

För frågor eller ytterligare information om säkerhet och användning av Shrade SCH U.G. Grön/Svart Fällkniv, vänligen kontakta din återförsäljare eller besök tillverkarens officiella webbplats.

Vi tackar för att du valt Shrade, och vi önskar dig en säker och tillfredsställande användning av din fällkniv.