

SCH Mini Axe/Saw Combo Box

- 12" overall length and weighs 1.5 lbs
- Twice injected handle with ti-nitride blade axe head coating
- 6.9" wood saw built into the handle
- 2 locking positions for the saw
- Pommel on back of axe head

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade SCH Mini Axe/Saw Combo Box
- Manufacturer: Shrade
- Product no.: EU1001568
- Mfr. No.: 1100052
- Color: Black
- Delivery weight: 0.921kg
- Shipping height: 40mm
- Shipping width: 170mm
- Shipping length: 85mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Shrade SCH Mini Axe/Saw Combo Box Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH Mini Axe/Saw Combo Box](#)

Shrade SCH Mini Axe/Saw Combo Box Safety Instructions

Introduction

Thank you for choosing the Shrade SCH Mini Axe/Saw Combo Box. This product is designed for outdoor activities and is equipped with a mini axe and a wood saw. To ensure safe use and optimal performance, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always use the product in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product for any damage before each use. Do not use if damaged.
- Store the product in a dry place, away from direct sunlight and extreme temperatures.
- Ensure that the axe and saw are clean and free from debris after use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment, including gloves and eye protection, while using the axe and saw.
- Ensure that you have a stable and secure footing while using the axe or saw.
- Use the axe for chopping and the saw for cutting; do not use them for unintended purposes.
- Keep hands and other body parts away from the cutting edges at all times.
- When using the saw, ensure that the locking mechanism is engaged to prevent accidental folding.
- Always cut away from your body to minimize the risk of injury.
- Do not attempt to cut through materials that exceed the saw's capacity.

Instructions for Installation and Usage

- **Unpacking:** Carefully remove the axe/saw combo from the packaging. Check for any damage.
- **Locking Mechanism:** Familiarize yourself with the locking positions for the saw. Ensure it is securely locked in place before use.
- **Using the Axe:**
 - Hold the axe firmly by the handle.
 - Swing the axe in a controlled manner, aiming at the target material.
 - Do not swing the axe if there are people or pets nearby.
- **Using the Saw:**
 - Extend the saw from the handle and secure it in the locked position.
 - Position the material to be cut securely.
 - Use a steady, backandforth motion to cut through the material.
- **After Use:**
 - Clean the axe and saw with a dry cloth.
 - Store the axe/saw combo safely in its designated storage area.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding waste disposal.
- If the product is no longer usable, ensure that it is securely wrapped to prevent injury during disposal.
- Do not dispose of the product in household waste if it contains hazardous materials. Check local guidelines for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or product support, please refer to the manufacturer's website or customer service. Ensure that you have the product details ready for assistance.

By following these safety instructions, you can ensure a safe and enjoyable experience with your Shrade SCH Mini Axe/Saw Combo Box. Thank you for your attention to safety.

Säkerhetsinstruktioner för Shrade SCH Mini Axe/Saw Combo Box

Introduktion

Tack för att du valt Shrade SCH Mini Axe/Saw Combo Box. Denna produkt är designad för att vara ett praktiskt och effektivt verktyg. För att säkerställa en säker och effektiv användning, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt instruktionerna för att minimera risker.
- Kontrollera produkten för skador innan användning. Använd inte om den är skadad.
- Håll produkten utom räckhåll för barn och andra som inte är utbildade i säker användning av verktyg.
- Använd skyddsutrustning som handskar och ögonskydd vid användning.
- Rapportera eventuella skador eller problem med produkten till försäljaren.

Specifika säkerhetsåtgärder för användning

- Använd aldrig yxhuvudet för att slå på hårda ytor, vilket kan leda till sprickor eller skador.
- Se till att sågen är korrekt låst innan användning för att undvika oavsiktlig öppning.
- Använd alltid sågen på en stabil yta och håll ett fast grepp.
- Undvik att använda produkten i blöta eller hala förhållanden för att minimera risken för olyckor.
- Förvara produkten på en säker plats när den inte används.

Instruktioner för installation och användning

- För att använda yxan, håll handtaget med båda händerna och rikta yxhuvudet mot det material som ska skäras.
- Använd en jämn och kontrollerad rörelse för att utföra snittet.
- För att använda sågen, dra ut sågen från handtaget och lås den på plats.
- Använd sågen med en fram och tillbakagående rörelse för bästa resultat.
- Efter användning, se till att sågen är ordentligt låst tillbaka i handtaget.

Avfallshanteringsanvisningar

- Kasta inte produkten i hushållssoporna.
- Följ lokala riktlinjer för avfallshantering för verktyg och skarpa föremål.
- Återvinn om möjligt, och se till att alla delar är säkert avlägsnade.

Kontaktinformation för ytterligare support

För frågor angående säkerheten eller funktionaliteten hos Shrade SCH Mini Axe/Saw Combo Box, vänligen kontakta din återförsäljare för mer information.

Tack för att du följer dessa säkerhetsinstruktioner. Genom att göra det bidrar du till en säkrare användning av din produkt.