

SCH Mini-Bolo II Box

- 18.4" overall length and weighs 1.4 lbs
- 12" blade length
- 3Cr13 steel with rubber handle and powder coated blade
- Sharpening stone and fire starter
- Sheath with shoulder strap

NO IMAGE
AVAILABLE

Attributes

- Name: SCH Mini-Bolo II Box
- Manufacturer: Shrade
- Product no.: EU1001570
- Mfr. No.: 1100056
- Color: Black
- Delivery weight: 1.102kg
- Shipping height: 54mm
- Shipping width: 118mm
- Shipping length: 307mm
- UPC: 661120076513

Table of Contents

- [Startpage](#)
- [English: Safety Instructions for Shrade SCH MiniBolo II Box](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH MiniBolo II Box](#)

Safety Instructions for Shrade SCH MiniBolo II Box

Introduction

Thank you for choosing the Shrade SCH MiniBolo II Box. This guide provides essential safety instructions to ensure the safe and effective use of your knife. Please read this document carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to prevent injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Use the knife only for its intended purpose.
- Inspect the knife regularly for any signs of damage or wear.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always cut away from your body and keep your hands clear of the blade.
- Use protective gloves when sharpening the blade.
- Ensure the area around you is clear of obstructions and bystanders when using the knife.
- Store the knife in its sheath when not in use to prevent accidental cuts or injuries.
- Do not use the knife for prying or as a lever, as this may damage the blade or cause injury.

Instructions for Installation and Usage

1. Unpacking the Knife

- Carefully remove the knife from its packaging.
- Dispose of any packaging materials responsibly.

2. Using the Knife

- Hold the knife firmly by the handle, ensuring a secure grip.
- For cutting tasks, position the blade at an angle suitable for the material you are cutting.
- Apply even pressure while cutting to maintain control.

3. Sharpening the Blade

- Use the provided sharpening stone to maintain the blade's sharpness.
- Follow the manufacturer's instructions for sharpening techniques.

4. Using the Fire Starter

- Follow the instructions included with the fire starter for safe operation.
- Keep flammable materials away from the fire starter when in use.

5. Storing the Knife

- Always store the knife in its sheath when not in use.
- Keep the knife in a cool, dry place away from direct sunlight.

Disposal Instructions

- Dispose of the knife responsibly at a designated waste disposal facility.
- Do not throw the knife in regular household waste.
- Follow local regulations regarding the disposal of sharp objects.

Contact Information for Further Support

For any safety inquiries or support related to the Shrade SCH MiniBolo II Box, please contact the relevant EUbased support team.

Thank you for following these safety instructions. Enjoy your Shrade SCH MiniBolo II Box responsibly!

Säkerhetsinstruktioner för Shrade SCH MiniBolo II Box

Introduktion

Tack för att du valt Shrade SCH MiniBolo II Box. Denna produkt är utformad för att vara säker och effektiv när den används korrekt. Vänligen läs igenom dessa säkerhetsinstruktioner noggrant för att säkerställa en trygg användning.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt instruktionerna.
- Håll produkten utom räckhåll för barn.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera osäkra produkter och olyckor till myndigheterna.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.
- Använd produkten endast för dess avsedda syfte.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar när du hanterar kniven för att undvika skador.
- Var försiktig när du öppnar och stänger knivbladet.
- Undvik att använda kniven i närheten av brännbara material.
- Använd kniven på en stabil yta för att förhindra olyckor.
- Håll kniven ren och torr för att förlänga livslängden och säkerheten.

Instruktioner för installation och användning

1. **Öppna kniven:** Tryck på låsmekanismen och dra försiktigt ut bladet.
2. **Stäng kniven:** Tryck på låsmekanismen igen och vik bladet tillbaka på plats.
3. **Användning:**
 - Använd kniven för skärning av material som är avsett för dess design.
 - Undvik att använda kniven för att skära genom hårda ytor som kan skada bladet.
4. **Underhåll:**
 - Rengör kniven med en fuktig trasa efter varje användning.
 - Smörj låsmekanismen regelbundet för att säkerställa smidig funktion.
 - Förvara kniven i det medföljande fodralet när den inte används.

Avfallshantering

- Kassera trasiga eller slitna delar på ett miljövänligt sätt.
- Följ lokala föreskrifter för avfallshantering av metallprodukter.
- Undvik att slänga kniven i hushållssoporna om den är i fungerande skick; överväg att ge bort eller återvinna den.

Kontaktinformation för vidare support

För frågor eller ytterligare support, vänligen kontakta din återförsäljare eller besök tillverkarens officiella webbplats för mer information.

Tack för att du följer dessa säkerhetsinstruktioner och för att du bidrar till en säker användning av Shrade SCH MiniBolo II Box.