

2201UH Stag Horn Gut Hook Skinner - Uncle Herny 2203UH Stag Horn Fixed Blade

- D2 Steel Satin Finish Blade Stag Horn Handle
- Full Tang
- Brass Pins
- Leather Sheath

NO IMAGE
AVAILABLE

Attributes

- Name: Uncle Herny 2203UH Stag Horn Fixed Blade
- Manufacturer: Uncle Herny
- Product no.: EU1001574
- Mfr. No.: 1085924
- Delivery weight: 0.322kg
- Shipping height: 54mm
- Shipping width: 78mm
- Shipping length: 100mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Uncle Herny 2201UH Stag Horn Gut Hook Skinner & 2203UH Stag Horn Fixed Blade Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Uncle Herny 2201UH Stag Horn Gut Hook Skinner och Uncle Herny 2203UH Stag Horn Fixed Blade](#)

Uncle HERNY 2201UH Stag Horn Gut Hook Skinner & 2203UH Stag Horn Fixed Blade Safety Instructions

Introduction

Thank you for choosing the Uncle HERNY 2201UH Stag Horn Gut Hook Skinner and 2203UH Stag Horn Fixed Blade. These knives are designed for safe and effective use in various cutting tasks. This guide provides important safety instructions and guidelines to ensure your safety and the longevity of the product.

General Safety Guidelines

- Always handle knives with care and keep them out of reach of children.
- Inspect the knife before each use to ensure it is in good condition and free from defects.
- Use the knife only for its intended purpose; do not use it for prying or other inappropriate tasks.
- Always cut away from your body and keep your hands clear of the blade.
- Store the knife in a safe place, preferably in its sheath, when not in use.
- Do not attempt to modify or repair the knife yourself; seek professional assistance if needed.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure the knife is sharp before use; a dull knife can be more dangerous as it requires more force.
- When using the gut hook feature, be cautious and ensure you are familiar with its operation to avoid accidental injury.
- Always maintain a firm grip on the handle while using the knife to prevent slippage.
- Avoid using the knife in wet conditions as this can lead to loss of grip and control.
- Be aware of your surroundings; ensure there are no obstacles or people nearby when using the knife.

Instructions for Installation and Usage

• Before Use:

- Remove the knife from its sheath carefully.
- Inspect the blade for any damage or defects.

• Using the Knife:

- Hold the knife firmly by the handle.
- Position the blade at the desired cutting angle.
- Use smooth, controlled motions to cut, avoiding excessive force.
- If the knife becomes stuck, do not force it; instead, carefully maneuver it to free it.

• After Use:

- Clean the knife with a damp cloth and dry it thoroughly.
- Store the knife in its sheath to protect the blade and ensure safety.

• Maintenance:

- Regularly check the knife for any signs of wear or damage.
- Sharpen the blade as needed using appropriate sharpening tools.

- Keep the handle clean and free from debris to maintain a good grip.

Disposal Instructions

- Dispose of the knife responsibly, following local regulations for hazardous materials.
- If the knife is damaged beyond repair, wrap it securely in a protective material to prevent injury during disposal.
- Do not throw the knife in regular household waste without proper precautions.

Contact Information for Further Support

For any inquiries or concerns regarding the safety and use of your Uncle Henry knives, please refer to the manufacturer's contact information provided with your product packaging. Ensure you have the product details ready for a more efficient response.

Thank you for your attention to these safety guidelines. Enjoy your Uncle Henry knives responsibly!

Säkerhetsinstruktioner för Uncle Herny 2201UH Stag Horn Gut Hook Skinner och Uncle Herny 2203UH Stag Horn Fixed Blade

Introduktion

Tack för att du har valt Uncle Herny 2201UH Stag Horn Gut Hook Skinner och Uncle Herny 2203UH Stag Horn Fixed Blade. Dessa knivar är designade för att ge hög prestanda och hållbarhet. För att säkerställa säker användning och lång livslängd, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och sårbara personer.
- Kontrollera knivens skick innan användning. Byt ut den om den är skadad.
- Använd kniven endast för avsedd användning.
- Förvara kniven på en säker plats när den inte används.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med en säker handposition för att undvika olyckor.
- Skär bort från kroppen och håll fingrarna borta från skärbladet.
- Använd skyddshandskar om möjligt för att minimera risken för skador.
- Undvik att använda kniven i fuktiga eller hala miljöer.
- Var försiktig när du hanterar kniven, särskilt vid rengöring och underhåll.

Instruktioner för installation och användning

1. Förberedelse:

- Se till att du har en ren och stabil arbetsyta.
- Kontrollera att kniven är ren och i gott skick.

2. Användning:

- Håll kniven med ett fast grepp, med tummen på knivens rygg för extra stabilitet.
- Vid skärning, börja med ett lätt tryck och öka trycket gradvis.
- Använd knivens specifika funktioner (gut hook) för att underlätta arbetet.

3. Rengöring:

- Rengör kniven omedelbart efter användning med varmt vatten och mild tvål.
- Torka kniven noggrant och förvara den i läderfodralet för att skydda den.

Avfallsinstruktioner

- Kassera trasiga eller slitna knivar på ett säkert sätt för att förhindra skador.
- Följ lokala riktlinjer för avfallshantering när du gör dig av med kniven eller dess delar.

Kontaktinformation för ytterligare stöd

För frågor eller säkerhetsinquiries, vänligen kontakta en lokal återförsäljare eller besök vår webbplats för mer information.

Genom att följa dessa riktlinjer och säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av Uncle Hery 2201UH Stag Horn Gut Hook Skinner och Uncle Hery 2203UH Stag Horn Fixed Blade. Tack för att du prioriterar säkerheten!