

2201UH Stag Horn Gut Hook Skinner - 2204UH 8" Stag Horn Fixed Blade

- D2 Steel Satin Finish Blade Stag Horn Handle
- Full Tang
- Brass Pins
- Leather Sheath

NO IMAGE
AVAILABLE

Attributes

- Name: 2204UH 8" Stag Horn Fixed Blade
- Manufacturer: Uncle Herry
- Product no.: EU1001575
- Mfr. No.: 1085925
- Delivery weight: 0.34kg
- Shipping height: 54mm
- Shipping width: 78mm
- Shipping length: 100mm
- UPC: 661120414445

Table of Contents

- [Startpage](#)
- [English: Uncle Henry 2201UH Stag Horn Gut Hook Skinner Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Uncle Henry 2201UH Stag Horn Gut Hook Skinner 2204UH](#)

Uncle Henry 2201UH Stag Horn Gut Hook Skinner Safety Instruction Guide

Introduction

Thank you for choosing the Uncle Henry 2201UH Stag Horn Gut Hook Skinner. This guide provides essential safety instructions to ensure the safe use and handling of your knife. Please read this manual carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to avoid injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife for any damage before use. Do not use if damaged.
- Ensure that you are in a safe environment when using the knife to avoid accidents.
- Use the knife only for its intended purpose.

Specific Safety Precautions for Use

- **Cutting Surface:** Always use a stable and appropriate cutting surface.
- **Grip:** Maintain a firm grip on the handle while using the knife.
- **Direction of Cut:** Cut away from your body to minimize the risk of injury.
- **Distraction:** Avoid distractions while using the knife to maintain focus.
- **Storage:** Store the knife in its sheath when not in use to prevent accidental cuts.

Instructions for Installation and Usage

1. **Unboxing:** Carefully remove the knife from its packaging. Avoid using sharp tools that may damage the knife.
2. **Inspection:** Check the knife for any visible defects or damage. If any issues are found, do not use the knife.
3. **Usage:**
 - Hold the knife by the handle and ensure your fingers are away from the blade.
 - When cutting, position your hand and fingers safely, ensuring they are not in the path of the blade.
 - Use the gut hook feature carefully, ensuring that it is only used for its intended purpose.
4. **Cleaning:** After use, clean the blade with a soft cloth and mild detergent. Do not immerse in water for extended periods.
5. **Maintenance:** Regularly inspect the blade for sharpness. Sharpen as needed using appropriate sharpening tools.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged beyond repair, wrap it securely in a protective material to prevent injury and dispose of it in accordance with local regulations.
- Do not throw the knife in regular trash without proper wrapping to avoid injury to others.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Uncle Henry 2201UH Stag Horn Gut Hook Skinner, please contact the manufacturer or visit their official website for further assistance.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your Uncle Henry 2201UH Stag Horn Gut Hook Skinner. Always prioritize safety and proper handling to avoid accidents. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för Uncle Henry 2201UH Stag Horn Gut Hook Skinner 2204UH

Introduktion

Tack för att du valt Uncle Henry 2201UH Stag Horn Gut Hook Skinner 2204UH. Denna guide ger viktiga säkerhetsinstruktioner för att säkerställa en säker och effektiv användning av din kniv. Läs noggrant igenom dessa instruktioner innan du använder produkten.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt sätt och i enlighet med dess avsedda syfte.
- Håll kniven utom räckhåll för barn och andra personer som inte är utbildade i säker användning av knivar.
- Kontrollera alltid knivens skick innan användning för att säkerställa att den är fri från skador.
- Rapportera omedelbart eventuella skador eller defekter till återförsäljaren.
- Följ lokala lagar och förordningar angående användning och bärande av knivar.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar vid hantering av kniven för att minimera risken för skador.
- Se till att arbetsytan är stabil och fri från hinder när du använder kniven.
- Undvik att rikta kniven mot dig själv eller andra när du skär.
- Förvara kniven i det medföljande läderhölstret när den inte används.
- Använd kniven endast för dess avsedda syften, som att skära och rensa.

Instruktioner för installation och användning

1. Kontrollera kniven:

- Inspektera bladet och handtaget för skador.
- Kontrollera att bladet är skarpt och rent.

2. Användning:

- Håll kniven med ett fast grepp och se till att fingrarna är borta från bladets väg.
- Använd en skärbräda eller annan stabil yta för skärning.
- Skär alltid bort från kroppen och använd långsamma, kontrollerade rörelser.

3. Rengöring:

- Rengör kniven efter varje användning med varmt vatten och mild tvål.
- Torka kniven noggrant för att förhindra rost.

4. Förvaring:

- Förvara kniven i det medföljande läderhölstret.
- Håll kniven på en säker plats, borta från barn och husdjur.

Avfallsinstruktioner

- När kniven inte längre är användbar, se till att den kasseras på ett säkert sätt för att undvika olyckor.
- Följ lokala riktlinjer för avfallshantering och återvinning av metall.

Kontaktinformation för vidare support

För säkerhetsfrågor och ytterligare information, vänligen kontakta den lokala återförsäljaren eller besök tillverkarens webbplats för mer information.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din Uncle Henry kniv. Tack för ditt köp!