

9" Serrated Flex Knife

The 9" Serrated Flex Knife is the ideal knife for the anglers who target large-scaled fish. This knife does it all—from filleting to cutting through large bones. The 9" Serrated Flex Fillet Knife comes fully-loaded with our iconic, non-slip grip handle and titanium-nitride coated blade. The full-tang construction includes engineered, razor sharp serrations and a deluxe sheath.

NO IMAGE
AVAILABLE

Attributes

- Name: 9" Serrated Flex Knife
- Manufacturer: BUBBA
- Product no.: EU1001645
- Mfr. No.: 1112553
- Color: Red/Black
- Delivery weight: 2.5kg
- UPC: 661120079910

Table of Contents

- [Startpage](#)
- [English: BUBBA 9" Serrated Flex Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA 9" Serrated Flex Knife](#)

BUBBA 9" Serrated Flex Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA 9" Serrated Flex Knife. This knife is designed for anglers who target largescaled fish and is equipped with features that enhance safety and usability. Please read this safety instruction guide carefully to ensure safe and effective use of your knife.

General Safety Guidelines

- Always handle the knife with care to prevent injuries.
- Keep the knife out of reach of children to avoid accidental cuts.
- Ensure that the knife is stored securely when not in use.
- Regularly inspect the knife for any signs of damage or wear.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about recall updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Cutting Surface:** Always use a stable and appropriate cutting surface to prevent slipping.
- **Grip:** Utilize the nonslip grip handle for secure handling and control.
- **Blade Safety:** Be aware of the sharpness of the blade and avoid placing your fingers near the cutting edge.
- **Cutting Technique:** Use a proper cutting technique to minimize the risk of accidents, ensuring that the blade is directed away from your body.
- **Safety Guards:** The knife features safety guards; always ensure they are in place during use.
- **Sheath Usage:** Use the included nylon sheath for safe storage and transport of the knife.

Instructions for Installation and Usage

1. Unpacking the Knife:

- Carefully remove the knife from its packaging.
- Inspect the knife for any visible damage or defects.

2. Using the Knife:

- Hold the knife by the nonslip grip handle.
- Position the knife at a comfortable angle to the cutting surface.
- Begin cutting with the tip of the blade, applying gentle pressure to initiate the cut.
- For filleting fish, use smooth, controlled motions to avoid tearing the flesh.

3. Storing the Knife:

- After use, clean the knife thoroughly with mild soap and water.
- Dry the knife completely to prevent rusting.
- Store the knife in the provided nylon sheath and keep it in a safe location, out of reach of children.

Disposal Instructions

- Dispose of the knife responsibly in accordance with local regulations.
- If the knife is damaged beyond repair, wrap it securely in protective material to prevent injury during disposal.

Contact Information for Further Support

For any questions or concerns regarding the use of your BUBBA 9" Serrated Flex Knife, please consult the manufacturer's website or contact your local distributor. Always ensure that you are following the latest safety guidelines and product updates.

Säkerhetsinstruktioner för BUBBA 9" Serrated Flex Knife

Introduktion

Tack för att du valt BUBBA 9" Serrated Flex Knife. Denna kniv är utformad för att ge en säker och effektiv upplevelse för sportfiskare. För att säkerställa en trygg användning av produkten, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert sätt och håll den utom räckhåll för barn.
- Kontrollera kniven före användning för att säkerställa att den är i gott skick och att bladet är skarpt.
- Undvik att använda kniven för andra ändamål än vad den är avsedd för.
- Förvara kniven på en säker plats när den inte används, helst i det medföljande fodralet.
- Var medveten om din omgivning när du använder kniven för att undvika olyckor.

Specifika säkerhetsåtgärder för användning

- Använd alltid ett stabilt och säkert underlag när du filéar eller skär fisk.
- Håll fingrarna borta från bladet och använd ett grepp som ger dig kontroll över kniven.
- Använd säkerhetsguard för att skydda dina händer från bladet och fiskens taggar.
- Använd kniven med ett fast grepp och undvik att använda överdriven kraft.
- Om kniven skadas eller bladet blir slitet, sluta använda den omedelbart och överväg att byta ut den.

Instruktioner för installation och användning

1. **Förberedelse:** Se till att kniven är ren och torr innan användning.
2. **Användning:**
 - Håll kniven med det halkfria handtaget för att säkerställa ett bra grepp.
 - Använd den serrerade kanten för att skära genom större ben eller hårda områden.
 - För filéering, använd den flexibla delen av bladet för att följa fiskens konturer.
3. **Rengöring:** Rengör kniven efter varje användning med varmt vatten och mild tvål. Torka noggrant för att undvika rost.
4. **Förvaring:** Förvara kniven i det medföljande nylonfodralet när den inte används för att skydda bladet och säkerställa säker förvaring.

Avfallshanteringsinstruktioner

- När kniven är förbrukad eller skadad, kassera den på ett säkert sätt.
- Undvik att kasta kniven i vanliga hushållsavfall. Kontakta lokala avfallshanteringsanläggningar för specifika riktlinjer för avfallshantering av vassa föremål.

Kontaktinformation för ytterligare stöd

För frågor eller säkerhetsinformationsförfrågningar, vänligen kontakta vår kundtjänst. Vi är här för att hjälpa dig med eventuella frågor eller problem du kan ha med produkten.

Tack för att du följer dessa säkerhetsinstruktioner och för att du använder BUBBA 9" Serrated Flex Knife på ett säkert sätt.