

Tether

Keep your clippers and pliers close at hand with the Bubba Tether Tool. The Bubba Tether Tool offers an extremely portable and durable carabineer clip to securely hold your gear while on the water. The Bubba tether tool offers 36" of cable for easy access and retrieval of your gear.

NO IMAGE
AVAILABLE

Attributes

- Name: BUBBA Tether
- Manufacturer: BUBBA
- Product no.: EU1001677
- Mfr. No.: 1116530
- Color: Black
- Delivery weight: 0.5kg
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: BUBBA Tether Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA Tether Tool](#)

BUBBA Tether Safety Instruction Guide

Introduction

Thank you for choosing the BUBBA Tether Tool. This guide provides essential safety instructions and guidelines to ensure the safe use of your BUBBA Tether. Please read this manual carefully before using the product to ensure you understand all safety precautions.

General Safety Guidelines

- Ensure the BUBBA Tether Tool is used only for its intended purpose.
- Inspect the tool and its components regularly for signs of wear or damage.
- Do not use the BUBBA Tether Tool if any part is damaged or malfunctioning.
- Keep the tool out of reach of children and vulnerable individuals.
- Always follow local regulations regarding the use of tools and equipment.

Specific Safety Precautions for Use

- Always secure the carabineer clip properly before use to prevent accidental release.
- Do not exceed the weight limit of the BUBBA Tether Tool.
- Avoid using the tether in highrisk environments, such as areas with strong currents or severe weather conditions.
- Do not use the tether to lift heavy objects; it is designed for securing gear only.
- Be mindful of the cable length (36 inches) to avoid entanglement or snagging.

Instructions for Installation and Usage

1. Inspect the Tool:

- Before use, check the carabineer clip and Dyneema cable for any signs of damage.
- Ensure that the swivel line is functioning properly.

2. Attaching the Tool:

- Attach the carabineer clip to a secure anchor point, such as a boat or a stable structure.
- Ensure the clip is fully closed and locked to prevent accidental detachment.

3. Securing Your Gear:

- Use the Dyneema cable to secure your clippers or pliers by threading the cable through the handle or attachment point of the gear.
- Ensure that the gear is firmly attached and can be easily accessed.

4. Retrieving Your Gear:

- To access your gear, simply pull on the Dyneema cable to retrieve it.
- Always ensure there is no obstruction or entanglement before pulling on the cable.

5. PostUse Care:

- After use, detach the carabineer clip and store the BUBBA Tether Tool in a dry place.
- Regularly clean the tool with a damp cloth to remove dirt and debris.

Disposal Instructions

- Dispose of the BUBBA Tether Tool in accordance with local regulations.
- Do not dispose of the tool in regular household waste if it contains any hazardous materials.
- Consider recycling the aluminum components where facilities exist.

Contact Information for Further Support

For any safety inquiries or product support, please contact your local BUBBA representative or authorized dealer. Ensure you have your product details ready for assistance.

By following these guidelines, you can ensure your safety and the effective use of the BUBBA Tether Tool. Thank you for your attention to safety. Enjoy your time on the water!

Säkerhetsinstruktioner för BUBBA Tether Tool

Introduktion

Tack för att du valt BUBBA Tether Tool. Denna produkt är designad för att hålla dina klippare och tänger nära till hands när du är på vattnet. För att säkerställa en säker och effektiv användning av produkten, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd produkten endast för sitt avsedda syfte.
- Kontrollera produkten regelbundet för skador eller slitage innan användning.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Vid användning av produkten, se till att du är medveten om din omgivning för att förhindra olyckor.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Kontrollera att karbinhaken är ordentligt fastsatt innan du använder den.
- Använd endast den medföljande 36" Dyneemakabeln för att undvika brister i säkerhet.
- Om produkten skadas, sluta använda den omedelbart och överväg att byta ut den.
- Undvik att använda produkten i extremt väder eller under ogynnsamma förhållanden.

Instruktioner för installation och användning

1. Installation av karbinhake:

- Fäst karbinhaken på ett stabilt och säkert ställe, såsom en båt eller en väst.
- Se till att karbinhaken är ordentligt låst innan du fortsätter.

2. Användning av Dyneemakabel:

- Dra försiktigt ut 36" kabeln för att nå din utrustning.
- Se till att kabeln inte är vriden eller trasslad under användning.
- Vid behov, återför kabeln till sin ursprungliga position när den inte används.

3. Underhåll:

- Rengör produkten med en fuktig trasa efter användning för att ta bort smuts och saltvatten.
- Förvara produkten på en torr plats för att förhindra korrosion.

Bortskaffande av instruktioner

- Bortskafte produkten på ett miljövänligt sätt i enlighet med lokala föreskrifter.
- Om produkten är skadad eller inte längre används, se till att den inte kan användas av barn eller andra oskyddade individer.

Kontaktinformation för vidare stöd

För frågor om produkten eller säkerhetsrelaterade ärenden, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens modell och serienummer tillgängliga för snabbare hjälp.

Tack för att du noggrant följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.