

Knife Sharpener - Clam

Never have another dull moment with our on the go, easily accessible knife sharpener. Always be prepared with ceramic and carbide sharpeners and a Torx driver to ensure your blades will always be in peak condition.

NO IMAGE
AVAILABLE

Attributes

- Name: Knife Sharpener - Clam
- Manufacturer: M&P
- Product no.: EU1001701
- Mfr. No.: 1117198
- Color: Black
- Delivery weight: 0.62kg
- UPC: 661120081142

Table of Contents

- [Startpage](#)
- [English: M&P Knife Sharpener Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P Knivslipare](#)

M&P Knife Sharpener Safety Instructions

Introduction

Thank you for choosing the M&P Knife Sharpener. This product is designed to keep your knives in optimal condition, ensuring safe and effective use. Please read this safety instruction guide carefully to understand how to use the sharpener safely and effectively.

General Safety Guidelines

- Always use the knife sharpener in a welllit area to avoid accidents.
- Keep the sharpener out of reach of children and vulnerable individuals.
- Do not use the sharpener for any purpose other than sharpening knives.
- Inspect the sharpener before each use. Do not use it if any part is damaged.
- Follow the manufacturer's instructions for use to ensure safety and effectiveness.

Specific Safety Precautions for Use

- **Sharp Edges:** The sharpeners included in this product can create sharp edges. Handle with care to avoid cuts.
- **Personal Protective Equipment:** Consider wearing cutresistant gloves while sharpening to protect your hands.
- **Stable Surface:** Always use the sharpener on a stable surface to prevent slipping during use.
- **Avoid Contact with Water:** Do not expose the sharpener to water or moisture, as this may affect its performance.

Instructions for Installation and Usage

1. Preparation:

- Ensure the sharpener is clean and dry before use.
- Place the sharpener on a flat, stable surface.

2. Using the Ceramic and Carbide Sharpeners:

- Hold the knife firmly by the handle.
- Position the blade against the ceramic or carbide sharpener at the recommended angle (typically 20 degrees).
- Draw the blade through the sharpener from heel to tip, applying light pressure.
- Repeat this process 35 times on each side of the blade for optimal sharpening.

3. Using the Tapered Diamond Honing Stone:

- Use the honing stone to refine the edge of the blade after sharpening.
- Hold the knife at the same angle and draw it along the honing stone, repeating 35 times on both sides.

4. Using the T8 Torx Driver:

- The Torx driver is included for maintenance purposes. Use it to tighten or adjust any screws on the sharpener as needed.

Disposal Instructions

- Dispose of the knife sharpener responsibly at the end of its life cycle.
- Check local regulations for proper disposal methods, as some components may require special handling.

Contact Information for Further Support

For safety inquiries or further assistance, please contact the manufacturer directly. Ensure you have your product details ready for a more efficient response.

Thank you for your attention to these safety instructions. Enjoy using your M&P Knife Sharpener responsibly!

Säkerhetsinstruktioner för M&P Knivslipare

Introduktion

Tack för att du valt M&P Knivslipare. Denna produkt är designad för att ge dig en effektiv och säker slipupplevelse. För att säkerställa säker användning och långvarig prestanda, vänligen läs noggrant igenom dessa säkerhetsinstruktioner.

Allmänna säkerhetsriktlinjer

- Använd alltid knivsliparen i enlighet med tillverkarens instruktioner.
- Håll knivsliparen utom räckhåll för barn och sårbara grupper.
- Kontrollera alltid att knivsliparen är i gott skick innan användning.
- Använd inte knivsliparen om den är skadad eller om några delar saknas.
- Rapportera eventuella skador eller defekter omedelbart.

Specifika säkerhetsåtgärder vid användning

- Använd endast knivsliparen för det avsedda ändamålet, dvs. slipning av knivar.
- Undvik kontakt med slipytorna när de är i bruk för att förhindra skador.
- Håll fingrar och andra kroppsdelar borta från slipytorna under användning.
- Använd skyddsglasögon om det behövs för att skydda ögonen mot skräp.
- Se till att knivarna är rena och torra innan slipning för bästa resultat.

Instruktioner för installation och användning

1. Förberedelse:

- Placera knivsliparen på en stabil och plan yta.
- Kontrollera att området är rent och fritt från hinder.

2. Slipning av knivar:

- Välj rätt slipare (keramisk eller karbid) beroende på knivens material och skick.
- För in knivbladet i slipöppningen och dra det långsamt mot dig med jämnt tryck.
- Upprepa processen 35 gånger beroende på hur slö kniven är.
- Använd den avsmalnande diamant slipstenen för att finslipa knivens egg.

3. Användning av Torx skruvmejsel:

- Använd den medföljande T8 Torx skruvmejseln för att justera eller byta ut delar på knivsliparen om så behövs.

4. Avsluta användningen:

- Rengör knivsliparen efter användning för att ta bort slipdamm och skräp.
- Förvara knivsliparen på en torr och säker plats.

Avfallsinstruktioner

- När knivsliparen når slutet av sin livslängd, avlägsna alla komponenter och sortera dem enligt lokala återvinningsföreskrifter.
- Om produkten är defekt eller skadad, se till att den hanteras på ett säkert sätt för att undvika skador.

Kontaktinformation för vidare support

För frågor eller mer information, vänligen kontakta M&P:s kundservice. Det finns en EUbaserad kontakt för säkerhetsfrågor relaterade till produkten.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet!