

Sear Spring Assist Folding Knife - Clam

As smooth and polished as a custom trigger, the M&P® Sear springs into action with just a touch of the index flipper.

NO IMAGE
AVAILABLE

Attributes

- Name: M&P Sear Spring Assist Folding Knife - Clam
- Manufacturer: M&P
- Product no.: EU1001705
- Mfr. No.: 1117203
- Color: Black
- Delivery weight: 0.66kg
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: M&P Sear Spring Assist Folding Knife Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P Sear Spring Assist Folding Knife](#)

M&P Sear Spring Assist Folding Knife Safety Instruction Guide

Introduction

Thank you for purchasing the M&P Sear Spring Assist Folding Knife. This guide provides essential safety instructions to ensure safe and effective use of your knife. Please read this guide carefully and keep it for future reference.

General Safety Guidelines

- Always handle the knife with care.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use for any damage or defects.
- Use the knife only for its intended purpose.
- Store the knife in a safe place when not in use.
- Follow local laws and regulations regarding knife ownership and carry.

Specific Safety Precautions for Use

- **Cutting Surface:** Always use a stable cutting surface to prevent slipping.
- **Opening Mechanism:** Use the index flipper gently to open the knife. Avoid using excessive force.
- **Blade Handling:** Always handle the blade by the handle, keeping your fingers away from the cutting edge.
- **Closing the Knife:** Ensure your fingers are clear of the blade when closing the knife. Use the finger flipper to assist in closing.
- **TipDown Pocket Clip:** Ensure that the pocket clip is securely attached to your pocket or bag to prevent accidental drops.
- **Environmental Conditions:** Do not use the knife in wet or slippery conditions to avoid accidents.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly by the handle.
- Use your index finger to press the flipper gently.
- The blade will spring open. Ensure your fingers are clear of the blade path.

2. Using the Knife:

- Position the knife on the cutting surface.
- Apply light pressure to cut through materials.
- Do not force the knife through tough materials to avoid damaging the blade.

3. Closing the Knife:

- Hold the knife by the handle.
- Use the finger flipper to assist in closing the blade.
- Ensure your fingers are away from the blade edge while closing.

4. Storage:

- Store the knife in a dry place.

- Use a protective sheath or case if available.
- Keep the knife out of reach of children.

Disposal Instructions

- Dispose of the knife responsibly in accordance with local regulations.
- If the knife is damaged or nonfunctional, consider recycling the metal components where possible.
- Ensure the blade is covered or secured to prevent injury during disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding your M&P Sear Spring Assist Folding Knife, please refer to the contact information provided with your product packaging or visit the manufacturer's website.

Conclusion

Your safety is our priority. By following these guidelines, you can ensure a safe and enjoyable experience with your M&P Sear Spring Assist Folding Knife. Always stay informed about safety updates and recall information through the EU's Safety Gate platform. Thank you for choosing M&P.

Säkerhetsinstruktioner för M&P Sear Spring Assist Folding Knife

Introduktion

Tack för att du valt M&P Sear Spring Assist Folding Knife. Denna kniv är designad för att ge användaren en säker och effektiv upplevelse. För att säkerställa att du använder produkten på rätt sätt och för att minimera risken för olyckor, vänligen läs dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert sätt och i enlighet med instruktionerna.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage.
- Om kniven skadas, sluta använda den omedelbart och kontakta tillverkaren för råd.
- Rapportera eventuella farliga produkter eller olyckor till behöriga myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven på en stabil yta och undvik att använda den i rörliga situationer.
- Håll fingrarna borta från bladet när du öppnar eller stänger kniven.
- Använd kniven endast för avsett ändamål; undvik att använda den som en verktyg för andra syften.
- Använd skyddshandskar om du är osäker på din förmåga att hantera kniven säkert.
- Se till att kniven är låst i stängt läge när den inte används.

Instruktioner för installation och användning

- För att öppna kniven, tryck på indexflippern med tummen för att aktivera fjäderassisterad öppning.
- För att stänga kniven, tryck på låsmekanismen och stäng bladet försiktigt.
- Kontrollera att kniven är i låst läge innan du förvarar den.
- För att fästa fickklämman, använd den medföljande skruven för att säkerställa att klämman sitter fast ordentligt.
- Använd kniven med försiktighet och undvik att rikta bladet mot dig själv eller andra.

Avfallshanteringsinstruktioner

- När kniven når slutet av sin livslängd eller är skadad, se till att den kasseras på ett säkert sätt.
- Följ lokala riktlinjer för avfallshantering för metallprodukter.
- Om möjligt, återvinna kniven enligt gällande regler för materialåtervinning.

Kontaktinformation för ytterligare stöd

För frågor eller säkerhetsärenden, vänligen kontakta tillverkaren direkt. Se förpackningen eller produktens dokumentation för kontaktinformation.

Tack för att du bidrar till en säkrare användning av produkter genom att följa dessa riktlinjer.