

Drive Folding Knife - Clam

Always be prepared with the Smith & Wesson® Drive Folding Knife. The high-carbon blade is perfect for all your daily cutting tasks. Its keychain accessibility and integral bottle opener makes sure you're always hydrated wherever you are.

NO IMAGE
AVAILABLE

Attributes

- Name: Drive Folding Knife - Clam
- Manufacturer: M&P
- Product no.: EU1001713
- Mfr. No.: 1117229
- Color: Light Grey
- Delivery weight: 0.51kg
- UPC: 661120081135

Table of Contents

- [Startpage](#)
- [English: M&P Drive Folding Knife Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P Drive Folding Knife](#)

M&P Drive Folding Knife Safety Instruction Guide

Introduction

Thank you for choosing the Smith & Wesson® Drive Folding Knife. This guide provides essential safety instructions to ensure safe usage of your knife. Please read this manual carefully before using the product to understand the risks and precautions associated with it.

General Safety Guidelines

- Always handle the knife with care to avoid accidental cuts or injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in proper working condition.
- Do not use the knife for purposes other than its intended use, such as prying or as a screwdriver.
- Ensure that the blade is locked in place before using it to prevent accidental closure.
- Store the knife in a safe location when not in use to prevent accidents.
- Report any unsafe conditions or malfunctions to the appropriate authorities.

Specific Safety Precautions for Use

- **Blade Handling:**
 - Always cut away from your body.
 - Use the finger flipper to safely open the blade.
- **Keychain Accessibility:**
 - Ensure that the knife is securely attached to your keychain to prevent it from falling or being lost.
- **Bottle Opener Use:**
 - Use the bottle opener feature only for its intended purpose. Avoid using excessive force.
- **Maintenance:**
 - Regularly clean and lubricate the blade to maintain optimal performance and safety.
 - Avoid exposure to moisture to prevent rust on the stainless steel blade.
- **Emergency Situations:**
 - Be aware of your surroundings when using the knife, especially in crowded or confined spaces.

Instructions for Installation and Usage

1. Opening the Knife:

- To open the knife, use the finger flipper located on the blade. Ensure your fingers are clear of the blade path.

2. Using the Knife:

- Hold the knife securely by the handle.

- Use the blade for cutting tasks only, such as opening packages or cutting rope.

3. Closing the Knife:

- To close the knife, press the locking mechanism and gently fold the blade back into the handle.
- Ensure the blade is fully retracted and locked before storing.

4. Using the Bottle Opener:

- Position the bottle opener on the cap of the bottle.
- Apply downward pressure to remove the cap safely.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged or no longer usable, consider recycling the metal parts where possible.
- Follow local regulations regarding the disposal of sharp objects to prevent injury to waste management personnel.

Contact Information for Further Support

For safety inquiries or to report unsafe products, please contact the appropriate EUBased contact point. Ensure you have the product details ready for efficient assistance.

Thank you for adhering to these safety guidelines. Your safety is our priority, and we hope you enjoy using your M&P Drive Folding Knife responsibly.

Säkerhetsinstruktioner för M&P Drive Folding Knife

Introduktion

Tack för att du valt Smith & Wesson® Drive Folding Knife. Denna kniv är designad för att vara ett pålitligt verktyg för dina dagliga skäruppgifter. För att säkerställa säker användning, vänligen läs igenom och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till myndigheterna.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd endast kniven för dess avsedda syfte.
- Undvik att använda kniven på hårda ytor som kan skada bladet.
- Håll kniven ren och torr för att förhindra rost och skador.
- Stäng alltid kniven när den inte används för att undvika oavsiktliga skador.
- Använd fingerflippare på ett korrekt sätt för att öppna kniven.

Instruktioner för installation och användning

1. **Öppning av kniven:**
 - Använd fingerflippare för att öppna kniven. Se till att fingrarna är borta från bladet.
2. **Användning av flasköppnare:**
 - Kniven är utrustad med en integrerad flasköppnare. Använd denna funktion försiktigt för att undvika skador.
3. **Stängning av kniven:**
 - För att stänga kniven, tryck på låsmekanismen och vik bladet tillbaka in i handtaget.
4. **Förvaring:**
 - Förvara kniven på en säker plats, bortom räckhåll för barn och djur.

Avfallsinstruktioner

- När kniven inte längre är användbar, se till att den kasseras på ett säkert sätt.
- Kontakta lokala myndigheter för information om korrekt avfallshantering.

Kontaktinformation för ytterligare stöd

För frågor eller säkerhetsrelaterade bekymmer, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens information till hands för snabbare hjälp.

Tack för att du bidrar till en säker användning av M&P Drive Folding Knife. Din säkerhet är vår prioritet!