

Benji Folding Knife - Clam

Perfect for your discreet EDC, this knife packs big features in a small package. This all-in-one pocket knife, money clip, and bottle opener fits cleanly into the coin pocket of your favorite jeans so you're always prepared.

NO IMAGE
AVAILABLE

Attributes

- Name: Benji Folding Knife - Clam
- Manufacturer: M&P
- Product no.: EU1001714
- Mfr. No.: 1117230
- Color: Black
- Delivery weight: 0.59kg
- UPC: 661120081326

Table of Contents

- [Startpage](#)
- [English: M&P Benji Folding Knife Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P Benji Folding Knife](#)

M&P Benji Folding Knife Safety Instruction Guide

Introduction

Thank you for choosing the M&P Benji Folding Knife. This versatile tool is designed for everyday carry (EDC) and offers multiple functions, including a pocket knife, money clip, and bottle opener. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in proper working condition.
- Use the knife only for its intended purpose. Do not use it as a pry bar or for any other unintended applications.
- Store the knife in a safe location when not in use, preferably in a sheath or protective case.
- Be aware of your surroundings when using the knife to avoid accidental injury to yourself or others.
- If you experience any difficulty with the knife, do not attempt to disassemble it. Contact a qualified professional for assistance.

Specific Safety Precautions for Use

- When opening or closing the knife, keep your fingers away from the blade to prevent cuts.
- Ensure that the knife is securely locked in place before use. Check the frame lock mechanism to confirm it is engaged.
- Use the tipup pocket clip to securely attach the knife to your pocket or belt, ensuring it does not fall out or become a hazard.
- Avoid using the knife in wet or slippery conditions, as this may increase the risk of accidental slips and injuries.
- Do not attempt to modify the knife or its components, as this may compromise its safety and functionality.

Instructions for Installation and Usage

1. Opening the Knife:

- Grip the handle firmly.
- Use your thumb to push on the thumb stud or flipper to open the blade. Ensure your fingers are clear of the blade path.

2. Using the Knife:

- Hold the knife securely by the handle.
- Use the blade for cutting tasks only. Do not apply excessive force that may cause the blade to slip.

3. Closing the Knife:

- Ensure the knife is not in use and that the area is clear.
- Press the frame lock to release the blade.
- Carefully fold the blade back into the handle, keeping fingers clear of the blade path.

4. Attaching the Pocket Clip:

- Position the pocket clip on the desired side of the knife handle.
- Secure it in place using the provided screws, ensuring it is tight and stable.

Disposal Instructions

- Dispose of the knife responsibly in accordance with local regulations.
- If the knife is damaged or no longer usable, consider recycling the metal components if possible.
- Do not dispose of the knife in regular household waste to prevent injury to waste handlers.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P Benji Folding Knife, please contact the manufacturer or your local distributor. Ensure that you have the product details at hand for a more efficient response.

Thank you for following these safety instructions. Enjoy the versatility and convenience of your M&P Benji Folding Knife!

Säkerhetsinstruktioner för M&P Benji Folding Knife

Introduktion

Tack för att du valt M&P Benji Folding Knife. Denna kniv är designad för att vara en mångsidig och praktisk följeslagare i din vardag. För att säkerställa en trygg och säker användning av produkten, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett säkert och ansvarsfullt sätt.
- Håll kniven utom räckhåll för barn och sårbara personer.
- Kontrollera kniven regelbundet för skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till myndigheterna.
- Håll dig informerad om produktåterkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven i en kontrollerad miljö, fri från distraktioner.
- Se till att knivens blad är korrekt låst innan användning.
- Undvik att rikta kniven mot dig själv eller andra.
- Använd kniven för dess avsedda ändamål; undvik att använda den för uppgifter som kan orsaka skador.
- Förvara kniven på en säker plats när den inte används.

Instruktioner för installation och användning

1. Öppna kniven:

- Tryck på ramlåset för att frigöra bladet.
- Fäll ut bladet tills det är helt utsträckt och lås det på plats.

2. Användning:

- Håll kniven i ett fast grepp.
- Skär alltid bort från kroppen och andra personer.
- Använd kniven på en stabil yta för bästa kontroll.

3. Stänga kniven:

- Tryck på ramlåset för att frigöra bladet.
- Fäll bladet tillbaka in i handtaget tills det klickar på plats.

Avfallshantering

- Avfallshantering av kniven bör ske enligt lokala föreskrifter.
- Om kniven är skadad eller inte längre säker att använda, vänligen hantera den som farligt avfall.
- Återvinn materialet där det är möjligt.

Kontaktinformation för vidare support

För frågor eller ytterligare information, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens modell och serienummer tillgängligt för snabbare hjälp.

Tack för att du valt M&P Benji Folding Knife. Vi önskar dig en säker och tillfredsställande användning av vår produkt!