

Sideburn Folding Knife - Clam

Don't let the lightweight and sleek design fool you from thinking it's your ordinary everyday knife, this EDC has a Modified Warncliffe blade giving it an edge above all the rest.

NO IMAGE
AVAILABLE

Attributes

- Name: Sideburn Folding Knife - Clam
- Manufacturer: M&P
- Product no.: EU1001719
- Mfr. No.: 1117235
- Color: Black/Gray
- Delivery weight: 0.62kg
- UPC: 661120081173

Table of Contents

- [Startpage](#)
- [English: M&P Sideburn Folding Knife Safety Instructions](#)
- [Svenska: M&P Sideburn Folding Knife Säkerhetsinstruktioner](#)

M&P Sideburn Folding Knife Safety Instructions

Introduction

Thank you for choosing the M&P Sideburn Folding Knife. This guide provides essential safety instructions to ensure the safe and effective use of your knife. Please read this document carefully before using the product.

General Safety Guidelines

- Always keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife before each use to ensure it is in proper working condition.
- Use the knife only for its intended purpose; do not use it for cutting materials that may cause damage to the blade or pose a safety risk.
- If the knife is damaged or malfunctioning, discontinue use immediately and seek assistance.
- Follow all local laws and regulations regarding knife ownership and use.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the knife is fully opened and locked in place before use.
- Always cut away from your body and keep your fingers clear of the blade path.
- Do not attempt to catch or grab the knife if it slips from your grip.
- Avoid using the knife in wet or slippery conditions to prevent accidents.
- Store the knife in a secure location when not in use, preferably in a sheath or protective case.
- Be cautious when using the finger flipper; ensure your fingers are clear of the blade when deploying.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly by the handle.
- Use the finger flipper to deploy the blade. Ensure that your fingers are clear of the blade's path.
- Confirm that the blade is locked in place before use.

2. Using the Knife:

- Use the knife for cutting tasks as intended.
- Maintain a firm grip on the handle while cutting.
- If you need to stop using the knife, carefully close it by pressing the release mechanism and folding the blade back into the handle.

3. Cleaning and Maintenance:

- Clean the blade with a soft cloth after each use to prevent rust and maintain sharpness.
- Avoid using harsh chemicals or abrasive materials that could damage the knife.
- Regularly check for signs of wear or damage, particularly on the blade and locking mechanism.

Disposal Instructions

- Dispose of the knife in a manner that prevents accidental injury to others.
- If the knife is damaged beyond repair, consider recycling the metal parts if possible.
- Follow local regulations for the disposal of sharp objects.

Contact Information for Further Support

For safety inquiries or additional support regarding your M&P Sideburn Folding Knife, please contact the appropriate EUbased contact point.

Thank you for taking the time to read these safety instructions. Your safety is our priority. Enjoy using your M&P Sideburn Folding Knife responsibly!

M&P Sideburn Folding Knife

Säkerhetsinstruktioner

Introduktion

Tack för att du valt M&P Sideburn Folding Knife. Denna kniv är designad för att ge användaren en säker och effektiv upplevelse. Vänligen läs dessa säkerhetsinstruktioner noggrant innan du använder produkten för att säkerställa korrekt och säker användning.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt sätt.
- Förvara kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage.
- Använd kniven endast för dess avsedda syfte.
- Rapportera eventuella farliga produkter eller olyckor till myndigheterna.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med försiktighet och undvik att skära mot kroppen.
- Håll kniven i ett fast grepp för att undvika olyckor.
- Använd fingerflippern för att öppna kniven på ett säkert sätt.
- Var försiktig när du stänger kniven; se till att fingrarna är borta från bladets väg.
- Undvik att använda kniven i fuktiga eller hala miljöer för att förhindra att den glider ur handen.

Instruktioner för installation och användning

1. Öppna kniven genom att använda fingerflippern. Se till att kniven är riktad bort från dig.
2. Kontrollera att bladet är helt utsträckt och låst i öppet läge innan du använder kniven.
3. Använd kniven för skärande uppgifter där den är avsedd, som att skära rep eller öppna förpackningar.
4. När du är klar med användningen, stäng kniven genom att trycka på låsmekanismen och fäll tillbaka bladet.
5. Förvara kniven på en säker plats, helst i ett fodral eller en låda, för att förhindra olyckor.

Avfallshanteringsinstruktioner

- Kniven ska inte kasseras med hushållsavfall.
- När kniven har blivit oanvändbar, se till att den kasseras på ett säkert sätt för att förhindra skador på andra.
- Kontakta lokala avfallshanteringsmyndigheter för korrekt avfallshantering av metallprodukter.

Kontaktinformation för vidare support

För frågor eller support angående säkerhet och användning av M&P Sideburn Folding Knife, vänligen kontakta din lokala återförsäljare eller besök tillverkarens officiella webbplats för mer information.

Tack för att du följer dessa säkerhetsinstruktioner och för att du använder M&P Sideburn Folding Knife på ett säkert sätt.