

Quick Release Baton, 24" - BOX - Quick Release Baton, 21" - BOX

This steel construction baton enables you to always be at the ready. With push button collapsing, it is easy to deploy and retract. The baton easily collapses into a compact size for easy carrying and a rapid deployment.

NO IMAGE
AVAILABLE

Attributes

- Name: Quick Release Baton, 21" - BOX
- Manufacturer: M&P
- Product no.: EU1001725
- Mfr. No.: 1117242
- Delivery weight: 2.5kg
- UPC: 661120081180

Table of Contents

- [Startpage](#)
- [English: M&P Quick Release Baton Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för M&P Quick Release Baton](#)

M&P Quick Release Baton Safety Instruction Guide

Introduction

Thank you for choosing the M&P Quick Release Baton. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your baton. Please read this manual thoroughly before use to familiarize yourself with the product and its features.

General Safety Guidelines

- Ensure the baton is stored in a secure location, away from children and unauthorized users.
- Always inspect the baton for any signs of damage or wear before use.
- Use the baton only for its intended purpose as a selfdefense tool.
- Avoid using the baton in a manner that could cause harm to yourself or others.
- Be aware of your surroundings and ensure that you are in a safe environment when deploying the baton.
- Follow all local laws and regulations regarding the possession and use of selfdefense tools.

Specific Safety Precautions for Use

- Always keep your fingers away from the push button when not in use to prevent accidental deployment.
- Use the rubberized grip to maintain a secure hold on the baton during use.
- Do not force the baton to collapse if it does not deploy or retract smoothly; check for obstructions or damage.
- Avoid striking hard surfaces or objects that could damage the baton or cause injury.
- If you experience any difficulty with the baton, discontinue use immediately and seek assistance.

Instructions for Installation and Usage

1. Deployment:

- To deploy the baton, locate the push button on the handle.
- Press the button firmly to extend the baton to its full length.
- Ensure that the baton is fully extended and locked in place before use.

2. Retracting:

- To retract the baton, press the push button again.
- Allow the baton to collapse fully before storing it.
- Ensure that your fingers are clear of the collapsing mechanism to avoid injury.

3. Carrying:

- The baton collapses into a compact size for easy carrying.
- Store the baton in a secure pouch or holster when not in use.

Disposal Instructions

- Dispose of the baton in accordance with local regulations.
- If the baton is damaged beyond repair, ensure that it is disposed of in a manner that prevents any potential harm to others.
- Do not dispose of the baton in regular household waste; check for recycling options specific to metal products.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the manufacturer's contact details provided with the product packaging or on the manufacturer's website.

Thank you for your attention to these safety guidelines. Your safety and the safety of others is our priority. Enjoy the reliable performance of your M&P Quick Release Baton.

Säkerhetsinstruktioner för M&P Quick Release Baton

Introduktion

Tack för att du valt M&P Quick Release Baton. Denna batong är utformad för att vara lättanvänd och praktisk, med en konstruktion i stål och funktioner som gör den säker att använda. För att säkerställa en trygg och säker användning av produkten är det viktigt att följa dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid batongen enligt tillverkarens instruktioner för att minimera riskerna för skador.
- Håll batongen utom räckhåll för barn och andra sårbara grupper.
- Kontrollera alltid batongen för skador innan användning. Använd inte en skadad batong.
- Rapportera omedelbart eventuella skador eller defekter till tillverkaren.
- Bekanta dig med lokala lagar och förordningar angående användning av batonger.

Specifika säkerhetsåtgärder vid användning

- Använd alltid ett fast grepp om det gummibelagda handtaget för att förhindra att batongen glider ur handen.
- Fäll inte ut batongen i trånga utrymmen där den kan orsaka skador på dig själv eller andra.
- Använd batongen endast i avsedda situationer och undvik att använda den som ett leksak.
- Var medveten om din omgivning och undvik att använda batongen i situationer som kan leda till oavsiktlig skada.

Instruktioner för installation och användning

1. **Uppackning:** Ta försiktigt bort batongen från förpackningen. Kontrollera att alla delar är intakta.
2. **Uppfällning:**
 - Håll batongen med ena handen vid handtaget.
 - Tryck på tryckknappen för att fälla ut batongen. Se till att den är helt utfälld innan du använder den.
3. **Ihopvikning:**
 - När du är klar med användningen, tryck på tryckknappen igen för att fälla ihop batongen.
 - Vik ihop batongen till en kompakt storlek för enkel transport.
4. **Transport:** Förvara batongen i en säker plats när den inte används för att förhindra oavsiktlig användning.

Avfallshantering

- När batongen når slutet av sin livslängd, se till att den kasseras på ett miljövänligt sätt.
- Kontakta din lokala avfallshantering för riktlinjer om hur du ska kassera metallprodukter på rätt sätt.

Kontaktinformation för ytterligare support

För frågor eller rapportering av osäkra produkter, vänligen kontakta tillverkaren. Mer information finns på tillverkarens officiella webbplats.

Viktigt att komma ihåg

- Denna produkt är designad för att användas av vuxna och bör inte användas av barn.
- Håll dig informerad om eventuella återkallelser eller säkerhetsuppdateringar via EU:s Safety

Gateplattform.

Tack för att du tar dig tid att läsa igenom dessa säkerhetsinstruktioner. Genom att följa dem bidrar du till en säker och effektiv användning av din M&P Quick Release Baton.