

SCH 12" Axe Box

- 3CR13 STEEL BLADE, GLASS FIBER NYLON HANDLE
- Lightweight
- Lanyard hole
- Sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: SCH 12" Axe Box
- Manufacturer: Shrade
- Product no.: EU1001733
- Mfr. No.: 1121076
- Color: Black, Brown
- Delivery weight: 1.06kg
- UPC: 661120081494

Table of Contents

- [Startpage](#)
- [English: Shrade SCH 12" Axe Box Safety Instructions](#)
- [Svenska: Säkerhetsanvisningar för Shrade SCH 12" Axe Box](#)

Shrade SCH 12" Axe Box Safety Instructions

Introduction

Thank you for choosing the Shrade SCH 12" Axe Box. This safety instruction guide is designed to provide you with essential information for the safe use, handling, and disposal of your axe. Please read this guide carefully before using the product to ensure a safe and enjoyable experience.

General Safety Guidelines

- Always handle the axe with care to avoid injury.
- Keep the axe out of reach of children and vulnerable individuals.
- Inspect the axe for any damage or defects before use.
- Use the axe only for its intended purpose.
- Wear appropriate personal protective equipment (PPE), such as gloves and safety goggles, when using the axe.

Specific Safety Precautions for Use

- Ensure you have a stable and secure stance before swinging the axe.
- Always cut away from your body and keep your hands and feet clear of the cutting path.
- Do not use the axe if you are under the influence of drugs or alcohol.
- Be aware of your surroundings and ensure that no one is in the vicinity when using the axe.
- Do not attempt to catch a falling axe; let it fall to the ground.
- Store the axe in a safe place, preferably in its sheath, when not in use.

Instructions for Installation and Usage

1. **Unboxing:** Carefully remove the axe from its packaging. Inspect the axe for any visible damage.
2. **Sheath Usage:** Always use the included sheath to cover the blade when the axe is not in use. This will help prevent accidental cuts and injuries.
3. **Grip:** Hold the axe firmly by the handle. Ensure your grip allows for control and precision.
4. **Cutting Technique:**
 - Position the target securely before cutting.
 - Swing the axe in a controlled manner, using your body weight for added force.
 - Follow through with your swing but maintain balance and control.
5. **Cleaning:** After use, clean the axe with a damp cloth to remove debris. Dry thoroughly to prevent rust.
6. **Storage:** Store the axe in a cool, dry place, preferably in its sheath, to protect the blade and handle.

Disposal Instructions

- Dispose of the axe responsibly at a designated waste disposal facility or recycling center.
- Ensure that the axe is secured and cannot cause injury during transport to the disposal site.
- Follow local regulations regarding the disposal of tools and sharp objects.

Contact Information for Further Support

For any safety inquiries or further support, please reach out to the manufacturer or your local retailer.

By following these guidelines, you can ensure your safety and the longevity of your Shrade SCH 12" Axe Box. Thank you for your attention to safety!

Säkerhetsanvisningar för Shrade SCH 12" Axe Box

Introduktion

Tack för att du valt Shrade SCH 12" Axe Box. Denna guide innehåller viktiga säkerhetsanvisningar och riktlinjer för korrekt användning av produkten. Vänligen läs noggrant igenom dessa anvisningar för att säkerställa en säker och effektiv användning.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med tillverkarens instruktioner.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Inspektera produkten innan varje användning för att säkerställa att den är i gott skick.
- Rapportera eventuella skador eller defekter till tillverkaren.
- Kontrollera regelbundet EU:s Safety Gateplattform för eventuella återkallelser.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar och skyddsglasögon vid användning av yxan.
- Undvik att använda yxan i blöta eller hala förhållanden.
- Använd inte yxan för att slå på hårda ytor som betong eller metall.
- Håll alltid yxan med båda händerna för bättre kontroll.
- Skär aldrig mot dig själv eller andra.
- Förvara yxan på en säker plats efter användning för att förhindra olyckor.

Instruktioner för installation och användning

1. Förberedelse:

- Kontrollera att yxan är i gott skick och att det inte finns några synliga skador.
- Se till att arbetsområdet är rent och fritt från hinder.

2. Användning:

- Håll yxan med båda händerna, en hand på handtaget och den andra nära bladet för bättre kontroll.
- Utför snitt med en jämn och kontrollerad rörelse.
- Undvik att använda yxan för att hacka eller slå på föremål.

3. Avslutning:

- När du är klar med arbetet, rengör yxan från smuts och skräp.
- Torka av bladet med en torr trasa för att förhindra rost.
- Förvara yxan i det medföljande fodralet för att skydda bladet och förhindra olyckor.

Avfallsanvisningar

- Kassera produkten enligt lokala bestämmelser för avfallshantering.
- Återvinn eventuella delar som kan återvinnas, såsom metall och plast, i enlighet med lokala riktlinjer.

Kontaktinformation för ytterligare stöd

För frågor eller mer information om produkten, vänligen kontakta tillverkaren eller besök deras officiella webbplats. Se till att ha produktens modellnummer till hands för snabbare hjälp.

Vi tackar för att du valde Shrade SCH 12" Axe Box och önskar dig en säker och effektiv användning!