

SCH 12" Axe Box - SCH 19.5" Axe Clam

- 3CR13 STEEL BLADE, GLASS FIBER NYLON HANDLE
- Lightweight
- Lanyard hole
- Sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: SCH 19.5" Axe Clam
- Manufacturer: Shrade
- Product no.: EU1001736
- Mfr. No.: 1121079
- Color: Black
- Delivery weight: 1.18kg
- UPC: 661120081524

Table of Contents

- [Startpage](#)
- [English: Shrade SCH 12" Axe & SCH 19.5" Axe Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH 12" Axe och SCH 19.5" Axe](#)

Shrade SCH 12" Axe & SCH 19.5" Axe Safety Instruction Guide

Introduction

Thank you for purchasing the Shrade SCH 12" Axe and SCH 19.5" Axe. This guide provides essential safety instructions to ensure the safe and effective use of your axes. Please read this guide thoroughly before using the product.

General Safety Guidelines

- Always use the axes in a welllit and open area to prevent accidents.
- Keep the axes out of reach of children and unauthorized users.
- Inspect the axes before each use for any signs of damage or wear.
- Always wear appropriate personal protective equipment, such as gloves and safety glasses, when using the axes.
- Be aware of your surroundings and ensure that no one is within the swing radius when using the axes.
- Store the axes in a safe, dry place when not in use, preferably in the included sheath.

Specific Safety Precautions for Use

- **Blade Safety:** The 3CR13 steel blade is sharp. Handle with care to avoid cuts or injuries.
- **Handle Grip:** Ensure a firm grip on the glass fiber nylon handle to prevent slipping during use.
- **Lanyard Hole:** Use the lanyard hole to secure the axe when working at heights or in unstable positions.
- **Sheath Usage:** Always use the sheath when transporting or storing the axes to protect the blade and prevent accidental injuries.

Instructions for Installation and Usage

1. Preparation:

- Ensure the work area is clear of obstacles and bystanders.
- Wear suitable safety gear.

2. Using the Axe:

- Hold the axe firmly by the handle with both hands.
- Position your body to the side of the intended cutting area to avoid potential accidents.
- Swing the axe with controlled force, aiming for the target area.
- Do not use the axe for purposes other than cutting or chopping.

3. PostUse Care:

- Clean the blade after each use to prevent rust and maintain sharpness.
- Dry the axe thoroughly before storing it.
- Inspect the axe for any damage and report any issues if necessary.

Disposal Instructions

- Dispose of the axe according to local regulations.
- If the axe is damaged beyond repair, ensure the blade is properly secured to prevent injury during disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Shrade axes, please contact the manufacturer's customer support team. Ensure you have your product details available for reference.

Conclusion

By following these safety instructions, you can enjoy the functionality of your Shrade SCH 12" and SCH 19.5" Axes while minimizing the risk of accidents. For further information and updates, please check the EU's Safety Gate platform for any recalls or safety alerts related to this product. Thank you for choosing Shrade!

Säkerhetsinstruktioner för Shrade SCH 12" Axe och SCH 19.5" Axe

Introduktion

Tack för att du valt Shrade SCH 12" Axe och SCH 19.5" Axe. Dessa verktyg är designade för att ge hög prestanda och hållbarhet. För att säkerställa en säker och effektiv användning av produkterna, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid axen på ett säkert och ansvarsfullt sätt.
- Håll axen utom räckhåll för barn och andra som inte är utbildade att använda den.
- Inspektera axen före varje användning för att säkerställa att den är i gott skick.
- Använd axen endast för avsedd användning och undvik att använda den för andra ändamål.
- Om du upptäcker några skador eller defekter, sluta använda axen omedelbart och kontakta en expert.

Specifika säkerhetsåtgärder vid användning

- Använd alltid skyddshandskar och skyddsglasögon när du använder axen.
- Säkerställ att arbetsområdet är fritt från hinder och att du har ett fast grepp.
- Håll axen med båda händerna och rikta den bort från kroppen och andra personer.
- Använd axen på en stabil yta och undvik att använda den i ogynnsamma väderförhållanden.
- Var medveten om din omgivning och se till att ingen står i närheten när du arbetar med axen.

Instruktioner för installation och användning

1. Förberedelse:

- Kontrollera att axen är i gott skick och att bladet är vasst.
- Välj en lämplig arbetsyta som är stabil och fri från skräp.

2. Användning:

- Håll axen med båda händerna, en hand på skaftet och den andra nära bladet för bättre kontroll.
- Utför snitt i en kontrollerad och kontrollerad rörelse för att undvika olyckor.
- Om du behöver göra ett snitt, se till att du har ett fast grepp och att du är medveten om din omgivning.

3. Efter användning:

- Rengör axen noggrant efter varje användning för att förhindra rost och slitage.
- Förvara axen på en säker plats, helst i det medföljande fodralet, för att skydda bladet och förhindra olyckor.

Avfallshantering

- Avfallshantering av produkten ska ske i enlighet med lokala föreskrifter.
- Om axen är skadad och inte kan repareras, se till att den kasseras på ett säkert sätt för att förhindra skador på personer eller miljön.

Kontaktinformation för ytterligare support

För frågor eller säkerhetsrelaterade ärenden, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens modellnummer och inköpsinformation tillgänglig för att få bästa möjliga hjälp.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din Shrade SCH 12" Axe och SCH 19.5" Axe. Tack för att du prioriterar säkerhet!