

SCH 12" Axe Box - Shrade SCH 17" Machete Clam

- 3CR13 STEEL BLADE, GLASS FIBER NYLON HANDLE
- Lightweight
- Lanyard hole
- Sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade SCH 17" Machete Clam
- Manufacturer: Shrade
- Product no.: EU1001738
- Mfr. No.: 1121081
- Color: Black, Brown
- Delivery weight: 1.45kg
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Shrade SCH 12" Axe and Shrade SCH 17" Machete](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH 12" Axe och Shrade SCH 17" Machete](#)

Safety Instruction Guide for Shrade SCH 12" Axe and Shrade SCH 17" Machete

Introduction

Thank you for purchasing the Shrade SCH 12" Axe and Shrade SCH 17" Machete. These tools are designed for outdoor use and can be very effective when used correctly. This guide provides important safety instructions to ensure safe handling and usage of these products in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always handle tools with care to prevent accidents and injuries.
- Keep tools out of reach of children and vulnerable individuals.
- Use the tools only for their intended purpose.
- Inspect the tools before each use to ensure they are in good condition.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Blade Safety:**
 - The blades are sharp. Always handle with caution.
 - Do not attempt to touch or clean the blade while it is in use.
- **Lanyard Hole:**
 - Use the lanyard hole to secure the axe or machete when not in use to prevent accidental drops.
- **Sheath Usage:**
 - Always use the included sheath when the tools are not in use to protect the blade and prevent accidental cuts.
- **Personal Protective Equipment (PPE):**
 - Wear appropriate PPE such as gloves and safety goggles when using the axe or machete.
- **Environment:**
 - Use these tools in a clear and safe area, away from people and pets.

Instructions for Installation and Usage

- **Using the Axe:**
 1. Ensure the axe is securely held by the handle.
 2. Stand with your feet shoulderwidth apart for balance.
 3. Swing the axe downwards with controlled force.
 4. Always aim away from your body and others.
- **Using the Machete:**
 1. Grip the handle firmly with both hands.
 2. Use a chopping motion, ensuring you have a clear path.
 3. Avoid using the machete for tasks it is not designed for, such as prying or digging.
- **Storing the Tools:**
 - Store the axe and machete in a dry place, away from moisture.
 - Always keep the tools in their sheaths when not in use.

Disposal Instructions

- Dispose of the axe and machete responsibly when they are no longer usable.
- Follow local regulations for the disposal of sharp objects.

- Consider recycling the materials where applicable.

Contact Information for Further Support

For any inquiries regarding safety or usage of the Shrade SCH 12" Axe and Shrade SCH 17" Machete, please refer to the contact information provided with your product packaging or visit the manufacturer's website for further details.

Thank you for your attention to these safety instructions. Enjoy using your Shrade tools safely and responsibly!

Säkerhetsinstruktioner för Shrade SCH 12" Axe och Shrade SCH 17" Machete

Introduktion

Tack för att du valt Shrade SCH 12" Axe och Shrade SCH 17" Machete. Dessa verktyg är designade för att ge hög prestanda och hållbarhet. För att säkerställa en säker och effektiv användning av produkterna, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkterna enligt tillverkarens anvisningar.
- Håll produkterna utom räckhåll för barn och andra sårbara grupper.
- Inspektera produkterna regelbundet för skador eller slitage. Använd inte skadade verktyg.
- Använd alltid lämplig skyddsutrustning, inklusive handskar och skyddsglasögon, vid användning.
- Förvara verktygen på en säker plats när de inte används, helst i det medföljande fodralet.

Specifika säkerhetsåtgärder för användning

- **Axe och Machete:**
 - Använd aldrig verktygen för att skära genom material som är hårdare än vad de är designade för.
 - Undvik att använda verktygen i trånga utrymmen där det kan vara svårt att manövrera.
 - Var alltid medveten om din omgivning och andra personer när du använder verktygen.
 - Använd inte verktygen om du är trött eller under påverkan av alkohol eller droger.
 - Vid skärning, se till att du har ett stabilt grepp och att du står på en säker yta.

Instruktioner för installation och användning

- **Installation:**
 - Inga speciella installationssteg krävs för dessa verktyg. Se till att de är rena och torra innan användning.
- **Användning:**
 - Håll verktyget med båda händerna för bättre kontroll.
 - Skär alltid bort från kroppen och andra personer.
 - Använd en stabil yta för att utföra skärningar, och se till att inget hinder finns i närheten.
 - Efter användning, rengör verktyget noggrant för att förhindra rost och skador.

Avfallshantering

- När produkten når slutet av sin livslängd, se till att den kasseras på ett miljövänligt sätt.
- Kontrollera lokala riktlinjer för avfallshantering och återvinning av metallprodukter.
- Använd inte produkten om den är skadad eller inte längre fungerar som avsett.

Kontaktinformation för vidare support

För frågor eller säkerhetsinquiries, vänligen kontakta en auktoriserad återförsäljare eller tillverkare. Se till att ha produktens modellnummer och inköpsdatum tillgängligt för snabbare hjälp.

Rapportera osäkra produkter

Om du upptäcker en osäker produkt eller ett olycksfall, rapportera detta till relevanta myndigheter. Håll dig informerad om återkallelser genom EU:s Safety Gateplattform.

Tack för att du följer dessa säkerhetsinstruktioner och bidrar till en säker användning av Shrade SCH 12" Axe och Shrade SCH 17" Machete.