

3.3" Ultraglide Folder Box

- 3CR13 STEEL BLADE, CARBON FIBER & G10 SCALE HANDLE
- Finger flipper
- Dual thumb studs
- Pocket clip
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: 3.3" Ultraglide Folder Box
- Manufacturer: Shrade
- Product no.: EU1001739
- Mfr. No.: 1121082
- Color: Black, Brown
- Delivery weight: 0.78kg
- UPC: 661120081555

Table of Contents

- [Startpage](#)
- [English: Shrade 3.3" Ultraglide Folder Box Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Shrade 3.3" Ultraglide Folder Box](#)

Shrade 3.3" Ultraglide Folder Box Safety Instruction Guide

Introduction

Thank you for choosing the Shrade 3.3" Ultraglide Folder Box. This guide provides essential safety instructions to ensure the safe use and handling of your knife. Please read this document carefully before using the product.

General Safety Guidelines

- Always keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear. Do not use if damaged.
- Use the knife only for its intended purpose. Improper use can lead to accidents.
- Store the knife in a safe place when not in use, preferably in a protective sheath or case.
- Do not attempt to modify or alter the knife in any way.
- Always cut away from your body and ensure that your hands and fingers are clear of the blade's path.
- Be aware of your surroundings when using the knife to avoid accidental injury to yourself or others.

Specific Safety Precautions for Use

- **Blade Handling:**
 - Always handle the blade with care. The 3CR13 steel blade is sharp and can cause injury.
 - Use the finger flipper and dual thumb studs to safely open and close the knife.
- **Carrying the Knife:**
 - When carrying the knife, ensure that the blade is fully closed.
 - Use the pocket clip to secure the knife to your clothing or bag, ensuring it is not at risk of falling out.
- **Environmental Considerations:**
 - Avoid using the knife in wet or slippery conditions to prevent loss of grip.
 - Do not use the knife in situations where it may come into contact with hazardous materials.

Instructions for Installation and Usage

1. Opening the Knife:

- To open the knife, use the finger flipper or dual thumb studs. Ensure your fingers are clear of the blade's path.

2. Using the Knife:

- Hold the knife firmly with one hand.
- Use the other hand to guide the material you are cutting, keeping fingers clear of the blade.
- Always cut away from your body to minimize the risk of injury.

3. Closing the Knife:

- To close the knife, ensure that your fingers are clear of the blade.
- Use the finger flipper or press down on the thumb studs to release the lock and fold the blade back

into the handle.

4. Cleaning and Maintenance:

- After use, clean the blade with a soft cloth to remove any dirt or debris.
- Regularly lubricate the pivot point of the knife to ensure smooth operation.

Disposal Instructions

- When the knife reaches the end of its life or is no longer usable, dispose of it responsibly.
- Do not throw the knife in regular trash. Instead, consider recycling options for metal.
- Ensure the blade is securely wrapped to prevent injury during disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Shrade 3.3" Ultraglide Folder Box, please consult the appropriate contact point as per local regulations. Always ensure you have the latest safety information from the manufacturer or authorized distributors.

By following these safety guidelines, you can enjoy the functionality and quality of your Shrade 3.3" Ultraglide Folder Box while minimizing risks. Thank you for your attention to safety.

Säkerhetsinstruktioner för Shrade 3.3" Ultraglide Folder Box

Introduktion

Tack för att du valt Shrade 3.3" Ultraglide Folder Box. Denna kniv är designad för att ge funktionalitet och säkerhet. För att säkerställa en trygg användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens instruktioner för att undvika olyckor.
- Kontrollera produkten för skador innan användning. Använd inte en skadad kniv.
- Förvara kniven utom räckhåll för barn och sårbara grupper.
- Rapportera eventuella osäkra produkter eller olyckor till berörda myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med försiktighet och se till att du har ett fast grepp.
- Undvik att använda kniven i fuktiga eller hala miljöer för att minska risken för olyckor.
- Använd fingerflippern för att öppna kniven på ett säkert sätt.
- Se till att kniven är helt stängd när den inte används.
- Använd kniven endast för avsett syfte; undvik att använda den som ett verktyg för andra ändamål.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd fingerflippern för att öppna bladet. Tryck lätt med fingret för att frigöra låset.

2. Stäng kniven:

- Tryck på tumstödet och fäll försiktigt bladet tillbaka i handtaget tills det är helt stängt.

3. Förvaring:

- Förvara kniven i ett torrt och säkert utrymme. Använd fickklämman för att fästa kniven på bältet eller i fickan för enkel tillgång.

Avfallshantering

- När kniven har nått slutet av sin livslängd, se till att den hanteras på ett säkert sätt.
- Om kniven är skadad eller inte längre används, överväg att återvinna materialet där det är möjligt.
- Följ lokala riktlinjer för avfallshantering och återvinning av metallprodukter.

Kontaktinformation för vidare support

För frågor eller mer information om säkerheten kring denna produkt, vänligen kontakta tillverkaren eller återförsäljaren där produkten köptes. Kontrollera att det finns en EUbaserad kontakt för säkerhetsfrågor.

Tack för att du läste dessa säkerhetsinstruktioner. Vi hoppas att du får en säker och tillfredsställande upplevelse med din Shrade 3.3" Ultraglide Folder Box.