

3.3" Ultraglide Folder Box - Shrade 3.3" Ultraglide Folder Clam

- 3CR13 STEEL BLADE, CARBON FIBER & G10 SCALE HANDLE
- Finger flipper
- Dual thumb studs
- Pocket clip
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade 3.3" Ultraglide Folder Clam
- Manufacturer: Shrade
- Product no.: EU1001740
- Mfr. No.: 1121083
- Color: Black, Brown
- Delivery weight: 1.18kg
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Shrade 3.3" Ultraglide Folder Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för Shrade 3.3" Ultraglide Folder](#)

Shrade 3.3" Ultraglide Folder Safety Instruction Guide

Introduction

Thank you for choosing the Shrade 3.3" Ultraglide Folder. This guide provides essential safety instructions and guidelines to ensure the safe use of your knife. Please read this manual carefully before using the product.

General Safety Guidelines

- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Use the knife only for its intended purpose.
- Regularly inspect the knife for any signs of damage or wear.
- Report any unsafe conditions or accidents to the relevant authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- When opening the knife, ensure that your fingers are clear of the blade path.
- Use the finger flipper and dual thumb studs to open the knife safely.
- Avoid using excessive force when closing the blade.
- Do not use the knife for prying or as a screwdriver.
- Ensure the blade is locked in place before use.
- Always cut away from your body and keep your other hand clear of the cutting path.
- Store the knife in a safe place when not in use, preferably in a designated sheath or case.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly by the handle.
- Use the finger flipper or one of the dual thumb studs to open the blade.
- Ensure that the blade is fully extended and locked in place before use.

2. Using the Knife:

- Hold the knife securely by the handle.
- Position the blade at the desired angle for cutting.
- Cut with a smooth motion, applying even pressure.

3. Closing the Knife:

- After use, ensure the blade is free from any obstructions.
- Press the locking mechanism to release the blade.
- Carefully fold the blade back into the handle until it clicks into place.

Disposal Instructions

- Dispose of the knife responsibly and in accordance with local regulations.
- If the knife is damaged or no longer usable, consider recycling components where possible.
- Ensure that the blade is safely folded and secured before disposal to prevent injury.

Contact Information for Further Support

For any safety inquiries or additional support regarding the Shrade 3.3" Ultraglide Folder, please contact the manufacturer directly. Ensure you have your product details available for reference.

Thank you for your attention to these safety instructions. Enjoy using your Shrade 3.3" Ultraglide Folder safely and responsibly.

Säkerhetsinstruktioner för Shrade 3.3" Ultraglide Folder

Introduktion

Tack för att du har valt Shrade 3.3" Ultraglide Folder. För att säkerställa en trygg och säker användning av denna produkt, vänligen läs och följ dessa säkerhetsinstruktioner noggrant. Dessa riktlinjer är utformade för att skydda dig och andra, och att hjälpa dig använda produkten på ett korrekt sätt.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Kontrollera alltid produkten före användning för att säkerställa att den är i gott skick.
- Håll produkten utom räckhåll för barn och sårbara personer.
- Rapportera eventuella skador eller defekter till återförsäljaren.
- Var medveten om och följ lokala lagar och förordningar gällande knivar och vapen.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven med bladet riktat bort från kroppen.
- Använd kniven på en stabil och säker yta.
- Undvik att använda kniven i trånga utrymmen eller i situationer där det finns risk för att skada andra.
- Förvara kniven i ett säkert läge när den inte används, helst i ett fodral eller en låda.
- Var försiktig när du fäller ut och stänger kniven för att undvika klämrisk.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd fingerflippern eller dubbla tumstudsar för att fälla ut bladet.
- Se till att kniven är helt utfälld och låst i öppet läge innan du börjar använda den.

2. Användning av kniven:

- Använd kniven för avsedda ändamål som skärning av material.
- Undvik att använda kniven för att skära genom hårda eller oegentligheter som kan skada bladet.

3. Stänga kniven:

- Tryck på tumstudsens eller använd fingerflippern för att fälla tillbaka bladet.
- Kontrollera att bladet är helt stängt innan du förvarar kniven.

Avfallshantering

- När kniven når slutet av sin livslängd, se till att den avfallshanteras på ett miljövänligt sätt.
- Kontakta lokala avfallshanteringsmyndigheter för riktlinjer om hur du ska kassera kniven på ett säkert sätt.

Kontaktinformation för ytterligare support

För frågor eller mer information om produkten, vänligen kontakta din återförsäljare eller besök tillverkarens webbplats för support.

Dessa säkerhetsinstruktioner är utformade för att säkerställa en säker och effektiv användning av Shrade 3.3" Ultraglide Folder. Genom att följa dessa riktlinjer skyddar du dig själv och andra från potentiella risker. Tack för att du väljer Shrade!