

3.5" Ultraglide Folder Box

- 3CR13 STEEL BLADE, G10 SCALE HANDLE
- Finger flipper
- Dual thumb studs
- Pocket clip
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: 3.5" Ultraglide Folder Box
- Manufacturer: Shrade
- Product no.: EU1001741
- Mfr. No.: 1121084
- Color: Black, Brown
- Delivery weight: 0.78kg
- UPC: 661120081579

Table of Contents

- [Startpage](#)
- [English: Shrade 3.5" Ultraglide Folder Box Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade 3.5" Ultraglide Folder Box](#)

Shrade 3.5" Ultraglide Folder Box Safety Instructions

Introduction

Thank you for choosing the Shrade 3.5" Ultraglide Folder Box. This guide provides important safety instructions to ensure the safe use of your knife. Please read this manual carefully before using the product.

General Safety Guidelines

- Always keep the knife out of reach of children.
- Do not use the knife for purposes other than its intended use.
- Inspect the knife before each use for any signs of damage or wear.
- Use caution when handling the knife, especially when opening and closing the blade.
- Ensure that your hands are dry and free from any substances that may cause slipping when using the knife.
- Store the knife in a safe and secure location when not in use.
- If the knife becomes damaged, discontinue use immediately and seek a replacement.

Specific Safety Precautions for Use

- **Blade Handling:** Always handle the blade with care. The blade is sharp and can cause injury.
- **Flipper and Thumb Studs:** Use the finger flipper and dual thumb studs to open the knife safely. Ensure your fingers are clear of the blade path.
- **Pocket Clip:** When carrying the knife, use the pocket clip to secure it in your pocket. Ensure the knife is fully closed before placing it in your pocket.
- **Environmental Considerations:** Avoid using the knife in wet or slippery conditions to prevent accidents.
- **Emergency Situations:** In case of an injury, seek medical attention immediately.

Instructions for Installation and Usage

• Opening the Knife:

1. Hold the handle firmly with one hand.
2. Use your index finger to push the finger flipper or press the thumb stud with your thumb.
3. The blade will open smoothly; ensure your fingers are clear of the blade path.

• Closing the Knife:

1. Hold the handle firmly with one hand.
2. Press the blade lock (if applicable) to release the blade.
3. Carefully fold the blade back into the handle, ensuring fingers are clear of the blade path.

• Cleaning and Maintenance:

- Regularly clean the blade and handle with a dry cloth.
- Avoid using harsh chemicals that may damage the materials.
- Lubricate the pivot point occasionally to ensure smooth operation.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged beyond repair, consider recycling the metal components where possible.
- Follow local regulations for the disposal of sharp objects to prevent injury to waste handlers.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Shrade 3.5" Ultraglide Folder Box, please reach out to your local retailer or manufacturer.

Thank you for your attention to these safety instructions. Enjoy your Shrade knife responsibly!

Säkerhetsinstruktioner för Shrade 3.5" Ultraglide Folder Box

Introduktion

Tack för att du valt Shrade 3.5" Ultraglide Folder Box. Denna produkt är designad för att ge en säker och effektiv användning. Vänligen läs dessa säkerhetsinstruktioner noggrant för att säkerställa en trygg användning av produkten.

Allmänna säkerhetsriktlinjer

- Använd endast produkten för dess avsedda syfte.
- Förvara produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera osäkra produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid produkten med försiktighet.
- Undvik att använda produkten om den är skadad.
- Håll fingrarna borta från bladet när du öppnar och stänger produkten.
- Använd produkten på en stabil yta för att förhindra olyckor.
- Använd inte produkten i närheten av vatten eller andra farliga miljöer.

Instruktioner för installation och användning

- För att öppna bladet, använd fingerflippern på baksidan av handtaget.
- För att stänga bladet, tryck på dubbel tummstuds samtidigt som du försiktigt trycker ned bladet.
- För att fästa fickklämman, skruva fast den på önskad plats på handtaget.
- Rengör produkten med en mjuk trasa efter användning för att ta bort smuts och skräp.

Avfallshanteringsinstruktioner

- Kassera produkten i enlighet med lokala avfallsföreskrifter.
- Återvinn materialet om möjligt, inklusive metall och plastkomponenter.

Kontaktinformation för ytterligare stöd

För frågor eller ytterligare information om säkerhet, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att ha produktens modellnummer och inköpsinformation tillgänglig.

Tack för att du följer dessa säkerhetsinstruktioner och bidrar till en säker användning av Shrade 3.5" Ultraglide Folder Box.