

3.5" Ultraglide Folder Box - 3.5" Ultraglide Folder Clam

- 3CR13 STEEL BLADE, G10 SCALE HANDLE
- Finger flipper
- Dual thumb studs
- Pocket clip
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: 3.5" Ultraglide Folder Clam
- Manufacturer: Shrade
- Product no.: EU1001742
- Mfr. No.: 1121085
- Color: Black
- Delivery weight: 0.78kg
- UPC: 661120081586

Table of Contents

- [Startpage](#)
- [English: Shrade 3.5" Ultraglide Folder Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade 3.5" Ultraglide Folder](#)

Shrade 3.5" Ultraglide Folder Safety Instructions

Introduction

Thank you for choosing the Shrade 3.5" Ultraglide Folder. This guide provides essential safety instructions to ensure the safe and effective use of your knife. Please read this document carefully before using the product.

General Safety Guidelines

- Ensure that the knife is used only for its intended purpose.
- Always handle the knife with care to avoid accidental cuts or injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Regularly inspect the knife for any signs of damage or wear.
- If the knife is damaged, discontinue use immediately and seek guidance on repair or replacement.
- Familiarize yourself with the knife's features, including the finger flipper and thumb studs, to ensure safe operation.
- Always cut away from your body and keep your fingers clear of the blade edge.

Specific Safety Precautions for Use

- Use the knife on a stable surface to prevent slips and accidents.
- Avoid using excessive force when opening or closing the blade.
- Do not attempt to modify the knife or its components.
- Ensure that the blade is fully locked in place before using it for cutting.
- Be cautious when using the knife in wet or slippery conditions, as this may affect your grip.
- Store the knife in a secure location when not in use, preferably in a sheath or protective case.

Instructions for Installation and Usage

1. Opening the Knife

- To open the knife, use the finger flipper or the dual thumb studs.
- Ensure that your fingers are positioned away from the blade edge during this process.

2. Using the Knife

- Hold the handle firmly with one hand while using the other hand to guide the material being cut.
- Apply gentle pressure to the blade to achieve a clean cut without forcing it through the material.

3. Closing the Knife

- To close the knife, ensure your fingers are clear of the blade.
- Press the lock mechanism and carefully fold the blade back into the handle.
- Always check that the blade is securely closed before storing the knife.

4. Cleaning and Maintenance

- Clean the blade and handle regularly with a damp cloth to remove dirt and debris.
- Dry the knife thoroughly after cleaning to prevent rusting.
- Apply a small amount of oil to the pivot point to ensure smooth opening and closing.

Disposal Instructions

- Dispose of the knife responsibly and in accordance with local regulations.

- If the knife is damaged beyond repair, ensure that it is disposed of in a way that prevents accidental injury to others.
- Consider recycling the materials where possible.

Contact Information for Further Support

For any safety inquiries or additional support regarding your Shrade 3.5" Ultraglide Folder, please refer to the manufacturer's contact information provided with the product packaging.

By following these safety instructions, you can ensure the safe and effective use of your Shrade 3.5" Ultraglide Folder. Thank you for your attention to these important guidelines.

Säkerhetsinstruktioner för Shrade 3.5" Ultraglide Folder

Introduktion

Tack för att du valt Shrade 3.5" Ultraglide Folder. Denna fällkniv är designad för att ge dig en säker och effektiv användarupplevelse. För att säkerställa din säkerhet och för att maximera livslängden på produkten, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven med försiktighet och respekt.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage.
- Använd kniven endast för avsett syfte.
- Följ alltid lokala lagar och förordningar gällande bärande och användning av knivar.

Specifika säkerhetsåtgärder för användning

- Använd fingerflippern för att öppna kniven på ett säkert sätt.
- Stäng alltid kniven när den inte används.
- Använd kniven på en stabil och säker yta.
- Undvik att använda kniven i fuktiga eller hala miljöer.
- Håll alltid fingrarna borta från bladets kant när du stänger kniven.

Instruktioner för installation och användning

- **Öppning av kniven:**
 1. Håll kniven i en hand med bladet pekande bort från dig.
 2. Använd fingerflippern för att snabbt och säkert öppna kniven.
- **Stängning av kniven:**
 1. Tryck på den dubbla tummknappen med tummen.
 2. Fäll bladet tillbaka in i handtaget med den andra handen.
- **Användning av fickklämma:**
 - Fäst fickklämman på bältet eller i fickan för enkel transport.
 - Kontrollera att klämman är ordentligt fastsatt innan du bär kniven.

Avfallshanteringsinstruktioner

- Kasta inte kniven i hushållsavfall.
- Om kniven är skadad eller defekt, vänligen ta den till en återvinningsstation som hanterar metallavfall.
- Följ lokala riktlinjer för avfallshantering av vassa föremål.

Kontaktinformation för ytterligare stöd

För frågor eller säkerhetsförfrågningar angående denna produkt, vänligen kontakta den lokala återförsäljaren eller besök tillverkarens webbplats för mer information.

Vi tackar för att du har valt Shrade och hoppas att du får stor nytta av din 3.5" Ultraglide Folder. Var alltid säker och ansvarig vid användning av din kniv.