

SCH 12" Axe Box - Shrade SCH 4" Fixed Blade Para Box

- 3CR13 STEEL BLADE, GLASS FIBER NYLON HANDLE
- Lightweight
- Lanyard hole
- Sheath included
- Black oxide blade

NO IMAGE
AVAILABLE

Attributes

- Name: Shrade SCH 4" Fixed Blade Para Box
- Manufacturer: Shrade
- Product no.: EU1001743
- Mfr. No.: 1121086
- Color: Black
- Delivery weight: 1.33kg
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: Shrade SCH 12" Axe and Shrade SCH 4" Fixed Blade Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för Shrade SCH 12" Axe och Shrade SCH 4" Fixed Blade](#)

Shrade SCH 12" Axe and Shrade SCH 4" Fixed Blade Safety Instructions

Introduction

Thank you for purchasing the Shrade SCH 12" Axe and Shrade SCH 4" Fixed Blade. These tools are designed for durability and efficiency. To ensure your safety and the safe use of these products, please read and follow the guidelines outlined in this manual.

General Safety Guidelines

- Always handle tools with care and respect.
- Keep tools out of reach of children and vulnerable individuals.
- Inspect the tool before each use for any signs of damage or wear.
- Use the tools only for their intended purposes.
- Wear appropriate personal protective equipment (PPE) such as gloves and eye protection.
- Store tools in a dry place away from direct sunlight and moisture.
- Report any unsafe products or accidents to local authorities.
- Stay informed about any recall updates through the EU Safety Gate platform.

Specific Safety Precautions for Use

Shrade SCH 12" Axe

- Always use the axe with both hands for better control.
- Ensure that the area around you is clear of obstacles and bystanders before swinging the axe.
- Do not use the axe for prying or as a lever.
- Avoid using the axe in wet conditions to prevent slipping.
- Always cut away from your body to minimize the risk of injury.

Shrade SCH 4" Fixed Blade

- Always use the blade with caution and keep the edge away from yourself and others.
- Ensure the blade is securely sheathed when not in use.
- Do not attempt to catch a falling blade.
- Use the blade only on stable surfaces to prevent slips.
- Keep your fingers away from the blade edge during use.

Instructions for Installation and Usage

Using the Shrade SCH 12" Axe

1. Hold the axe with both hands, ensuring a firm grip on the handle.
2. Stand with your feet shoulderwidth apart and balance your weight.
3. Position the axe above the target and swing down in a controlled manner.
4. After use, clean the blade and store it in the provided sheath.

Using the Shrade SCH 4" Fixed Blade

1. Remove the blade from the sheath carefully, ensuring that your fingers are clear of the edge.
2. Use the blade for cutting tasks only, avoiding any twisting or prying motions.
3. After use, clean the blade and return it to the sheath immediately to prevent accidents.

Disposal Instructions

- Dispose of any damaged or broken tools in accordance with local waste disposal regulations.
- Do not throw tools in regular household garbage. Instead, consider recycling options where available.
- Ensure that blades are securely sheathed or wrapped before disposal to prevent injury.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the contact point provided with your product packaging or visit the manufacturer's website.

Thank you for choosing Shrade products. Your safety is our priority.

Säkerhetsinstruktioner för Shrade SCH 12" Axe och Shrade SCH 4" Fixed Blade

Introduktion

Tack för att du valt Shrade SCH 12" Axe och Shrade SCH 4" Fixed Blade. Dessa verktyg är utformade för att ge hög kvalitet och prestanda. För att säkerställa en säker och effektiv användning är det viktigt att följa dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt instruktionerna för att minimera riskerna för skador.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Kontrollera produkten för skador före användning. Använd inte produkten om den är skadad.
- Följ alltid lokala lagar och förordningar när du använder skärverktyg.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddshandskar och ögonskydd när du hanterar verktygen.
- Se till att arbetsområdet är rent och fritt från hinder.
- Använd inte produkten i närheten av brännbara material.
- Var medveten om din omgivning och undvik att använda verktyget i trånga utrymmen.
- Håll alltid bladet borta från kroppen och andra personer när du använder det.

Instruktioner för installation och användning

1. Förberedelse:

- Kontrollera att alla delar är intakta och att inga skador finns.
- Se till att du har rätt arbetskläder och skyddsutrustning på plats.

2. Användning av Shrade SCH 12" Axe:

- Håll axeln med båda händerna, en hand på skaftet och en nära bladet för bättre kontroll.
- Använd en stabil yta för att göra snitt.
- Undvik att använda axeln i fuktiga eller hala förhållanden.

3. Användning av Shrade SCH 4" Fixed Blade:

- Håll kniven med ett fast grepp och undvik att använda den med en hand.
- Använd alltid kniven bort från kroppen.
- Rengör bladet noggrant efter användning och kontrollera för skador.

Avfallshanteringsinstruktioner

- Avfallshantering av produkten ska ske enligt lokala miljöbestämmelser.
- Om produkten är skadad eller inte längre används, se till att den kasseras på ett säkert sätt för att undvika olyckor.
- Återvinn material där det är möjligt.

Kontaktinformation för ytterligare support

För frågor eller mer information om säkerhetsåtgärder och produktanvändning, vänligen kontakta din lokala återförsäljare eller besök tillverkarens officiella webbplats.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår högsta prioritet.