

Benji Folding Knife - Clam - Benji Folding Knife - Box

Perfect for your discreet EDC, this knife packs big features in a small package. This all-in-one pocket knife, money clip, and bottle opener fits cleanly into the coin pocket of your favorite jeans so you're always prepared.

NO IMAGE
AVAILABLE

Attributes

- Name: Benji Folding Knife - Box
- Manufacturer: M&P
- Product no.: EU1001749
- Mfr. No.: 1122566
- Color: Black
- Delivery weight: 0.01kg
- UPC: 661120081302

Table of Contents

- [Startpage](#)
- [English: M&P Benji Folding Knife Safety Instruction Guide](#)
- [Svenska: M&P Benji Folding Knife Säkerhetsinstruktioner](#)

M&P Benji Folding Knife Safety Instruction Guide

Introduction

Thank you for choosing the M&P Benji Folding Knife. This versatile tool is designed for everyday carry (EDC) and combines a pocket knife, money clip, and bottle opener in one compact design. To ensure your safety and the proper use of this product, please read this safety instruction guide carefully.

General Safety Guidelines

- Always handle the knife with care to prevent accidental cuts or injuries.
- Keep the knife away from children and vulnerable individuals to avoid misuse or accidents.
- Inspect the knife regularly for any signs of wear or damage. Do not use if damaged.
- Ensure the knife is stored in a safe place when not in use, preferably in a protective case or sheath.
- Follow all local laws and regulations regarding the carrying and use of knives.

Specific Safety Precautions for Use

- Always ensure the blade is fully extended and locked before use.
- Use the knife only for its intended purposes. Do not use it as a pry bar or for any task it is not designed for.
- When using the knife, keep your fingers and other body parts clear of the blade.
- Do not attempt to disassemble or modify the knife; this may compromise safety and functionality.
- Avoid using the knife in wet conditions to maintain grip and prevent slippage.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife securely by the handle.
- Use your thumb to push the blade out until it clicks into place, ensuring it is locked.

2. Using the Knife:

- Position the knife securely in your hand.
- Cut away from your body and ensure your cutting surface is stable.
- If using the bottle opener or money clip features, follow the respective instructions included in this guide.

3. Closing the Knife:

- Press the frame lock located on the handle to release the blade.
- Carefully fold the blade back into the handle until it clicks into place.

4. Storing the Knife:

- Store the knife in a dry location away from children.
- Consider using a knife sheath for added protection.

Disposal Instructions

- When disposing of the knife, ensure it is safely wrapped to prevent injury to waste handlers.

- Check local regulations for proper disposal methods of knives and sharp objects.
- If the knife is broken or unusable, consider recycling the metal components where possible.

Contact Information for Further Support

For any safety inquiries or concerns regarding your M&P Benji Folding Knife, please refer to the manufacturer's contact information provided with your product packaging or visit the official M&P website.

By following these guidelines, you can ensure a safe experience with your M&P Benji Folding Knife. Always prioritize safety and handle your knife responsibly. Thank you for being a responsible consumer!

M&P Benji Folding Knife

Säkerhetsinstruktioner

Introduktion

Tack för att du valt M&P Benji Folding Knife. Denna kniv är designad för att vara en praktisk och säker följeslagare för din dagliga användning. För att säkerställa en trygg och säker användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt sätt och i enlighet med gällande lagar och förordningar.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage. Använd inte kniven om den är skadad.
- Förvara kniven på en säker plats när den inte används.
- Rapportera omedelbart eventuella farliga produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för avsett syfte. Undvik att använda den för att skära material som är för hårda eller för mjuka.
- Var försiktig när du fäller ut eller fäller ihop kniven. Håll fingrarna borta från bladets väg.
- Använd alltid kniven på en stabil yta för att förhindra olyckor.
- Om du använder kniven för att öppna flaskor, se till att du har ett fast grepp för att undvika skador.
- Använd skyddshandskar om du är osäker på din förmåga att hantera kniven säkert.

Instruktioner för installation och användning

1. **Fäll ut kniven:** Håll kniven i ena handen och tryck på ramlåset med tummen för att fälla ut bladet.
2. **Användning:** Använd kniven för att skära eller öppna föremål, men se till att du har ett bra grepp och att bladet är riktat bort från kroppen.
3. **Fäll ihop kniven:** Tryck på ramlåset igen och fäll försiktigt tillbaka bladet i handtaget.
4. **Förvaring:** Förvara kniven i ett torrt och svalt område. Använd pengaklämman för att fästa kniven i fickan eller på bältet för säker transport.

Avfallsinstruktioner

- Kniven bör kasseras på ett säkert sätt när den inte längre är i bruk.
- Kontakta lokala avfallshanteringsmyndigheter för att få information om hur man korrekt återvinner eller kasserar metallprodukter.

Kontaktinformation för ytterligare support

För frågor eller mer information om säker användning av M&P Benji Folding Knife, vänligen kontakta en lokal återförsäljare eller besök tillverkarens webbplats för support och resurser.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är viktig för oss.