

Sideburn Folding Knife - Clam - Sideburn Folding Knife - Box

Don't let the lightweight and sleek design fool you from thinking it's your ordinary everyday knife, this EDC has a Modified Warncliffe blade giving it an edge above all the rest.

NO IMAGE
AVAILABLE

Attributes

- Name: Sideburn Folding Knife - Box
- Manufacturer: M&P
- Product no.: EU1001751
- Mfr. No.: 1122568
- Color: Black
- Delivery weight: 0.01kg
- UPC: 661120081166

Table of Contents

- [Startpage](#)
- [English: M&P Sideburn Folding Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P Sideburn Folding Knife](#)

M&P Sideburn Folding Knife Safety Instructions

Introduction

Thank you for choosing the M&P Sideburn Folding Knife. This guide provides essential safety instructions to ensure the safe use of your knife. Please read this manual carefully before using the product. Adhering to these guidelines will help you avoid potential hazards and ensure a safe experience.

General Safety Guidelines

- Always handle the knife with care.
- Keep the knife out of reach of children.
- Use the knife only for its intended purpose.
- Regularly inspect the knife for any signs of damage or wear.
- If the knife is damaged, discontinue use immediately.
- Store the knife in a safe and dry location when not in use.
- Be aware of your surroundings when using the knife to avoid accidents.

Specific Safety Precautions for Use

- Ensure the blade is fully deployed and locked before use.
- Avoid placing your fingers near the blade edge when opening or closing the knife.
- Do not use excessive force when cutting; let the blade do the work.
- Always cut away from your body and keep your hands clear of the cutting path.
- Use protective gloves if necessary, especially when handling tough materials.
- Do not attempt to modify or disassemble the knife.
- Do not use the knife for prying or as a tool for other purposes.

Instructions for Installation and Usage

1. Opening the Knife:

- Use the finger flipper to deploy the blade.
- Ensure the blade locks in place before use.

2. Using the Knife:

- Hold the handle firmly with one hand.
- Position the material to be cut securely.
- Apply even pressure while cutting, keeping fingers clear of the blade.

3. Closing the Knife:

- Press the release mechanism to unlock the blade.
- Carefully fold the blade back into the handle.
- Ensure the blade is fully closed and locked before storing.

4. Maintenance:

- Clean the blade regularly with a soft cloth.
- Lubricate the pivot point with knife oil to ensure smooth operation.
- Store the knife in a protective sheath or case.

Disposal Instructions

- Dispose of the knife in accordance with local regulations.
- If the knife is damaged beyond repair, ensure that the blade is safely contained to prevent injury during disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P Sideburn Folding Knife, please refer to the EUbased contact point provided by the manufacturer.

By following these safety guidelines and instructions, you can enjoy the benefits of your M&P Sideburn Folding Knife while minimizing the risk of injury. Always prioritize safety and responsible usage. Thank you for your attention!

Säkerhetsinstruktioner för M&P Sideburn Folding Knife

Introduktion

Tack för att du har valt M&P Sideburn Folding Knife. Denna kniv är designad för att vara både funktionell och säker. För att säkerställa en trygg användning, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt och säkert sätt.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador. Använd inte en skadad kniv.
- Följ alltid tillverkarens instruktioner för användning och underhåll.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder för användning

- Använd alltid kniven på en stabil och säker yta.
- Håll fingrarna borta från bladet när du öppnar eller stänger kniven.
- Använd kniven endast för dess avsedda syfte; undvik att använda den för att skära igenom hårda material som metall eller glas.
- Förvara kniven i ett säkert läge när den inte används, helst i en knivficka eller ett skyddande fodral.
- Var medveten om omgivningen när du använder kniven för att undvika olyckor.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd fingerflippern för att öppna bladet. Tryck ner flippern med ett snabbt rörelse för att frigöra bladet.

2. Stäng kniven:

- Tryck på låsmekanismen för att frigöra bladet och stäng det försiktigt. Se till att inga fingrar eller andra kroppsdelar är i vägen.

3. Underhåll:

- Rengör kniven med en mjuk trasa efter varje användning.
- Smörj gångjärnen regelbundet med lämplig olja för att säkerställa smidig funktion.

Avfallshantering

- Kasta inte kniven i hushållsavfallet. Följ lokala föreskrifter för avfallshantering av vassa föremål.
- Om kniven är skadad eller inte längre användbar, överväg att lämna den till en återvinningsstation eller en speciell insamlingspunkt för farligt avfall.

Kontaktinformation för vidare support

För frågor eller mer information om säkerhet och användning av M&P Sideburn Folding Knife, vänligen kontakta den lokala återförsäljaren eller tillverkaren. Se till att alltid ha köpebevis till hands vid förfrågningar.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet!