

Sear Spring Assist Folding Knife - Clam - Sear Spring Assist Folding Knife - Box

As smooth and polished as a custom trigger, the M&P® Sear springs into action with just a touch of the index flipper.

NO IMAGE
AVAILABLE

Attributes

- Name: Sear Spring Assist Folding Knife - Box
- Manufacturer: M&P
- Product no.: EU1001758
- Mfr. No.: 1122580
- Delivery weight: 0.01kg
- UPC: 661120080763

Table of Contents

- [Startpage](#)
- [English: M&P Sear Spring Assist Folding Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P Sear Spring Assist Folding Knife](#)

M&P Sear Spring Assist Folding Knife Safety Instructions

Introduction

Thank you for choosing the M&P Sear Spring Assist Folding Knife. This guide provides important safety instructions to ensure your safe use of this product. Please read this manual carefully before using your knife.

General Safety Guidelines

- Always handle the knife with care to avoid accidental cuts or injuries.
- Keep the knife out of reach of children and vulnerable individuals.
- Ensure that you are in a safe environment when using the knife, away from people and animals.
- Regularly inspect the knife for any signs of damage or wear. Do not use if damaged.
- Always store the knife in a safe place when not in use, preferably in a sheath or a designated storage area.

Specific Safety Precautions for Use

- **Cutting Surface:** Use the knife on a stable and flat cutting surface to prevent slips and accidents.
- **Opening Mechanism:** Always use the index flipper to open the knife. Do not force the blade open manually.
- **Blade Care:** Keep the blade clean and dry to maintain its sharpness and prevent rust.
- **Closing the Knife:** Always ensure the blade is fully closed before storing or carrying the knife.
- **Personal Safety Gear:** Consider wearing cutresistant gloves when using the knife for added protection.

Instructions for Installation and Usage

Opening the Knife

1. Hold the knife firmly by the handle with one hand.
2. With your index finger, gently push the flipper located on the back of the blade.
3. The blade will spring open smoothly. Ensure your fingers are clear of the blade path.

Using the Knife

- Use the knife for its intended purpose only—cutting and slicing.
- Avoid using the knife for prying or as a lever.
- Always cut away from your body to minimize the risk of injury.

Closing the Knife

1. Ensure that the blade is clean and free from any debris.
2. Hold the handle securely.
3. Press the thumb stud or push the blade down gently to close the blade into the handle.
4. Ensure the blade is fully retracted and locked in place before storage.

Disposal Instructions

- When the knife reaches the end of its life or is damaged beyond repair, dispose of it responsibly.
- Do not throw the knife in regular household waste. Instead, consider recycling the metal components where possible.
- If you are unsure how to dispose of the knife, contact your local waste management authority for guidance.

Contact Information for Further Support

For any safety inquiries or concerns regarding the M&P Sear Spring Assist Folding Knife, please contact the manufacturer or your local retailer. Ensure that you have the product details ready for a more efficient response.

Conclusion

By following these safety instructions, you can enjoy the functionality of your M&P Sear Spring Assist Folding Knife while minimizing risks. Always prioritize safety and responsible usage. Thank you for your attention to these important guidelines.

Säkerhetsinstruktioner för M&P Sear Spring Assist Folding Knife

Introduktion

Tack för att du valt M&P Sear Spring Assist Folding Knife. Denna kniv är designad för att ge en säker och effektiv användning. För att säkerställa en trygg och korrekt användning av produkten, vänligen läs igenom och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven med försiktighet och respekt.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage.
- Använd kniven endast för avsedda ändamål.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder vid användning

- Se till att kniven är i fullt fungerande skick innan användning.
- Använd alltid kniven på en stabil yta.
- Håll fingrarna borta från bladet när du öppnar eller stänger kniven.
- Använd fingerflippern för att öppna kniven; tryck inte för hårt.
- Förvara kniven i ett säkert läge när den inte används.

Instruktioner för installation och användning

1. **Öppning av kniven:**
 - Använd fingerflippern för att öppna kniven. Tryck lätt med pek fingret för att aktivera fjädern.
2. **Stängning av kniven:**
 - Håll kniven i ett fast grepp och tryck på låsmekanismen för att fälla ihop bladet.
3. **Förvaring:**
 - Förvara kniven på en torr plats, borta från direkt solljus och fukt.
 - Använd den medföljande fickklämman för att fästa kniven på bältet eller i fickan när den inte används.

Avfallshantering

- Kniven bör kasseras enligt lokala föreskrifter för metallavfall.
- Se till att kniven är säker att hantera innan du kasserar den för att undvika skador.

Kontaktinformation för vidare stöd

För frågor eller support, vänligen kontakta en auktoriserad återförsäljare eller tillverkare. Kontrollera alltid den senaste informationen om säkerhetsåtgärder och produktåterkallelser via EU:s Safety Gateplattform.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår högsta prioritet.